




SMART S2

Product List

Before use, please check carefully if the package contains all the following items. If case of any missing items, please contact our customer service or your dealer.

- **Smartphone gimbal stabilizer x 1**
- **USB Type-C charging cable x 1**
- **Tripod x 1**
- **User manual x 1**



APP and Tutorials

1. Download APP

Please scan the QR code below or search **"AOCHUAN"** in your APP store to download our official APP.



Support IOS / Android



Download on the
App Store



Download for
Android



2. Watch video tutorials



Instagram



YouTube



Facebook

Product Information

Magnetic attraction



Roll axis

Pan axis

LED display panel

Zoom toggle switch

Photo / Video button

Tilt axis

Built-in extension rod

Joystick

Power button



Product Information



Operation Panel Information

1 LED display panel



Battery life

PF

Pan follow mode

F

Full follow mode

L

Full lock mode

POV

POV mode

GO

GO mode

DM

Inception mode



Bluetooth



2 Joystick



Up / Down / Left / Right: Adjust the mobile direction

Single click: Switch PF/F/L/POV mode

Double click: Recenter the smartphone

3 Power button



Long press: power on / off

Single click: Switch fill light among low beam/medium beam/high beam/off in a loop

Operation Panel Information

4 Focus roller



Adjust focus point/ virtual and real
(in combination with APP)

5 Zoom toggle switch



Adjust time parameters of AB track
Adjust focal length / distance
(in combination with APP)

6 Photo / Video button



Single click: take photo / video

Double click: switch front / rear camera
(in combination with APP)



Operation Panel Information

7 AB button



Single click: set A (starting point)'s location

Double click: set B (finishing point)'s location

Triple click: start A → B trajectory movement, trigger photo/video function simultaneously

Five click: stop A → B trajectory movement

Long press: enter / exit AB mode

8 Trigger switch



Single click: switch portrait / landscape (hold the gimbal horizontally)

Double click: Enter / Exit, DM Automatic Dreamscape Mode

Triple click: Enter / Exit, Self-timer mode

long press: GO mode



Equipment Expansion

■ Cold shoe interface

The Smart S2 body is equipped with a universal cold shoe connector, supports 360° free rotation adjustment, and is easily compatible with third-party microphone or fill-in light and other shooting and audio equipment.



* Before installing accessories, please check with the accessory manufacturer for compatibility of the device interface and cable length, etc., so as to meet your actual usage requirements.

Gimbal Charging

■ Battery Charging

Use the equipped charging cable to connect power adapter and the charging port of the stabilizer. When the LED panel is on, the stabilizer is in charging state; When [] icon appears, the battery is fully charged.



Before first use, please fully charge Smart S2 gimbal to ensure its normal operation.

Product Parameters

Product size	128*123*302.5mm
Product weight	630g (Tripod is not included)
Payload	≤300g
Battery capacity	3.6V / 5200mAH
Standby time	16 hours (standby)
Charging time	About 3.5 hours
Working voltage	7.6V
Working current	280mA (standby mode)
Working temperature	-10°C-55°C
Phone width range	55-95mm
Phone thickness range	<10.5mm
Controllable pan angles	360° horizontal rotation
Controllable tilt angles	324°
Controllable roll angles	±25°

* Above data are the testing data in the AOCHUAN laboratory and is subject to variance to some extent under different testing conditions. Please refer to the real using experience.

Warranty Terms

1. Within 15 days from the date of purchase, the product with any functional malfunction or quality problems will be replaced for free, under the premise that the product and packaging are not damaged. We will offer a brand new one after confirming the product problem.
2. The product will enjoy 1-year free warranty for use under normal conditions (all accidental or artificial damages, and damages caused by improper disassembly or misuse are NOT covered by the warranty).
3. Please keep and offer the warranty card for claiming the warranty service.



connect us on facebook

E-mail: aochuan_gimbal@outlook.com

WEB: WWW.AOCHUAN-TECH.COM

ADDR: 4th Floor and Half of the 3rd Floor, No.9 Huayuan Road, Xiaolan Town, Zhongshan City, Guangdong Province, China

Warranty Card

Customer Information

Customer Name:

Phone Number:

Address:

Sales Information

Sales date:

Product Serial Number:

Distributor Name:

Distributor's Contact Number:

First Maintenance Record

Service Date:

Repairman Signature:

Cause of Problem:

Service Result: ☐ Solved ☐ Unsolved ☐ Refunded/Replaced

Customer Support

Zhongshan Yang Guo Electronic Technology Co., Ltd.

Address: NO.9 Huayuan Road, Xiaolan Town, Zhongshan
City, Guangdong, China.

Email: aochuan_gimbal@outlook.com

Website: www.aochuan-tech.com