

Product packaging



Product parameters

GA: Water heating 3A;
GB: Electric heating 16A
GC: Linkage; M: Gas boiler 3A

Electrical Specifications:

Thank you for your trust and support!

We have adopted advanced technology and perfect craftsmanship so that your new thermostat will provide you with a suitable temperature environment every day in the future. It makes your life more pleasant and artistic and making your living environment more fashionable aesthetic.

For detailed instructions on installing and using this thermostat, please read this manual carefully.

Please get in touch with a professional to install the thermostat for you. Besides, please install and use this product within the scope of the law.

1.Temperature 2.Temperature 3. Display screen:LCD

The intelligent digital humidity controller is a floor heating system suitable for room temperature control and household temperature control. It controls the operating status of the floor heating equipment by sensing the comparison between the ambient temperature and the set temperature. While improving comfort, it achieves the purpose of energy saving.

The digital thermostat adopts microcomputer control technology and has an elegant design, and is easy to use. Moreover, it has manual and automatic functions, programmable functions, and state memory functions.

Sensor : NTC accuracy : $\pm 1^{\circ}\text{C}$

4. Working environment: -5~50°C	5. Self-consumption power: <1W	6. Temperature setting: 5~60°C
---------------------------------	--------------------------------	--------------------------------

7. Display range: 0-51°C
8. Load current: water heater 3A (resistive) electric heater 16A (resistive) 02


9.Voltage :AC95-220V, 50/60Hz

10. Electrical safety standards: GB14536.1-2008



Mounting steps

1. Read this manual carefully. A general operation may damage the product or cause a dangerous situation.
2. The installation personnel must be well-trained and experienced service technicians.
3. After the installation is complete, please close this manual carefully and operate this product following the user guide. Note: There is a risk of electric shock or equipment damage.


1. Connect the power box according to the wiring diagram



GA : Water heating



3.Screw the power supply into the box
of 86



4. Connect the power board to the control board line, and align the buckle at 30 degrees to complete the installation.

Time programming instructions

Long press the M key to enter the programming setting, short press the M key to switch options, press the up or down key to adjust the parameters of each option, and press the  key to exit and save mode.

Thermostat User Guide

Advanced Option Setting

In the shutdown state, press the M key and  key. Press for 5 seconds to enter the advanced option setting

Press the M key to enter thenext option, then press the up and down key to adjust options , and press the key to exit the advanced option setting mode.

08