

Mini Smart Projector

※Quick Installation Guide※




Attention

Please read this manual carefully before use and keep it for future reference.

1. To reduce the risk of fire and electric shock, do not expose the projector to rain or fog.
2. Please use the original power adapter. The projector should operate under the specified rated power supply.
3. When the projector is in use, do not look directly into the lens. The strong light may flash your eyes and cause slight discomfort. Children should use the projector under adult supervision.
4. Do not cover the projector vents. Overheating can shorten the projector's lifespan and pose a safety risk.
5. Regularly clean the projector vents, as dust buildup may cause cooling malfunctions.
6. Do not use the projector in greasy, damp, dusty, or smoky environments. Oil or chemicals may lead to malfunction.
7. Handle the product with care during daily use.
8. Disconnect the power if the projector will not be used for an extended period.
9. Non-professionals are prohibited from disassembling the projector for testing or maintenance.


Product Overview

This manual is for reference only and is subject to the actual product. We reserve the right to modify product features and interfaces outlined in this manual without prior notice.




- | | |
|----------------|-------------------|
| ① Power Button | ④ Micro HDMI Port |
| ② USB Port | ⑤ IR Receiver |
| ③ Headset Jack | ⑥ Power Port |
| | ⑦ Vent |

Focus Wheel




Rotating support bracket



Hovering freely within the range of 0 to 30 degrees.


Remote Control Overview



Switching Applications


On the home screen, select "My Apps" and press the OK button to view installed applications. Press any app icon to switch between applications.

All apps can be clearly distinguished from the icons.




Settings

On the home screen, select the "Settings" option and press the OK button to enter the settings screen. From here, you can configure general, display, and system



Network Settings


On the settings screen, select the Wifi icon and press OK to access the network settings. To connect to a Wifi network, toggle the switch to turn Wifi on. A list of available networks will appear within seconds. Select the Wifi SSID you want to connect to and press the OK button, then enter the password when prompted to establish the connection.



BT Settings


Bluetooth headset connection operation

On the settings screen, select the Bluetooth icon and press the OK button to open the Bluetooth settings. To pair a Bluetooth device, toggle the switch to enable Bluetooth. A list of available devices will appear shortly. Select the device you want to pair with and press the OK button. Once pairing is complete, the projector will be successfully connected.




Language Settings

On the settings screen, select the Language icon and press the OK button to access language options. Choose your preferred language and press the OK button to confirm.




Other Settings

Under System Configurations, you can adjust the date and time, reset the device, view projector information, or update the firmware.




Time & Timezone Settings

To set the date and time zone, select Time & Timezone to access its settings. Toggle the switch to enable time configuration, then adjust the time zone as needed.




Projection Settings

Under Display Settings, you can fine-tune the Trapezoid and Manual Keystone settings for optimal image quality. To adjust Trapezoid Settings, select the second icon and press the OK button. Then, toggle the switch to enable the feature and follow the on-screen instructions to complete the image calibration.



Signal Source

After connecting the projector to an external device, select the "Source" option from the home screen to access the input selection menu. Choose the appropriate input source based on the connected device and press OK to confirm.




Miracast


Make sure your Android device is connected to the same Wifi network as the projector.

Then, follow these steps:

Home Screen → My Apps → Miracast → Enable Miracast service → Turn on phone mirroring → Connect.




Android Device:




Airplay

Ensure your iOS device (such as an iPhone or iPad) is connected to the same Wifi network as the projector. Then, follow these steps:

Home Screen → My Apps → AirPin → Enable AirPin service → Turn on Screen Mirroring → Connect.



iOS Device:



Safety instructions

- Please pay close attention to the important information regarding the operation and maintenance of the projector. Reading this carefully can help prevent issues and extend the projector's lifespan.
- Consult qualified personnel for installation and repair services. Avoid using damaged wires, accessories, or other peripherals.
- Keep the projector away from flammable materials, explosive environments, and areas with strong electromagnetic interference (e.g., large radar stations, power stations, substations). Avoid exposure to strong ambient light, including direct sunlight.
- Ensure the projector vents are not covered.
- Use only the original power adapter.
- Maintain adequate ventilation and ensure vents remain unobstructed to prevent overheating.
- Do not look directly into the lens while the projector is operating, as the intense light can cause eye discomfort or pain.
- Avoid bending or dragging the power cord.
- Do not place the power cord under the projector or heavy objects.
- Avoid covering the power cord with soft materials.
- Do not expose the power cord to heat.

Disclaim

This manual provides general instructions only. The images and functions described herein are subject to the actual product. Our company is committed to enhancing product performance and reserves the right to modify product features and interfaces outlined in this manual without prior notice.

Please store your device properly. We are not liable for any loss resulting from incorrect operation of software/hardware, repairs, or other causes. Additionally, we are not responsible for any claims made by third parties. This manual has been thoroughly reviewed by a professional engineer; however, please understand that some omissions may be unavoidable.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure

Attention:

When the projector is in use, avoid looking directly into the lens, as the intense light may flash in your eyes and cause slight discomfort. Children should operate the projector only under adult supervision.