

Προβολέας Blitzwolf BW-V1

BLITZWOLF · EAN 5907085525075

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Blitzwolf BW-V1 Projector

User Manual

TABLE OF CONTENTS

Product Appearance

Package Contents

Projector Lens Infrared Remote Control Window

Projector x1 Power Cable x1 HD Cable x1

Knob Anti-slip Mat

USB Output 5V Audio Output Port

Remote Control x1 Projector User Manual

(Batteries not included)

Heat Dissipation Window

Note: Do not block any ventilation openings! On/Off Focus

Remote Control Operating Instructions

Power Switch

Menu Signal Source

Scroll Up Connect the power cable to Press the power button to

the projector. turn on the projector. Scroll Left Scroll Right

OK

Scroll Down

Home Back

Decrease Increase Volume HD Cable Connect the projector to a device

Volume supporting HD port. Mute

Select HD as the input signal source. Press the power button twice to turn off the projector.

Adjust the focus knob to

achieve the best image quality. Connection

Projector Interface Connection

Connecting multiple devices and applications. Format Processing

File Extension

Video Playback

Photo Preview

Audio Playback

3.5 mm Audio Connection Menu Settings

a. Use the 3.5 mm audio jack to connect headphones and speakers. Amplifier

Stationary

Audio Cable

(Cable not included)

Parameter Option

OSD Language Language Settings

Restore Factory Settings

Mixing

OSD Duration

Blue Screen Off. Firmware Update (USB)

Parameter

Parameter Option Option

Image Mode Standard / Medium / Warm / User / Cool Sound Mode Standard / Music / Movie / Sport / User

Color Temperature Medium / Warm / User / Cool Balance

Aspect Ratio Automatic Volume

Noise Reduction

Projection Direction Front Projection / Rear Projection / Ceiling Projection
/ Rear Projection / Ceiling Projection

HD Mode PC

Display Size Reduction 100%

Parameter Option

Sleep Timer

WARNING: Gray options can only be set after entering the appropriate mode. Technical

Features

Product Model

Image System Light Source

Support Ratio

Max Ratio

Image Size Projection Distance 2.72 - 9.84 feet

Speaker Power

Weight 0.83 pounds Size

Input Output

Projection Mode Front / Rear / Ceiling

Ceiling

Projector Mounting

All information regarding product usage can be found in the user manual. Before you start using it, familiarize yourself with its content and follow the instructions provided. Also, review the information below before use:

Usage Warnings

Risk of Product Damage:

- Ensure that the projector is connected to a power source that complies with the device's specifications. Using inappropriate adapters or cables may damage the device.
- Portable projection screens should be set up on a stable surface to prevent tipping over. The mount or stand must be properly installed according to the user manual.
- When transporting projectors or screens, avoid shocks and impacts that may damage the lens, projector matrix, or screen deployment mechanism.

Risk of Overheating:

- Ensure that the projector is used in a location with adequate ventilation. Never cover ventilation openings or use the device near flammable materials.

- Ensure at least 20 cm of free space around the projector for proper cooling. Danger to children and untrained users:

- Projectors emit an intense beam of light that can be hazardous to eyesight, especially for children. Ensure that children do not look directly into the lens while the device is in operation.

- Portable projection screens, especially larger models, can be unstable. Do not allow children to play near the stands or attempt to fold and unfold the screens, as this may lead to them tipping over and causing injuries.

- Projector accessories, such as remote controls, adapters, or connectors, contain small parts that may pose a choking hazard. Store these items out of reach of children.

- When using the projector or screen, ensure that power and signal cables are properly routed and secured to prevent accidental tripping by children or damage to the devices.

- Projectors and screens are not toys. Never allow children to operate devices that require proper technical knowledge and caution without supervision.

- Ensure that the projector is placed on a stable surface out of reach of children to prevent it from being accidentally knocked over.

Compatibility:

- Ensure that devices such as computers, laptops, or players are compatible with the standards supported by the projector (e.g., HDMI, USB-C, Wi-Fi).
 - Match the projector's resolution and aspect ratio to the projection screen (e.g., 16:9 or 4:3) to avoid distortion. Environmental hazard:
 - Used projectors, screens, and accessories should be disposed of properly at e-waste collection points, in accordance with local environmental protection regulations. Avoid throwing them in regular waste bins to prevent harmful effects on the environment.
- Information on proper usage Recommendations for use:
- Use the projector in a dimly lit room for the best image quality.
 - Set the projector at the recommended distance from the screen. Details can be found in the product manual.
 - Adjust the brightness, contrast, and sharpness of the image according to lighting conditions and projection size.
 - Use screens according to the manufacturer's instructions, avoiding excessive stretching of the material, which may lead to damage.
 - Ensure that the projector has adequate space around the ventilation openings. Avoid covering these openings to prevent overheating.
 - Do not use the projector for extended periods without breaks. For intensive use, take breaks to allow the device to cool down.
- Maintenance and storage:
- Regularly clean the projector lens and screen surface with a soft, dry cloth. Do not use chemicals that may damage the device.
 - Store projectors and screens in a dry, cool place. Protect them from moisture, dust, and direct sunlight.
 - When transporting, use dedicated covers or cases to protect the device from shocks and mechanical damage.
- Additional precautions User customization:
- Choose a projector and screen tailored to your needs, such as business presentations, home cinema, or gaming. Pay attention to parameters such as brightness (lumens) and resolution.
 - If the projector supports smart features, such as streaming apps, ensure that your device is compatible with these features.
- Damage and service:
- In case of damage, such as cracks in the casing, difficulties in displaying images, or power issues, immediately stop using the device and contact an authorized service center.
 - Do not attempt to repair the projector or screen yourself. Only authorized service will ensure compliance with warranty conditions.
 - Check the condition of cables, connectors, and the projector lamp. Replace them with

original parts from the manufacturer if worn out. Declaration of conformity

The products have been designed in accordance with the safety requirements specified in Regulation (EU) 2023/988. They meet the relevant technical standards, including those concerning electromagnetic compatibility (EMC), electrical safety, and protection of users from mechanical and environmental hazards. Environmental protection

Used electronic equipment marked in accordance with the European Union directive must not be disposed of together with other municipal waste. It is subject to selective collection and recycling at designated points.

By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health due to its physical and chemical structure aging over time and usage. The manufacturer specifies the maximum operating time of the device in laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. The actual operating time may differ from that declared in the offer and is not a defect of the device but a feature of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.18V or 15% of the total capacity. Lower values, such as 2.5V for the cell, permanently damage it and are not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. The product should be regularly maintained (cleaned) either by the user or by specialized service points at the user's cost and responsibility.

In the absence of information about necessary maintenance or service actions in the user manual, the physical condition of the product should be assessed regularly, at least once a week, to determine any deviation from a physically new product. If any deviation is detected or identified, urgent maintenance (cleaning) or service actions should be taken. Lack of proper maintenance (cleaning) and response upon detection of a deviation may lead to permanent damage to the product. The guarantor is not responsible for damages resulting from negligence.

Detailed information on the distributor/manufacturer warranty conditions is available on the website <https://serwis.innpro.pl/gwarancja>.

LIPO Battery

The device is equipped with a LI PO (lithium polymer) battery, which, due to its physical and chemical structure, ages over time and usage. The manufacturer specifies the maximum

operating time of the device in laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. The actual operating time may differ from that declared in the offer and is not a defect of the device but a feature of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.5V or 5% of the total capacity. Lower values, such as 3.2V for the cell, permanently damage it and are not covered by the warranty.

In the case of discontinuing the use of the battery or the entire device for more than one month, the importer: must charge the battery to 50% and check its charge level every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. INNPRO Robert Błędowski sp. z o.o. ul. Rudzka 65c 44-200 Rybnik, Poland tel. +48 533 234 303 hurt@innpro.pl www.innpro.pl Responsible entity: VISHTEC Ltd Address: 3rd floor office 5, Plovdiv 2 Liuben Karavelov bul, 4002 Bulgaria Contact: compliance@vish-tec.com