


■ Tire Inflator

■ A14



User Manual	【01 - 04】
用户手册	【05 - 08】
Benutzerhandbuch	【09 - 12】
Manuale d'uso	【13 - 16】
Manual de usuario	【17 - 20】
Manuel de l'Utilisateur	【21 - 24】

steven@cycplus.com

Specification

Size:	170 × 51 × 56 mm
Weight:	395 g
Battery:	2000 mAh 7.4 V
Work Current:	1~6 A
Charging Mode:	Type-C
Charging Time:	2 hours
Max inflating pressure:	150 PSI / 10.3 bar
Operation Temperature:	0°C to 40°C
Storage Temperature:	-10°C to 60°C

About Inflation

Inflatable product	Reference pressure	Time from empty	Frequency from empty
Car(205 55R17)	33-36 PSI	8-12 min	1-2
Road Bike(700×23C)	100-120PSI	2-3 min	8-10
Mountain Bike(26×1.95)	30-50PSI	2-3 min	8-10
Motorcycle	30-50PSI	2-3 min	8-10
Basketball	7-9PSI	0.5-1 min	30-40


Preset Modes

Mode	Default Value	Pressure range	Save the last settings
 Bicycle	45 PSI	3~150 PSI	Yes
 Motorcycle	30 PSI	3~150 PSI	Yes
 Car	35 PSI	3~150 PSI	Yes
 Basketball	8 PSI	3~150 PSI	Yes



Indicate a proper target pressure for your inflatable. Incorrect pressure setting could result in personal or property damage, or negatively impact the device functionality.

Packing List & Details



Operation


- 01 **Connection:** Connect the metal end to the pump, and thread the other end onto the valve stem. For Presta valves, install the **Presta valve converter** first. For balls, install the **Ball needle** first.
- 02 **Start up:** Long press the **Power** button to turn on the power. The screen will display the current pressure.
- 03 **Choose mode:** Press the **Alter** button to switch between 4 modes of use: Bicycle, Motorcycle, Car, and the Basketball. The pump remembers your previous setting in each mode automatically.
- 04 **Set Target Pressure:** Long press **Alter** button to switch the units PSI and bar. Use **+** button and **-** button to adjust the preset air pressure value. The screen will flash twice when you stop setting, then it will display the current air pressure.
- 05 **Inflation:** Press **Power** Button to start inflating. Press again to pause/continue. It will stop automatically when the target pressure is reached.

Air Nozzle			
Valve Type	 Schrader Valve	 Presta Valve	 Ball

Battery & Charging

- 01 For the first time to use or a long time no use, please charge the inflator before using.
- 02 The battery level indicator  will flash during the charging, and the full indicator  will light up when the battery is fully charged.
- 03 Please charge the inflator once every two months even if not in use to avoid battery damage.

Attentions

- 01 It's normal that the inflator becomes hot after working more than 1min. Please don't touch the hot part of the air tube!  **HOT**
- 02 Please check the inflator before inflating. If find any exception, don't use it.
- 03 If find any abnormal sounds or excessive temperatures during the inflation, please stop it immediately.
- 04 Please ensure the smooth flow of air during the inflation.

- 05 The compressor in the inflator may produce electric sparks at work. Please keep it away from flammable and explosive objects.
- 06 Do not leave the working area in case of accidents.
- 07 After long-time using, both the inflator and the air tube will become hot. Allow it to cool prior to inflating again.
- 08 Please try to avoid silt invasion, soaking and bad fall.
- 09 Harsh chemicals, cleaning agents, detergents and other chemicals are forbidden to be used during the cleaning.
- 10 Don't store the inflator in a cold, hot or humid place.
- 11 Children are forbidden to use the inflator. Please keep it away from children.
- 12 Do not inflate the mouth, ears, eyes, etc. of people or animals.
- 13 Do not inflate while the pump is being charged.

Manufacturer Information

Company:

Chengdu Chendian Intelligent Technology Co., Ltd.

Address:

No. 88, Tianchen Road, Chengdu, Sichuan, China

Warranty:

Free repair or replacement within 2 years for non-user-induced damage.

Contact: steven@cycplus.com

To continuously improve product functionality and user experience, we may make adjustments to the design, features, or accessories of the product. The actual item you receive may differ from the description in this manual. Please refer to the physical product as the final reference. We reserve the right to modify products without prior notice. Thank you for your understanding and support!



FR

Cet appareil,
ses accessoires,
cordons et batteries
se recyclent

À DÉPOSER
EN MAGASIN



OU

À DÉPOSER
EN DÉCHÈTERIE



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

MADE IN CHINA