

Deerma Ηλεκτρικό Σκουπάκι CM800 Αφαίρεσης Σκόνης/Ακάρων (Λευκό)

DEERMA · EAN 6955578033124

Machine translation from Čeština. In case of doubt the manufacturer's original document prevails.

Deerma

Dust Mite Vacuum

CM800

This manual has been carefully checked; however, the manufacturer acknowledges the possibility of printing errors and factual inaccuracies. The manufacturer reserves the right to make changes to specifications, functionality, and color of the device. Changes may be made without prior notice. Dust Mite Vacuum

Ultraviolet cleaning technology for dust mites combined with high suction power will rid your bed of dust mites and ensure you a peaceful sleep. Product Design

1. Switch. 2. Window. 3. Air outlet. 4. Warm air outlet. 5. Brush. 6. Dust container. 7. Brush sensor. 8. UV lamp. 9. UV lamp. 10. Vibrating surface. Wiring Diagram

The diagram is for illustrative purposes only. Product Features

Highly efficient bactericidal UV lamp (253.7 nm), made of quartz glass. Cyclone cleaning system with an effective HEPA filter. Ergonomic handle for easy, effortless cleaning in various conditions. Power sensing function for safe use. High-frequency vibration function for more thorough cleaning of dust mites. Hot air drying function at a constant temperature effectively prevents the regeneration of bacteria. Safety Information

1. This product is intended for indoor use only on beds, sofas, blankets, etc., and should not be used as a substitute for a regular vacuum cleaner in an industrial environment.
2. Keep the product away from rain, water, or damp places (e.g., bathroom or laundry room) to prevent short circuits or electric shock.
3. Do not use the product in hazardous areas, such as gas stations, oil depots, chemical plants, or areas containing flammable and explosive materials.
4. Do not use the product to clean the interior of a copier or laser printer to avoid damaging it.
5. Do not leave the appliance near high-temperature areas, such as ovens or fireplaces, for extended periods to prevent deformation and damage to the casing.

6. Do not use the product to clean:

- hot objects, such as cigarette butts, matches, etc.;
- liquids, especially water, gasoline, paraffin, paints, alcohol, and cleaning agents;
- sharp elements, such as glass or iron filings;
- toxic substances, such as acids or corrosives.

7. It is strictly prohibited to expose any part of the human body, especially eyes, hands, and face, to direct UV lamp light.

8. The product has a patented design ensuring safety. Do not manufacture or modify the device yourself to avoid hazards.

9. Do not use the UV lamp for long periods in one place to prevent damage.

10. Do not place hands under the UV light to avoid skin burns.

11. Do not allow children or persons with limited mobility to use the device without supervision to prevent injury.

12. If the UV lamp does not function properly (does not light up or flickers), contact an authorized service center. Do not attempt to repair the product yourself.

13. The UV lamp operates only in a horizontal position. Technical Specifications

Product Name: Dust and Mite Vacuum

Model: CM800

Rated Voltage: 220-240V~ 50-60Hz

Rated Power: 450 W

Maximum Suction Power: >13 kPa.

Noise Level: <78 dB

Package Contents

Unit with power cord

Small brush

Certificate

User Manual

Power Supply

1. The rated voltage of the product is 230 V; never connect it to a power source with a different voltage.

2. If the power cord is damaged, it should be replaced with a new one to avoid hazards.

3. Do not plug or unplug the cord from the outlet with wet hands; it may cause electric shock.

4. If you will not be using the product for an extended period, turn it off and unplug the power cord. Using the Product

1. Connect the power cord to the power source.
2. Press the power on/off button. The main motor and the vibrating motor will turn on. Warm air will be blown out from the outlet at the bottom of the device. The appliance will then activate the hot drying function.

3. Hold the unit by the handle and gently push down on both front wheels. The sensor will activate the UV lamp, and the vibrating surface will start to work.

1. If you will not be using the device for an extended period, store it in a dry and cool place. Do not expose it to direct sunlight or moisture.

2. Do not crush the device with heavy objects.

3. If the device (especially the UV lamp) malfunctions, contact an authorized service center; never open or repair the device yourself.

Cleaning the Dust Container
Turn off the appliance, unplug the power cord, turn the appliance over, firmly press and hold the latches on both sides of the dust container to remove it. Open the container lid, empty the dust, and rinse it with water.

1. Remove the dust container.

2. Open the hopper cover.

3. Empty the contents of the container.

4. Remove the HEPA filter, dispose of it in the trash. Wash the tank and filter.

Daily Maintenance

- 1.

Maintenance should only be performed when the plug is disconnected from the power source. 2. To ensure effective cleaning and prolong the life of the motor, regularly clean the dust container and filter. If the dust container or filter is damaged, replace it. 3. Do not allow the UV lamp to be contaminated with dust or greasy stains. 4. The vacuum cleaner cover should not be cleaned with liquids such as water or oil to avoid damage. Wipe the device with a dry cloth or a cloth dampened with water, but do not allow water to enter the device.

Environmental Protection Electronic waste marked in accordance with European Union directives must not be disposed of with other municipal waste. It is subject to separate collection and recycling at designated locations. By ensuring its proper disposal, you will prevent possible negative consequences for the environment and human health. The collection system for used equipment complies with local environmental protection regulations for waste disposal. Detailed information on this topic can be obtained at the municipal office, at the processing plant, or at the store where the product was purchased. The product meets the requirements of the so-called new approach directives of the

European Union (EU) in the areas of safety, health, and the environment, which specify hazards that should be identified and eliminated. This document is a translation of the original user manual issued by the manufacturer. The product must be regularly maintained (cleaned) by the user or a specialized service center at the user's expense. If the user manual does not provide information on necessary periodic maintenance or service actions, the physical condition of the product should be evaluated regularly, at least once a week, against that of a physically new product. If any deviation is detected or found, maintenance (cleaning) or service measures must be carried out immediately. If proper maintenance (cleaning) is not performed and no action is taken in response to the identified condition of deviation, permanent damage to the product may occur. The guarantor is not responsible for damages caused by negligence. The device is equipped with a rechargeable battery, which ages over time and with use due to its physical and chemical structure. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal operating conditions for the device are present and the battery itself is new and fully charged. Actual operating time may differ from the time declared in the offer and this is not a defect of the device, but a characteristic of the product.