

Powerbank EcoFlow RAPID Pro X 27650 300W

ECOFLOW · EAN 4895251646673

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Powerbank EcoFlow RAPID Pro X

27650 300W

User Manual

General Safety Guidelines

Disclaimer: The product includes the necessary printed documentation required for configuration and basic operation. Detailed operating instructions, support materials, and the latest product information can be found at <https://www.ecoflow.com/support/download/>. Before using the product, please read the product documentation carefully. Improper use may cause serious injury, damage, or material loss. By using this product, you agree to all terms specified in the product documentation and accept them. EcoFlow is not responsible for any losses, damages, or injuries caused by improper use or non-compliance with the rules.

- Due to the energy conversion efficiency in the power bank, the actual capacity is lower than the nominal battery capacity.
- Use the product according to the operating instructions contained in this manual. Improper use may damage the product or pose a threat to persons and property.
- Check and ensure that the charging voltage of your digital device is compatible with the output voltage of the power bank.
- Choose and use the original charging cable for your digital device.
- Please regularly charge the power bank to extend its lifespan.
- **WARNING: Risk of fire and burns.** Do not open, crush, heat above 35°C (95°F), or incinerate.
- Do not use the power bank that has been submerged in water. For disposal, contact a battery recycling company.
- Keep the product away from water, fire, and heat sources.
- To reduce the risk of injury, strict supervision is necessary when using the product near children.
- If the product shows visible deformation, leakage, or damage, immediately cease its use and contact a recycling company for disposal.
- The product contains no user-serviceable parts, and the battery is not replaceable.
- Throwing the battery into fire or a heating furnace, as well as mechanically crushing or cutting the battery, may cause an explosion.
- Placing the battery in an environment with extremely high temperatures or low air pressure may cause an explosion or leakage of flammable liquids or gases.
- The product automatically enters standby mode when not in use.
- Do not expose the product to fire or excessive temperature. Contact with fire or temperatures above 100°C

may cause an explosion. • Do not expose the product to rain or snow. • Do not disassemble, repair, or modify this product yourself. For any repair services, please contact EcoFlow customer service. Model: EF-HB-140-X

Dimensions: 152 x 64.4 x 56.5 mm (6 × 2.5 × 2.2 inches) (without magnetic block)

Weight: 669 g (1.5 lbs) (without magnetic block)

Charging temperature: from 0°C to 35°C (32°F-95°F)

Discharging temperature: from -10°C to 35°C (14°F-95°F)

Storage temperature: from -20°C to 45°C (-4°F-113°F)

Altitude: ≤3000 m (9842.5 ft)

1.5s / / /

×1 OK

SIMPLIFIED EU DECLARATION OF CONFORMITY

EcoFlow Inc. hereby declares that the type of radio equipment [Powerbank EcoFlow RAPID Pro X 27650 300W] complies with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following web address: <https://files.innpro.pl/ecoflow>

Manufacturer's address:

RM 401, Plant #1, Runheng Industrial Zone, Fuyuan Road, Zhancheng Community, Fuhai Street, Bao'an District, Shenzhen City, Guangdong Province, China

Radio frequency: 2400-2483.5 MHz

Maximum radio frequency power: 20 dBm

Environmental Protection

Waste electrical and electronic equipment marked in accordance with European Union directives must not be placed together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The waste collection system complies with locally applicable environmental regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, cleaning facility, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning safety, health protection, and environmental protection, identifying hazards that should be detected and eliminated.

This document is a translation of the original user manual created by the manufacturer.

Detailed information about the distributor/manufacturer warranty conditions is available on the website <https://serwis.innpro.pl/gwarancja>

The product should be regularly maintained (cleaned) at the user's own expense or by specialized service points. In the absence of information about necessary periodic or service maintenance actions in the user manual, the user should regularly, at least once a week, assess the difference in the physical condition of the product from that of a physically new product. If any difference is detected or identified, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detecting a state of difference may lead to permanent damage to the product. The guarantor is not responsible for damages resulting from negligence.

Importer:

INNPRO Robert Błędowski sp. z o.o. Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

hurt@innpro.pl

www.innpro.pl

Responsible entity in the EU:

EcoFlow Europe s.r.o. Doubravice 110, 533 53 Pardubice,

Czech Republic

support.eu@ecoflow.com