

# EMEET SmartCam C950 Κάμερα web

Emeet · EAN 6971337720692

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

EMEET SmartCam

Short user manual

EMEET SmartCam

1. Connect to the computer. Configuration of the webcam

2. How to use EMEETLINK

To use EMEETLINK, you must first download the application from the website

[www.emeet.com/EMEETLINK](http://www.emeet.com/EMEETLINK). \* For Windows 7/8/10 and newer systems \* For Mac computers with system 10.14

and newer

3. Use EMEETLINK to fix image flickering. Click on the [Device] page. If you see flickering images, you can

switch between 50 Hz and 60 Hz, the two

popular power grid frequencies in different countries or regions, to try to fix the images. 50HZ 60HZ

Manufacturer data:

HONGKONG EMEET TRADING LIMITED

Web [www.emeet.com](http://www.emeet.com)

Tel +86 755 8672 4720

Address: Unit 03, 9/F, Austin Plaza, No. 83 Austin Road, Kowloon

Responsible person:

Company name: SUCCESS COURIER SL

Address: CALLE RIO TORMES NUM. 1, PLANTA

1, DERECHA, OFICINA 3, Fuenlabrada, Madrid, 28947 Spain

Email: [successservice2@hotmail.com](mailto:successservice2@hotmail.com)

Warnings and safety information

All information regarding product use can be found in the user manual. Before you start using it, familiarize yourself with its content and follow the instructions contained therein.

Also, review the following information before use:

## Usage warnings

### Risk of camera damage:

- Use the camera according to its intended purpose and the user manual.
- Avoid using the product in extreme conditions, such as excessive moisture, high temperatures, or severe frost, to prevent permanent damage.
- Mount the device only on stable surfaces or in appropriate mounts to avoid falling.
- Avoid cleaning the lens and screen with sharp or chemical agents that may damage the protective coatings.
- If the camera is waterproof, use it only within the depth and conditions specified by the manufacturer. Exceeding these limits may cause damage to the device. Before each use in water, ensure that all seals are properly installed and show no signs of damage or wear.
- When mounting the camera on vehicles, clothing, or other surfaces, ensure it is securely attached to avoid falling or losing it.

### Risk to children:

- Cameras and accessories, such as batteries, cables, or memory cards, are not intended for use by children.
- Store the device in a place inaccessible to children to prevent accidental damage to the equipment or swallowing of small parts.

### Risk of overheating:

- During intensive use of the camera, monitor its temperature – in case of overheating, turn off the device and allow it to cool down.
- Do not leave the camera in places exposed to direct sunlight.

### Risk of electric shock:

- If the camera requires wired power, ensure that the power source is compatible with its technical specifications.
- Never handle the device's cables or ports with wet hands.

### Data protection:

- If the camera offers wireless connectivity, use only official manufacturer applications downloaded from trusted sources.
- Regularly update the camera's software to protect it from potential threats.
- Secure access to the camera and application with a strong password and enable two-factor authentication if available.

### Access management:

- Control the list of paired devices and remove those that should not have access to the camera.
- Limit the ability to pair devices only to users you trust.

### Information on proper usage

Connecting and configuring:

- Before first use, configure the camera according to the user manual, ensuring that all settings are adjusted to the planned usage conditions.
- If you plan to connect additional accessories, such as microphones, lighting, or gimbals, ensure they are compatible with the camera model.

Storage and transport:

- Store the camera in an appropriate bag or protective case to secure it against mechanical damage, dirt, and moisture.
- Transport the camera in appropriately secured luggage to prevent it from moving during transport.

Additional precautions

Service and maintenance:

- Regularly clean the lens and other camera elements with a soft cloth or dedicated cleaning agents for photographic equipment.
- If the device stops functioning properly, contact an authorized manufacturer service – do not attempt to repair the camera yourself.

Safe disposal:

- Used accessories, such as batteries or damaged camera components, should be disposed of according to local regulations regarding electronic waste.
- Do not throw the camera in municipal waste – contact your local electrical equipment collection point.

If you need additional information regarding the product, please contact the customer service department (email: [hurt@innpro.pl](mailto:hurt@innpro.pl), website: <https://innpro.pl/>) or another specialist.

Environmental Protection

Used electronic equipment marked in accordance with the European Union directive must not be placed together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The system for collecting used equipment complies with locally applicable environmental protection regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, cleaning plant, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning issues related to user safety, health protection, and environmental protection, which define hazards that should be detected and eliminated. This document is a translation of the original user manual created by the manufacturer. Detailed information about the distributor/manufacturer warranty conditions is available on the website

<https://serwis.innpro.pl/gwarancja>.

The product should be regularly maintained (cleaned) by the user or by specialized service points at the user's cost and scope. In the absence of information about necessary periodic maintenance or service actions in the user manual, the user should regularly, at least once a week, assess the difference in the physical condition of the product from that of a physically new product. If any difference is detected or noted, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detecting a difference may lead to permanent damage to the product. The guarantor is not responsible for damages resulting from neglect.

Importer: INNPRO Robert Błędowski sp. z o.o. ul. Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

[hurt@innpro.pl](mailto:hurt@innpro.pl)

[www.innpro.pl](http://www.innpro.pl)