

EMEET SmartCam S800 Κάμερα web

Emeet · EAN 6971337724041

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Manufacturer's data:

How to connect a webcam to a computer HONGKONG EMEET TRADING LIMITED

How to install the webcam Connect one end of the USB port to the webcam, and the other

Web1www.emeet.com

end to the computer. Tel1+86 755 8672 4720

1J Install the camera on the monitor/laptop Address: Unit 03, 9/F, Austin Plaza, No. 83 Austin Road, Kowloon

Install the webcam on the monitor *It is recommended to connect to the computer's USB 3.0 port. Responsible person:

EMEET SmartCam S800 or laptop in the chosen location and at Company name: SUCCESS COURIER SL

the selected angle, ensuring that it is Address: CALLE RIO TORMES NUM. 1, PLANTA well secured and stable. 1, DERECHA, OFICINA 3, Fuenlabrada, Madrid, 28947 Spain Email: successservice2@hotmail.com

2J Install the camera on a tripod

Install the webcam on a tripod, using the 1/4" thread located at its base. EMEETLINK

*Tripods are sold separately. Image settings and firmware updates are available in the EMEETLINK app, which can be downloaded from www.emeet.com/EMEETLINK. How to use the privacy cover

To close the cover: Press the protrusion above the lens and turn Adjust resolution the switch to close the cover. Open the software (such as OBS or Windows Camera), select EMEET, click [Settings] - [Resolution], select the required resolution (e.g., 2160P or 1080P), and then record a video or start a live stream. *More information can be found at <https://emeet.com/pages/web-cam-downloads>

Copyright © Shenzhen EMEET Technology Co.,Ltd. The latest version of the information

contained in this manual is available at www.emeet.com. Warnings and safety information

Wireless connectivity Environmental protection

All information regarding product usage can be found in the user Data protection: Waste electrical and electronic equipment marked in accordance with European Union directives must not be

manual. Before you start using it, familiarize yourself with its content and follow ●If the camera offers wireless connectivity, use only the disposed of together with other municipal waste. It is subject to selective collection and the instructions contained within. official manufacturer applications downloaded from trusted sources. recycling at designated points. By ensuring its proper disposal, you prevent Also, familiarize yourself with the following information before use: ●Regularly update the camera's software to protect it from potential potential negative consequences for the natural environment and human health. Usage warnings threats. The collection system for used equipment complies with locally applicable waste disposal regulations. Detailed information on this can

be obtained from the municipal office, waste management facility, or store where the product was purchased.

●Use the camera according to its intended purpose and the user manual. Secure access to the camera and applications with a strong password and enable two-factor authentication if available.

●Avoid using the product in extreme conditions, such as excessive humidity, high temperatures, or severe frost, to prevent permanent damage. ●Monitor the list of paired devices and remove those that should not have access to the camera. ●Install the device only on stable surfaces or in appropriate mounts to avoid falling. ●Limit the ability to pair devices only to users you trust. This document is a translation of the original user manual created by the manufacturer. Information regarding proper usage. Connecting and configuration: Detailed information on the distributor/manufacturer warranty conditions is available at the website <https://serwis.innpro.pl/gwarancja>. ●Before first use, configure the camera according to the user manual, ensuring that all settings are adjusted to the planned usage conditions. The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. In the absence of information on necessary maintenance or service actions in the user manual, the condition of the product should be assessed regularly, at least once a week, for any deviations from

the condition of a physically new product. In case of detection or identification of any deviation, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detection of a deviation may lead to permanent damage to the product. The warranty does not cover damages resulting from neglect. ●If the camera is waterproof, use it only within the depth and conditions specified by the manufacturer. Exceeding these limits may cause damage to the device. Before each use in water, ensure that all seals are properly installed and show no signs of damage or wear.

●When mounting the camera on vehicles, clothing, or other surfaces, ensure that it is securely attached to avoid falling or losing it. Storage and transport: ●Store the camera in an appropriate bag or protective case to protect it from mechanical damage, contamination, and moisture. ●Transport the camera in appropriately secured luggage to prevent it from moving during transport. Hazard to children: ●Cameras and accessories, such as batteries, cables, or memory cards, are not intended for use by children. ●Keep the device in a location inaccessible to children to prevent accidental damage to the equipment or swallowing of small parts. Additional precautions: ●Regularly clean the lens and other camera elements with a soft cloth. Risk of overheating:

●During intensive use of the camera, monitor its temperature – in case of overheating, turn off the device and allow it to cool down. ●If the device stops functioning properly, contact an authorized service center – do not attempt to repair the camera yourself. Importer: INNPRO Robert Błędowski sp. z o.o. ●Do not leave the camera in places exposed to direct sunlight. Safe disposal: ●Used accessories, such as batteries or damaged camera components, should be disposed of in accordance with local electronic waste regulations. ●If the camera requires wired power, ensure that the power source complies with its technical specifications. ●Never handle the device's cables or ports with wet hands. If you need additional product information, contact customer service (email: hurt@innpro.pl, website: <https://innpro.pl/>) or another specialist.