

fifine

H18

USER'S GUIDE



B2B Version: 25-09

CONTENTS

What's in the Box	1
Product Description	2
Guidelines For Use	3-4
Computer Set Up(Windows & MAC OS)	4-11
Important Notice	11-12
Specifications	12

WHAT'S IN THE BOX


- 1 x Headset with Detachable Microphone
- 1 x User's Manual

All pictures of the product, accessories and UI involved in this document are for reference only. The actual product may differ due to updates.



1

PRODUCT DESCRIPTION



The H18 is an open-back monitoring headphone featuring an all-new exterior design with a professional dual external headband structure. Equipped with a 3.5mm audio jack, it ensures unimpeded and stable audio signal transmission.

- ① Headband - With soft and comfortable materials.
- ② Earpads-With cozy ear pads.
- ③ 3.5mm interface - Used to connect with your computer, phone, mixer and the USB in-line control (Not included).
- ④ Detachable Omni - Directional Microphone-Gooseneck design can be adjusted and detached.


2

GUIDELINES FOR USE

► Detach/Install the Microphone

Unplug the microphone outward to separate it from the headset. Insert the microphone completely into the jack to combine it with the headset.


Tips: Make sure to plug your microphone into the microphone jack slot fully.



3

► 3.5mm jack Connection


3.5mm interface can be plugged to the sound card or the computer to hear the output voice.



► The Use of Microphone

The gooseneck microphone with omni-directional pickup pattern can be adjusted the speaking distance and angle at will.

Tips: It is suggested that put the mic slightly below the mouth, and preferably 0.8-1.2 inches from it. Adjust the position of the mic, 30 to 45 degree angle off axis to your mouth, to avoid picking up your popping sounds that much.




COMPUTER SET UP

► Windows


4

1. Headset Settings

- 1) Connect the headphones into the correct 3.5mm port on your PC/Laptop. Make sure to plug it fully into the port, and none of the headphones are disabled, muted or something.
- 2) Right click the speaker icon at the bottom right of the screen. Click "Open Sounds Settings".



- 3) Click the Sound Control Panel.




5

- 4) Click the Playback tab, and choose "Headphones" as the default device. When you playback audio, bar-type icon will turn green and bounce.


Tips: If it remains unchanged, please try the following ways to solve.

- a. reset computer and replug them.
- b. eadphones in the available ports of the computer.
- c. check if the audio volume is on.
- c. check if the detachable cable is fully connected to headphones and computer.




- 5) Adjust headphones volume. Double click the "Headphones" to open the Speaker Properties window and click the "Level" tab. Drag the process bar to adjust the headphones level.

6




Tips: If you don't want to monitor your own voice, you can follow below steps. Go to Sound Control Panel - "Playback" tab - select "Headphones" - Properties - "Level" tab - disable the microphone volume.




2. Microphone Settings

- 1) Right click the speaker icon at the bottom right of the screen. Click "Open Sound Settings".

7



- 2) Click the Sound Control Panel.




- 3) Click the Recording tab, and choose "Microphone" as the default device. When you speak into mic, bar-type icon will turn green and bounce.


Tips: If it remains unchanged, you can try the following three ways to solve.

- a. Reset computer and replug the headset in the available ports of the computer.
- b. Check whether the mic is fully inserted into the headset.

8




- 4) Adjust microphone volume. Double click the "Microphone" to open the Microphone Properties window and click the "Level" tab. Drag the process bar to adjust the mic level.



► Apple MAC OS

1. Headset Settings


- 1) Connect the headphones into the correct 3.5mm port on your Mac. Make sure to plug it fully into the port, and none of the headphones are disabled, muted or something.
- 2) Go to System Preferences.



- 3) Click Sound to display the Sound preference pane.



- 4) Click the Output tab and make certain "Headphones" is selected as the default output device. Drag progress bar to adjust headset volume.



10

- 5) If there is no sound from the headphones, please try the following ways to solve.
 - a. Reset computer and replug the headset in the available USB ports of the computer.
 - b. Check whether the mic is fully inserted into the headset.
 - c. Make sure that switch the unmute option on the in-line control.

► Headphone Jack Usage Instructions:

For the H18, the headphone jack must be connected to the port labeled "4G" to enable both audio output (headphone) and microphone input functionality. If connected to other ports, only audio output will work, and the microphone input will not function.

Note: To ensure full headphone + microphone support, always use the designated "4G" port.

IMPORTANT NOTICE

On Headset Use

- To avoid high volume harming your ears, please turn down the audio volume before you start to listen by the headset. And then adjust the appropriate volume levels you need.
- Please wear the headset correctly according to the "L" and "R" on the headset. Wear the "L" side on the left ear, and wear the "R" side on the right ear.
- Please enjoy music at a moderate volume to prevent adverse effects on the hearing.
- Do not listen for a long time at high volume to avoid hearing damage.
- There is a tendency to raise the volume when using in noisy places. However, for reasons of safety, it is advised to keep the volume at a level whereby you can still hear sounds around you.
- When the volume is too high, the sound may leak outside the headset. Be careful not to raise the volume so high that it bothers people around you.

11

On Safety

- Do not drop, hit or otherwise expose headset to strong shock of any kind, which may damage the product.
- Do not attempt to disassemble the headset without authorization, which may affect the product use.
- Do not submerge in liquid or water.
- Do not use any corrosive cleaner or oil to clean the product. You can clean it by dry cloth.

On Placement

- You can place the headset flat on a desk or place on a headset stand. Do not place the headset in the following locations.
- Location exposed to direct sunlight, near a heater, or other extremely high-temperature location.
 - Dusty location.
 - On an unsteady or inclined surface.
 - Location exposed to large amounts of vibration.
 - Bathroom or other high-humidity locations.

SPECIFICATIONS

Model Number	H18
Product Category	Over-Ear Headphones
Headset Type	Wired Headset
Primary Usage	Entertainment/Music
Speaker Unit	Dynamic Driver
Headphone Frequency Response	20Hz - 20kHz
Driver Unit Size	53mm
Compatibility	PC, MAC, PS

CONTACT US

Get Social: [Facebook](#)
Facebook page: <http://bit.ly/FifinePage>

Contact Info: [Email](#)
E-mail: web@fifine.cc
More product inquiries can be found on the website.
Company Website: <https://fifinemicrophone.com>

WARRANTY

Fifine warrants its hardware products against defects in materials and workmanship for a period of one year from the date of the original retail purchase, provided the purchase was made from an authorized Fifine dealer. This warranty is void if the equipment is altered, misused, mishandled, subjected to excessive wear, or serviced by any parties not authorized by Fifine. For warranty service, please contact your local distributor or email web@fifine.cc.