

Φουσκωτό στρώμα Flextail Tiny Sleeping Pad R05 AVS Mummy (Πορτοκαλί)

Flextail · EAN 6975755966663

Machine translation from Magyar. In case of doubt the manufacturer's original document prevails.

Inflatable Mattress

Flextail Tiny Sleeping Mattress

R05 AVS Mummy

TMR5RIN01

PRODUCT DESCRIPTION

Sleeping Two-level AVS Valve AVS Capsule

Mattress Valve

Deflation Port

Inflation Indicator

Switch Inflation Port

Display Usage

Inflation Indicator

0%-99%

100%

USER MANUAL

Inflation Mode

Open the AVS valve Insert the AVS capsule

Turn on the switch to start After inflation

usage Close the lid

Deflation Mode

Remove the capsule, switch the Turn it over, insert the AVS capsule
switch

Open the auxiliary valve for

Faster deflation

Storage

Fold and roll up (

Before rolling up, ensure

that all air has been released)

Place in the storage bag

User Guide

Before use, remove all sharp objects (branches, stones, glass debris, etc.)

PARAMETERS

Name Small R05 AVS Mattress, standard

Model TMR5R

Weight 733g/25.86oz $\pm 7\%$

Dimensions when inflated 183*65*7 cm / 72*25.6*2.8 in

Dimensions when folded $\phi 13.5 \times 28$ cm / $\phi 5.3 \times 11$ in

Surface Material 100% nylon

Inner Material 100% nylon

Other PET aluminum foil

Name BUILT-IN PUMP FROM MOVE

Model BPZM700

Weight 33 g (1.16 oz)

Pressure 3kPa(0.44psi)

Flow Rate 100L/min(26.42gal/min)

Input 5V 0.8A

9.5 W

Rated Power

Duration 16 minutes

Rated Capacity 2.59 Wh(3.7V,700mAh)

BUILT-IN MOVE PUMP, Type-C charging

Package Contents

cable, user manual

WARNING

· Before cleaning the sleeping mattress, ensure that the air valve is tightly closed to prevent water or moisture from entering the mattress. It is not washable with water. Wipe with a clean towel dipped in water and thoroughly wrung out, then place in a cool, dry place to dry. · Do not expose to sunlight. · To extend the lifespan, do not inflate the mattress directly with your mouth; it is recommended to use a professional air pump for inflation. · Before use, remove sharp objects from the ground, and it is recommended to use a moisture-resistant mat. · Keep away from fire during use; · Children may only use the

mattress under adult supervision. TROUBLESHOOTING

- Connect the charger to check the battery charge level.
- Check for any water or other liquid on the surface of the pump.
- Check if the fan blades are clogged or obstructed by foreign objects.
- Press the switch multiple times to check if the product starts.
- For questions, contact your FLEXTAIL dealer or email support@flectail.com.

WARRANTY CONDITIONS

- FLEXTAIL offers a two-year warranty on materials and manufacturing defects for customers who purchase the product from an official dealer, starting from the date of purchase. The warranty period for the product is two years.
- If the customer detects a hidden product defect, please return the product to the place of purchase. If the product cannot be returned to the seller, please send it back to our specified address. The product will be repaired or replaced according to the warranty conditions. During the warranty period, we will fulfill our obligations in accordance with the warranty conditions. After the warranty period expires, service is not available. We reserve the right to request proof of warranty claim.

PRODUCT SAFETY WARNING

- Our warranty does not cover problems arising from normal wear and tear, modifications or alterations to the product, failure to follow instructions, improper maintenance, accidental damage, misuse, improper use, intentional damage, or use contrary to its intended purpose. This warranty provides you with specific legal rights, and you may also have other rights that vary from place to place of purchase. This warranty expressly replaces all other warranties, whether express or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose (if the area of sale prohibits the exclusion or limitation of liability for incidental or consequential damages, or the limitation of implied warranties, the above exclusions or limitations may not apply to the particular user).
- Both FLEXTAIL and FLEXTAILGEAR are registered trademarks of our company.

A FLEXTAIL and FLEXTAILGEAR are registered trademarks used for various manufacturing batches. Both trademarks do not affect the use of the product. This document is a translation of the original user manual prepared by the manufacturer. The product must be regularly maintained (cleaned) by the user, or at the user's expense and cost at a professional service. If there is no information in the user manual regarding the necessary cyclical maintenance or servicing operations, the physical condition of the product must be evaluated regularly, at least once a week, for deviations from the condition of a physically new product. If any deviations are detected or found, maintenance (cleaning) or service actions must be taken urgently. Failure to properly maintain (clean) and respond to the detection of differing conditions may result in permanent damage to the product. The

warranty provider is not responsible for damages resulting from negligence. All information regarding handling and use can be found in the user manual or on the product label. Before using the product, read the content and follow the instructions contained therein. Also, read the following information before use: Warnings and safety information

Electrical safety:

Power supply: Electric-powered products (e.g., fans, pumps, lighting) should only be used with an appropriate power source, in accordance with the manufacturer's instructions. To avoid damage to the device or the risk of electric shock, ensure that the device is connected to the appropriate voltage network.

Use in wet conditions: Electric devices intended for outdoor use must be protected from water and moisture to avoid the risk of electric shock. Do not use electric devices in the rain or near water sources unless they are clearly marked as waterproof.

- **Power supply:** Electric-powered products (e.g., fans, pumps, lighting) should only be used with an appropriate power source, in accordance with the manufacturer's instructions. To avoid damage to the device or the risk of electric shock, ensure that the device is connected to the appropriate voltage network.
- **Use in wet conditions:** Electric devices intended for outdoor use must be protected from water and moisture to avoid the risk of electric shock. Do not use electric devices in the rain or near water sources unless they are clearly marked as waterproof.

Material warnings:

Sharp points and cuts: Products such as knives, multi-tools, or kitchen accessories should be kept out of reach of children. Extra care must be taken to avoid cuts and injuries.

Flammable materials: Some camping products, such as sprays, repellents, or battery-operated accessories, may contain flammable materials. Keep them away from open flames, heat, and sources of sparks.

- **Sharp points and cuts:** Products such as knives, multi-tools, or kitchen accessories should be kept out of reach of children. Extra care must be taken to avoid cuts and injuries.
- **Flammable materials:** Some camping products, such as sprays, repellents, or battery-operated accessories, may contain flammable materials. Keep them away from open flames, heat, and sources of sparks.

User instructions:

Overloading: Products such as inflatable mattresses, sun loungers, and tents must be used according to the maximum load limits specified by the manufacturer. To avoid damage to the products and the risk of injury, do not exceed these limits.

Inflation recommendations: Inflatable products, such as mattresses, beds, or sun loungers, should not be over-inflated. To avoid breakage, pressure recommendations must be followed.

- **Overloading:** Products such as inflatable mattresses, sun loungers, and tents must be used according to the maximum load limits specified by the manufacturer. To avoid damage to the products and the risk of injury, do not exceed these limits.
- **Inflation recommendations:** Inflatable products, such as mattresses, beds, or sun loungers, should not be over-inflated. To avoid breakage, pressure recommendations must

be followed. Safe storage: Protection from damage: Camping products should be stored in a dry, cool place, away from sharp objects that could damage their material.

Avoid contact with chemicals that may affect their integrity. Keep out of reach of children: Products that may pose a danger to children, such as multi-tools, sharp instruments, or accessories containing small parts, should be stored in a safe place. • Protection from injuries: Camping products should be stored in a dry, cool place, away from sharp objects that may damage their material. Avoid contact with chemicals that may affect their integrity. • Keep out of reach of children: Products that may pose a danger to children, such as multi-tools, sharp instruments, or accessories containing small parts, should be stored in a safe place. Fire hazard warnings: Explosion hazard: Products containing lithium-ion batteries (e.g., portable coolers, flashlights, or pumps) must be used according to the charging and storage instructions. Avoid overheating the batteries, which can lead to explosion or fire hazards. Overheating warning: To avoid overheating and potential ignition, do not use electrical or battery-operated products near heat sources, and do not leave them in closed, hot rooms. • Explosion hazard: Products containing lithium-ion batteries (e.g., portable coolers, flashlights, or pumps) must be used according to the charging and storage instructions. Avoid overheating the batteries, which can lead to explosion or fire hazards. • Overheating warning: To avoid overheating and potential ignition, do not use electrical or battery-operated products near heat sources, and do not leave them in closed, hot rooms. Warnings regarding rest and health: Improper use of sunbeds and mattresses: Ensure that sunbeds and mattresses are used for their intended purpose (for resting). These products should not be used for activities that may lead to their damage (e.g., jumping, overloading). Hygiene care: Products such as mattresses, sunbeds, and tents should be regularly cleaned to prevent the accumulation of dirt, bacteria, and mold. Use appropriate cleaning agents according to the manufacturer's instructions. • Improper use of sunbeds and mattresses: Ensure that sunbeds and mattresses are used for their intended purpose (for resting). These products should not be used for activities that may lead to their damage (e.g., jumping, overloading). • Hygiene care: Products such as mattresses, sunbeds, and tents should be regularly cleaned to prevent the accumulation of dirt, bacteria, and mold. Use appropriate cleaning agents according to the manufacturer's instructions. Safety precautions Before charging, check that the device's contacts are clean. Never leave the device unattended during use and charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high temperatures. Charge the device in a dry and well-ventilated area, keeping at least 1 meter away from other objects. Never

cover the device while charging. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and approval. Take care of your property; the device is equipped with hard-to-extinguish cells, so equip it with a fire blanket. For LI-ION batteries The device is equipped with a LI ION (lithium-ion) rechargeable battery, which ages over time and with use due to its final and chemical composition. The manufacturer specifies the maximum operating time under laboratory conditions, where optimal operating conditions for the device are present, and the battery itself is new and fully charged. In reality, the operating time may differ from what is stated in the offer, and this is not a fault of the device but a characteristic of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge the battery below 3.18 V or below 15% of its full capacity. Lower values, such as 2.5V on a cell, can permanently damage it, and this is not covered by the warranty. If you do not use the battery or the entire device for more than a month, charge the battery to 50% and check its charge level regularly every two months. Store the battery and the device in a dry place protected from sunlight and negative temperatures.

LIPO batteries

The device is equipped with a LI PO (lithium-polymer) battery, which ages over time and with use due to its physical and chemical structure. The manufacturer specifies the maximum operating time under laboratory conditions, where optimal operating conditions for the device are present, and the battery itself is new and fully charged. The actual operating time may differ from what is stated in the offer, and this is not a fault of the device, but a characteristic of the product. To preserve the maximum lifespan of the battery, it is not recommended to discharge the battery below 3.5 V or 5% of its total capacity. Lower values, such as 3.2V on a cell, will cause permanent damage, and this is not covered by the warranty. If you do not use the battery or the entire device for more than a month, charge the battery to 50% and regularly check its charge level every two months. Store the battery and the device in a dry place protected from sunlight and negative temperatures.

Environmental protection

In accordance with the European Union directive, labeled electronic waste must not be disposed of with other municipal waste. Waste must be collected separately and recycled at designated points. Proper disposal can prevent potential negative consequences for the environment and human health. The collection system for used equipment complies with local environmental regulations regarding waste disposal. Detailed information on this topic can be obtained from the local municipality, the waste management facility, or the store

where the product was purchased. The product complies with the European Union (EU) so-called new approach directives regarding safety, health, and environmental issues, which define the hazards to be identified and eliminated.

Importer:

INNPRO Robert Błędowski sp. z o.o. Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

hurt@innpro.pl

www.innpro.pl

Manufacturer:

Changzhou Flextail Technology Co., Ltd. North Huashan 18 213022 Changzhou City, China

support@flextail.com

EU representative:

SUOCESS COURIER SL

CALLE RIO TORMES 1

28947 Madrid, Spain

Battery data:

Type: lithium-polymer battery

Net weight: 0.0148 kg

Capacity: 1500 mAh

Exceeding the permissible cadmium (0.002%) or lead (0.004%) content: no

Battery serial number: BAT-K7X2M

successservice2@hotmail.com

Warranty ticket

Name and address of the importer: INNPRO Robert Błędowski,

ul. Rudzka 65c, 44-200 Rybnik, Poland

Name and address of the seller (distributor, liable for statutory warranty):

Date of purchase (contract conclusion) and transfer to the consumer:

Invoice number/Package number:

Product data:

Type:

Name:

Identification number:

Warranty length:

DEAR CUSTOMER

Thank you for choosing a product distributed by INNPRO. We hope you will find our product useful in the future. It is unlikely that the product will require repair during use, but if it does, you can contact the seller (distributor) directly for assistance. To avoid inconveniences, please read the user manual carefully before contacting the distributor. WARRANTY CONDITIONS

Regarding the Products, the owner of the product can assert warranty claims according to the warranty conditions recorded here, provided that they qualify as a consumer ("a natural person acting outside their profession, independent occupation, or business activity").

Warranty claims can be asserted at any time during the warranty period against the seller (distributor) by presenting the original Warranty Ticket. EXCLUSIONS AND LIMITATIONS

The importer does not warrant the quality, performance, accuracy, reliability, or suitability of the software that is part of the product or any accessory. The seller (distributor) is exempt from warranty obligations if the seller (distributor) or the service authorized to perform warranty repairs proves that the cause of the defect arose after delivery. The warranty does not cover the following cases:

- a. Physical damage, fire damage, or water damage not resulting from manufacturing defects, including user errors;
- b. Damage resulting from improper use, unauthorized disassembly, or tampering with the product that does not comply with the user manual;
- c. Water damage resulting from improper preparation, use, or use not in accordance with the user manual;
- d. Unauthorized modifications to the circuit, damage resulting from improper battery use;
- e.

Injury resulting from use in bad weather conditions (e.g.: storm, sandstorm, rain, etc.); f.

Injury resulting from operation in a strong electromagnetic field; g. Injury resulting from

operation in other high interference environments; h. Injury resulting from low battery

voltage or the use of a faulty battery; i. In the case of products whose identifier is counterfeit or destroyed; j. Products that do not have sales documentation, or the sales documentation

cannot be identified as belonging to that product, or the sales documentation is counterfeit;

k. In the case of injury resulting from improper storage, transportation, or dropping; l. In the case of damage; m. In the case of malfunction caused by reasons arising after purchase; n.

Failure to perform regular inspections and maintenance as prescribed by the manufacturer;

o. Any intervention or repair that causes the defect or its cause, which is not performed by the official service indicated on this warranty certificate. LEGAL WARRANTY The legal

warranty applies to products purchased in Hungary under a consumer contract, marketed by the distributor, according to Government Decree 151/2003. (IX. 22.), with a duration calculated from the date of delivery of the product or the date of commissioning by the seller or the seller's agent as follows: • For a selling price reaching 10,000 forints but not exceeding 250,000 forints, two (2) years, • For a selling price above 250,000 forints, three (3) years. The expiration of these deadlines results in the loss of rights. The legal warranty is the responsibility of the seller (distributor) who sells the product directly to you. According to Section 4 (2) of Government Decree 151/2003. (IX. 22.), the irregular issuance of the warranty certificate or the failure to provide the warranty certificate to the consumer does not affect the validity of the warranty. The fulfillment of claims based on an irregularly issued warranty certificate is the responsibility of the seller (distributor). The enforcement of rights arising from the legal warranty does not require the return of the product's opened packaging by the consumer. The provisions of this Warranty Certificate do not affect the rights of the consumer arising from the law.

RIGHTS ENFORCEABLE UNDER LEGAL WARRANTY

In the event of a malfunction within the warranty period, the consumer may choose: a) to demand repair or replacement, except if the fulfillment of the chosen warranty claim is impossible, or if it would result in an unreasonable additional cost to the distributor compared to the fulfillment of the other warranty claim, taking into account the value of the product in flawless condition, the severity of the breach of contract, and the damage caused to the entitled party by fulfilling the warranty rights; b) to demand a proportional price reduction, or - if the distributor has not undertaken the repair or replacement, cannot fulfill this obligation within the appropriate deadline, or if the entitled party's interest in repair or replacement has ceased - may withdraw from the contract. Withdrawal is not applicable for insignificant defects. The distributor - unless the consumer provides otherwise - is obliged to replace the product within eight (8) days if a) it is established during the first repair of the product within the duration of the legal warranty that the product is not repairable, or b) the product malfunctions again after three (3) repairs; or c) the product is not repaired within thirty (30) days from the communication of the repair request to the seller, counting from the expiration of the thirty-day deadline. If replacement of the product is not possible as stated above, the seller (distributor) will refund the purchase price indicated on the receipt presented by the consumer within eight (8) days. The repair or replacement must be carried out within an appropriate timeframe, taking into account the product's characteristics and the intended use expected by the entitled party, while safeguarding the consumer's interests. The party obliged to provide the warranty must strive to ensure that the repair or replacement occurs within a maximum of 15 days. The consumer must report the warranty

claim directly to the seller (distributor) immediately after noticing the malfunction. If the consumer asserts a replacement claim within three working days from the purchase (commissioning) due to the product's malfunction, the seller (distributor) cannot invoke unreasonable additional costs but is obliged to replace the consumer product, provided that the malfunction hinders its intended use.

Within the warranty period, warranty repair work may only be carried out by the designated service center, based on the valid Warranty Certificate. For any repairs under warranty, please check the proper completion of the repair vouchers. During the repair, only new parts may be installed in the product. If the designated workshop does not carry out the repair, or if they refuse to undertake the repair, the consumer may have the product repaired elsewhere at the expense of the warranty obligor. To reimburse the costs of the repair, it is necessary to provide appropriate documentation with a receipt. The warranty claim for the part affected by the replacement or repair restarts. **COMMON WARRANTY RULES** If the product malfunctions within the warranty period (calculated from the date of the first purchase as new) due to manufacturing defects or the use of improper materials during manufacturing, the official service of the importer will repair it free of charge within the Warranty area, or replace the product or defective part, provided that the conditions and limitations stated in this Warranty Certificate are met and the Contractual warranty is valid. Ownership of every replaced product or part transfers to the entity performing the replacement. Warranty is only valid within the warranty period, upon the transfer of the defective product, and upon the presentation of the original document proving the purchase, which must include the purchase date, model type, and the name of the selling distributor, in a readable and undamaged condition (warranty certificate, or in its absence, invoice or receipt). Otherwise, the official service of the importer may refuse the free warranty service. The warranty is not valid for products where the type or serial number has been altered, deleted, removed, or made illegible. Please carefully check the proper completion of the warranty certificate at the time of purchase, and keep the Warranty Certificate safe. A lost Warranty Certificate can only be replaced with credible proof of the sale date (e.g., an invoice with date and stamp, presentation of a sales record). Any corrections, deletions, rewrites, or false entries on the Warranty Certificate will render the Warranty Certificate invalid. To avoid the loss or malfunction of removable data storage devices from the product, please remove them from the product before submitting it for repair. The warranty does not cover shipping costs and risks related to the transportation of the defective product to the importer or the official service of the importer by a carrier not designated by the importer.

The Manufacturer may also provide additional supplementary warranty for the product specified on this warranty certificate, the conditions of which - depending on the product - are included in the User Manual attached to the purchased product and/or on the Manufacturer's official website. The Consumer may report warranty claims related to the products beyond the mandatory warranty period defined by law at the representative points designated by the Manufacturer. In case of legal disputes, the Consumer may also initiate proceedings with the conciliation board operating alongside the county (capital city) chambers of commerce and industry. REPAIRS/REPLACEMENTS UNDER WARRANTY: Date of notification: Date of return:

Malfunction: New warranty deadline:

New identification number: Work order number:

(Ph) Performed repair/replacement:

Date of notification: Date of return:

Malfunction: New warranty deadline:

New identification number: Work order number:

(Ph) Performed repair/replacement:

Date of notification: Date of return:

Malfunction: New warranty deadline:

New identification number: Work order number:

(Ph) Performed repair/replacement:

The seller (warranty obligor under law)

Signature of the buyer

Seal impression and signature of the person acting during the issuance of the Warranty Certificate