




**FLEXTAIL™**



# **The Guide Of EVO SUP PUMP PRO**

— ESPP8000IN02 —

# PRODUCT INTRODUCTION



For swim rings/inflatable toys



For inflatable beds / boats



For SUP/ Surf Kite/Surf Wing/inflatable tent



3.28ft Long Hose




Schrader valve inflator needle



12V DC Car Connector




Manual



Storage Bag




Charging Cable




For Car & Motorcycle Tires

# DISPLAY INSTRUCTIONS

## Display




## Charging Indicator



## 12V DC Car Connector




## Anti-misoperation switch & Charging Port




- Toggle the "Anti-touch switch" to start the product & turn off the power.
- Press "Unit/Mode" once to select "SUP, KITE, MAT".
- Press and hold "Unit/Mode" to select "PSI, BAR".
- "SUP" & "KITE": Press "plus" & "minus" once to set the demand pressure (0.3 psi-20psi). psi-20psi/0.02bar-1.38bar).
- "MAT": Press "plus" & "minus" once to set the countdown time (1min-10min).

# OPERATING INSTRUCTIONS


## INFLATION MODE




Choose the Appropriate Nozzle



Connect to the Pump




Connect to the Inflation Product




Click to start


## DEFLATION MODE




Choose the Appropriate Nozzle



Connect to the Pump



Connect to the Deflation Product



Click to start

## PARAMETERS

|                  |                                                                                                                            |
|------------------|----------------------------------------------------------------------------------------------------------------------------|
| Name             | EVO SUP PUMP PRO                                                                                                           |
| Model            | ESPP8000                                                                                                                   |
| Input(DC)        | 12V---10A                                                                                                                  |
| Input(Type-C)    | 5V --- 3A/9V --- 2A/12V --- 3A/20V --- 2.25A                                                                               |
| Rated Power      | 120W                                                                                                                       |
| Rated Capacity   | 88.8Wh(11.1V,8000mAh)                                                                                                      |
| Weight           | 1.86kg(65.6oz)                                                                                                             |
| Size             | 28.1cm*24.7cm*10.2cm (11.1in*9.7in*4.0in)                                                                                  |
| Package Contents | EVO SUP PUMP, 3.28ft Long Hose, 12V DC Car Connector, Charging Cable, Manual, Storage bag, High-pressure Air Hose, Nozzles |

## EN WARNING

---

- Do not attempt to repair or modify the product. If servicing is needed, please contact FLEXTAIL.
- Childre e this product under adult supervision.
- Before use, check for any abnormalities in the product. Do not use if any issues are found.
- Do not directly look into the inflation and deflation ports of this product during use.
- Do not insert fingers into the inflation and deflation ports of this product.
- This product is suitable for inflating products with pressures lower than 20 psi.
- Do not use continuously for more than 30 minutes.
- After inflating inflatable products like paddle boards, wait for ten minutes before using the product again.
- Immediately stop using the product if there are abnormal sounds or excessive heat during use.
- Do not leave the product unattended during use to prevent accidents.
- Ensure that the inflation and deflation ports are not blocked at any time.
- Prevent water and foreign objects from entering the inflation and deflation ports.
- Using strong chemicals or detergents for cleaning is prohibited.
- Avoid placing this product in extremely cold, hot, or humid environments.

## EN TROUBLESHOOTING GUIDE

---

- Plug in the charger to check if the battery is charged.
- Check if there is water or other liquid on the pump surface.
- Please check if the fan blades are stuck or obstructed by foreign objects.
- Please repeatedly press the switch to observe if the product starts.
- If you have any questions, please contact FLEXTAIL distributor or email to [support@flectail.com](mailto:support@flectail.com)

## EN WARRANTY POLICY

---

- FLEXTAIL warrants its products against defects in raw materials and manufacturing processes for a period of two years from the date of purchase to customers who have purchased the product from an authorized retailer. For this product, the warranty period is two years.
- If customer discovers a hidden defect in the product, please return it to the place of purchase. If cannot return it to the dealer, please return it to the address we provide. We will repair or replace the product in accordance with the warranty terms. We will undertake the due obligations during warranty period based on warranty terms. The service will no longer be provided after the warranty expires. We reserve the right to request proof of your warranty claim.

## EN PRODUCT DISCLAIMER

---

- Our warranties do not cover problems such as those caused by ordinary wear, modification or alteration of product, failure to follow directions, improper maintenance, accident damage, abuse, misuse, intentional damage or off-design use. This warranty gives you specific legal rights, and you may also have other rights which vary from purchase place. This warranty is expressly in lieu of all other warranties, express or implied, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose (If sales area prohibits exemption or limitation liability for incidental or consequential damages, or prohibits limitation of implied warranties, the above limitations or exclusions may not apply to you.)
- Both FLEXTAIL and FLEXTAILGEAR are legal registered trademarks of our company. The registered trademark FLEXTAIL and FLEXTAILGEAR are used for products in different batches. Both trademarks do not affect the use of the product.