

Φακός κεφαλής Flextail Tiny Helio 700Z (Πορτοκαλί)

Flextail · EAN 6975755966731

Machine translation from Magyar. In case of doubt the manufacturer's original document prevails.

A HELIO 700Z

User Manual

HEL900chtIN01

PRODUCT DESCRIPTION

Flood

Spot button

button

Lens

Charging port

Battery cover

Battery

Headband

Sliding lock

Tripod

Quick release pin

Battery cover

headband

DISPLAY INSTRUCTIONS

Charging indicator

0%-99%

100%

Type-C: 5V 600mA

Operation indicator

76%-100%

51%-75%

26%-50%

0-25%

USAGE INSTRUCTIONS

Flood mode Red mode

10lm 10lm OFF

200lm 100lm 5lm OFF

12h 17h 129.5h 36.5h 34h

Normal Slow

Medium Low Moon-

light flash

light

Double click to turn on Press again In flood mode, press and hold the Press again

Mode switch flood button to set the red Mode switch

mode. Spot mode Special mode

600lm 600lm OFF

400lm 100lm OFF

9.5h /

6h 20h

SOS SIGNAL LIGHT

Medium Low

Double click to turn on Press again In spot mode, press and Press again

Mode switch hold the spot button Mode switch

to activate the special mode. Mixed light mode

600lm250lm100lm4h OFF

10.5h 23h

Strong Medium Weak

Click twice on the spot Double press the flood Press again

button, then double press the button, then double press the focus Mode switch

wide light button to activate- button to turn on. Lock for transport

Press and hold simultaneously the wide light and the flashes three times and enters the

locked Press and hold simultaneously the wide light and the flashes, and exits the locked

spot button. state. spot button. state. TECHNICAL DATA

Name HELIO 600Z

Model HEL900cht

Input

5V 600mA

Rated power 4.65W*2

Weight 45.5 g (1.6 oz)

Color temperature 6500K

Rated capacity 3.33Wh(3.7V,900mAh)

Package contents HELIO 600Z, charging cable, user manual

(lm) (h) (m) (cd)

HIGH 600 4 100 2000

Mixed light mode MEDIUM 250 10.5 50 900

LOW 100 23 25 300

MEDIUM 400 6 100 2000

Spot mode

LOW 100 20 30 500

MEDIUM 200 12 30 300

Flood mode LOW 100 17 15 100

MOON 5 129.5 5 5

CONTINUOUS ON 10 36.5 10 40

Red mode

SLOW FLASH 10 34 10 /

SOS 600 9.5 / /

LIGHTHOUSE 600 / / /

WARNING

- The device's light source is not replaceable. When the light source reaches the end of its lifespan, the entire device must be replaced.
- If you notice battery leakage, unusual odor, or deformation, stop using the product immediately and dispose of it safely.
- Do not attempt to repair or modify the product. For service, please contact FLEXTAIL.
- This product contains a lithium battery, so special restrictions apply during transport. Please check the packaging before shipping.
- Avoid fully discharging the battery during storage. Products containing lithium-ion batteries should be charged at least every three months during storage.
- Children under 12 years old may only use this product under adult supervision.
- Do not immerse in water.
- The use of strong chemicals or cleaning agents is prohibited.
- Avoid placing the product in extremely cold, hot, or humid environments.
- Before use, check the product for any abnormalities. Do not use if any defects are detected.
- If you notice any unusual sounds or excessive heat during use, stop using the product immediately.
- To prevent accidents, do not leave the product unattended while in use.

·Bright light can damage the eyes.

ERROR PREVENTION GUIDE

- Connect the charger to check the battery charge level.
- Check for any water or other liquid on the product's surface.
- Press the switch repeatedly to check if the product starts.
- If you have any questions, contact your FLEXTAIL distributor or send an email to support@flectail.com.

EU REP

SUCCESS COURIER SL

CALLE RIO TORMES NUM. 1, PLANTA 1, DERECHA, OFICINA 3,
Fuenlabrada, Madrid, 28947 Spain

succeservice2@hotmail.com

Manufacturer: Changzhou Flectail Technology Co., Ltd., North Huashan 18, 213022
Changzhou City,

China, support@flectail.com

For all information regarding use and operation, please read the user manual or the product label. Before using the product, read the documentation and follow the instructions contained within. Please also read the following information before use:

Warnings and Safety Information

1. Electrical Safety:

- Proper battery use: Only use batteries recommended by the flashlight manufacturer to avoid overheating, explosion, or damage to the device.
- Battery charging: Charge the batteries according to the manufacturer's instructions, using the appropriate charger, and do not leave the flashlight unattended while charging.
- Do not use in wet environments: If the flashlight is not waterproof, avoid using it in the rain or near water to prevent damage to the electrical components and the risk of electric shock.
- Overheating warning: Flashlights, especially those with high-intensity light sources, can become hot during prolonged use. Always check the device for overheating to avoid burns or material damage.

2. Usage Safety:

- Using in dark conditions: When using a flashlight in the dark or adverse conditions (e.g., hiking, camping), be aware of your surroundings to avoid tripping or falling.
- Flashlight storage: Store the flashlight in a dry, cool place when not in use to prevent damage, especially if the batteries can overheat.

- Child safety: Keep the flashlight away from children, especially if it contains small parts – such as replaceable batteries or removable covers – that may pose a choking hazard.

3. Burn and Damage Hazards:

- Attention to bright light: Do not direct the flashlight beam directly into your eyes, especially at high brightness, to avoid eye damage.

- Warning when touching hot surfaces: The outer parts of the flashlight can become hot, especially when using a high-performance LED flashlight. Always check the temperature of the flashlight before use, especially after prolonged use.

4. Maintenance Recommendations:

- Cleaning and maintenance: Regularly check the condition of the flashlight. Use a soft cloth to clean the housing to avoid scratches and damage. Ensure there is no moisture in the battery compartment to prevent damage to the device.

- Battery replacement recommendations: Replace the batteries regularly according to the manufacturer's instructions. Avoid using damaged or overly worn batteries, as they can degrade the device's performance and cause overheating.

5. Flashlight Storage:

- Proper storage: To maintain the long-term proper functioning of the flashlight, store it in a dry, cool place, away from extreme temperatures, moisture, and heat sources. Avoid storing the flashlight in a location where it may be exposed to direct sunlight or high temperatures.

Environmental Protection

In accordance with European Union directives, labeled electronic waste should not be disposed of with other municipal waste. Waste must be collected separately and recycled at designated points. Proper disposal can prevent potential negative impacts on the environment and human health. The collection system for used equipment complies with local environmental regulations regarding waste disposal. Detailed information on this topic can be obtained from your local municipality, waste management facility, or the store where the product was purchased. The product complies with the European Union (EU) so-called new approach directives regarding safety, health, and environmental issues, which define the hazards to be identified and eliminated. This document is a translation of the original user manual prepared by the manufacturer. The product must be regularly maintained (cleaned) by the user or serviced at the user's expense and cost.

If the user manual does not contain information regarding the necessary cyclical maintenance or servicing operations, the physical condition of the product must be evaluated regularly, at least once a week, for deviations from that of a physically new

product. If any deviations are detected or found, maintenance (cleaning) or service measures must be taken urgently. Failure to perform proper maintenance (cleaning) and to respond when a different condition is detected may result in permanent damage to the product. The warranty provider is not liable for damages resulting from negligence. Importer: INNPRO Robert Błędowski sp. z o.o. Rudzka 65c 44-200 Rybnik, Poland tel. +48 533 234 303 hurt@innpro.pl www.innpro.pl

For LI-ION batteries

The device is equipped with a LI ION (lithium-ion) rechargeable battery, which ages over time and with use due to its final and chemical composition. The manufacturer specifies the maximum operating time under laboratory conditions, where optimal operating conditions for the device are present, and the battery itself is new and fully charged. In reality, the operating time may differ from what is stated in the offer, and this is not a fault of the device, but a characteristic of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge the battery below 3.18 V or below 15% of its full capacity. Lower values, such as 2.5V on a cell, will permanently damage it, and this is not covered by the warranty. If the battery or the entire device is not used for more than a month, charge the battery to 50% and regularly check its charge level every two months. Store the battery and the device in a dry place protected from sunlight and negative temperatures.

For LIPO batteries

The device is equipped with a LI PO (lithium-polymer) battery, which ages over time and with use due to its physical and chemical composition. The manufacturer specifies the maximum operating time under laboratory conditions, where optimal operating conditions for the device are present, and the battery itself is new and fully charged. In reality, the operating time may differ from what is stated in the offer, and this is not a fault of the device, but a characteristic of the product. To preserve the maximum lifespan of the battery, it is not recommended to discharge the battery below 3.5 V or below 5% of its full capacity. Lower values, such as 3.2V on a cell, will permanently damage it, and this is not covered by the warranty. If the battery or the entire device is not used for more than a month, charge the battery to 50% and regularly check its charge level every two months. Store the battery and the device in a dry place protected from sunlight and negative temperatures.

Safety precautions

Before charging, check that the device's contacts are clean. Never leave the device

unattended while in use or charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high temperatures. Charge the device in a dry and well-ventilated area, keeping at least 1 meter away from other objects. Never cover the device while charging. Never use power supplies, charging stations, cables, etc., without the manufacturer's recommendation and approval. Take care of your property; the device is equipped with hard-to-extinguish cells, equip it with a fire blanket.

Warranty certificate

Importer name and address: INNPRO Robert Błędowski, ul. Rudzka 65c, 44-200 Rybnik, Poland

Product seller (distributor, legal warranty provider) name and address:

Date of purchase (contract conclusion) and consumer's receipt:

Invoice number/Package number:

Product data:

Type:

Name:

Identification number:

Warranty length:

DEAR CUSTOMER

Thank you for choosing a product distributed by INNPRO. We hope you will make good use of our product in the future. It is unlikely that the product will need repair during use, but if it does, you can contact the seller (distributor) directly for assistance. To avoid inconveniences, please read the user manual carefully before contacting the distributor.

WARRANTY CLAIMS

Regarding the products, the owner of the product can assert warranty claims according to the registered warranty certificate, provided that they act as a consumer (a natural person acting outside their profession, independent occupation, or business activity). The warranty claim can be asserted at any time during the warranty period by presenting the original warranty certificate to the seller (distributor).

WARRANTIES AND GUARANTEES

The importer does not assume any warranty for the product or any accessory regarding its quality, performance, accuracy, reliability, or suitability. The seller (distributor) is exempt from warranty obligations if the seller (distributor) or the service authorized to perform warranty repairs proves that the defect occurred after the completion of the performance.

Product battery specifications

Property Value

Battery category Portable battery

Battery type Portable button cell

Batteries: Lithium

Contains cadmium/lead No

(>0.002% Cd, >0.004% Pb)

Net weight (kg) 0.0188

Capacity (mAh) -

The warranty does not cover:

a) Physical damage, fire damage, or water damage not resulting from manufacturing defects, including but not limited to user errors; b) Damage resulting from improper use, unauthorized disassembly, or damage resulting from tampering that does not comply with the user manual; c) Water damage resulting from improper storage, use, or use not in accordance with the user manual; d) Damage resulting from unauthorized modifications to the circuit, improper battery use; e) Damage resulting from use under adverse weather conditions (e.g., storm, sandstorm, rain, etc.); f) Damage resulting from operation in a strong electromagnetic field; g) Damage resulting from operation in other high-interference environments; h) Damage resulting from low battery voltage or faulty battery use; i) Products that are counterfeit or destroyed; j) Products that do not have sales documentation or where the sales documentation cannot be identified as belonging to that product, or where the sales documentation is counterfeit; k) Damage resulting from improper storage, transportation, or dropping; l) In case of vandalism; m) Malfunctions occurring due to causes arising after the warranty period; n) Failure to perform regular inspections and maintenance required by the manufacturer; o) Any intervention or repair that causes the defect or its cause, which is not performed by an official service listed on this warranty certificate. LEGAL

WARRANTY

Under the consumer contract, products purchased in Hungary from the distributor are subject to mandatory legal warranty according to Government Decree 151/2003. (IX. 22.), which lasts from the date of delivery of the product or the date of commissioning by the seller or the seller's representative:

- For a sales price reaching 10,000 forints but not exceeding 250,000 forints, two (2) years,
- For a sales price exceeding 250,000 forints, three (3) years. Failure to meet these deadlines results in the loss of rights. The legal warranty applies to the seller (distributor) who sold the product. According to Section 4 (2) of Government Decree 151/2003. (IX. 22.),

the irregular issuance of the warranty certificate or the failure to provide the warranty certificate to the consumer does not affect the validity of the warranty. The fulfillment of claims based on an irregularly issued warranty certificate is the responsibility of the seller (distributor). The enforcement of rights arising from the legal warranty is not conditional on the return of the product's packaging by the consumer. The provisions of this warranty certificate do not affect the rights of the consumer arising from the law. RIGHTS

ENFORCEABLE UNDER LEGAL WARRANTY

In the event of a defect occurring during the warranty period, the consumer may choose:

a) repair or replacement, unless the fulfillment of the chosen warranty claim is impossible, or if it would result in an unreasonable burden on the distributor compared to fulfilling the other warranty claim, taking into account the value of the product in perfect condition, the severity of the breach of contract, and the detriment caused to the entitled party by fulfilling the warranty claim; b) a price reduction; or - if the distributor has not fulfilled the repair or replacement within the deadline set for this obligation, or if the entitled party's interest in repair or replacement has ceased, the consumer may withdraw from the contract. There is no place for withdrawal due to the current defect. The distributor - in the absence of any different provision from the consumer - is obliged to replace the product within eight (8) days if

a) during the first repair of the product under the legal warranty period, it is determined that the product is not repairable, or

b) the product malfunctions again after three (3) repairs.

or

c) if the correction of the product does not take place within thirty (30) days calculated from the request for correction made to the seller, starting from the expiration of the thirty-day period. If, according to the above, there is no possibility for the product to be exchanged, the seller (distributor) will refund the purchase price indicated on the receipt presented by the consumer, which proves the payment of the product's countervalue, within eight (8) days.

The correction or exchange must be carried out within an appropriate time frame, taking into account the product's properties and the expectations of the entitled party, while safeguarding the interests of the consumer. The warranty provider must strive to ensure that the correction or exchange is completed within a maximum of 15 days. The consumer must report the warranty claim directly to the seller (distributor) without delay upon noticing the malfunction. If the consumer submits a valid exchange request within three working days from the purchase (from the commissioning) due to the product's malfunction, the seller

(distributor) cannot refer to additional costs and is obliged to exchange the consumer goods, provided that the malfunction hinders the intended use. During the warranty period, warranty repair work can only be performed by the designated service center based on the valid warranty ticket. All warranty repairs must be checked for the proper completion of the repair receipts. During the repair, only new parts may be installed in the product. If the designated workshop does not carry out the repair or refuses to accept the repair, the consumer may have the product repaired elsewhere at the expense of the warranty provider. To claim the repair costs, appropriate invoicing is required. The warranty claim for the part of the product affected by the exchange or repair starts anew. COMMON RULES

REGARDING WARRANTY

If the product malfunctions within the warranty period due to the use of unsuitable materials during manufacturing or production (calculated from the date of the first purchase), the official service of the importer will repair it free of charge within the warranty area, or will replace the product or the defective part, provided that the conditions and restrictions specified in this warranty ticket for the defective part are taken into account, and the contractual warranty is valid. Ownership of all replaced products or parts transfers to the party performing the exchange. Warranty is only valid for the defective product handed over within the warranty period, as well as for the original document proving the purchase, which contains the date of purchase, the model type, and the name of the seller or distributor (warranty ticket, in the absence of which a receipt or invoice) if it is presented in an intact and readable manner. Otherwise, the official service of the importer may refuse the free warranty service. The warranty is not valid for products on which the serial or production number has been altered, removed, or rendered unreadable. Please check the proper completion of the warranty ticket at the time of purchase, and keep the warranty ticket carefully. A lost warranty ticket can only be replaced if there is credible proof of the sale date (e.g., an invoice with a date and stamp, presentation of a sales receipt). Any modification, deletion, rewriting, or entry of false data on the warranty ticket invalidates the warranty ticket. Please ensure that removable storage devices are removed from the product before submitting it for repair to avoid loss or malfunction. The warranty does not cover shipping costs and risks related to delivery by a carrier designated by someone other than the importer to the importer or the official service of the importer for defective products. The manufacturer may also provide additional warranty coverage for the products specified on this warranty ticket, the conditions of which - depending on the product - are included in the User Manual attached to the purchased product and/or on the manufacturer's official website. The consumer may report warranty claims related to the product beyond the legally

mandated warranty period at the representative points designated by the manufacturer. In case of legal disputes, the consumer may initiate proceedings before the conciliation body operating alongside the county (capital city) chambers of commerce and industry.

REPAIRS/REPLACEMENTS PERFORMED UNDER WARRANTY:

Report date: Return date:

Fault occurrence: New warranty expiration date:

New identification number: Work order number:

(Ph) Performed repair/replacement:

Report date: Return date:

Fault occurrence: New warranty expiration date:

New identification number: Work order number:

(Ph) Performed repair/replacement:

Report date: Return date:

Fault occurrence: New warranty expiration date:

New identification number: Work order number:

(Ph) Performed repair/replacement:

The seller's warranty obligation (signature of the authorized person issuing the warranty certificate) Buyer's signature
and the signature of the person issuing the warranty ticket