

Εξωτερική μπαταρία Flextail Zero Power 10.000 mAh (Μαύρη)

Flextail · EAN 6975755966793

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Flextail Zero Power Bank

10000mAh

User Manual

Introduction

Performance Indicator

Power Button Lanyard Hole

IN / OUT1 OUT2

Battery Status Indicator

Screen

Charging Indicator

100%

75%-100%

25%-50%

10%-25%

Low Battery Level Indicator

1 flashing light: < 10%

During use, the charger will automatically turn off when the battery level drops below 10%.

To restart the device, press the switch again or disconnect and reconnect the device.

Usage

Output Indicator

Green light: normal charging mode

Orange indicator: High performance mode

Performance indicator

To activate high performance mode, double press the power button. In high performance mode, the total output power OUT1+OUT2 is 5 V, 1 A. Parameters

Model: PB10000C

Weight: 145 g (±3 g)

Dimensions: 122 mm × 59.5 mm × 9.9 mm (±1 mm)

Capacity: 10000 mAh, 3.87 V (38.7 Wh)

Nominal capacity: 7000 mAh (5 V, 1 A)

Input: USB-C (IN) 5 V, 3 A / 9 V, 2 A / 12 V, 1.5 A (max. 18 W)

Output:

USB-C (OUT1) 5 V 1 A/5 V 3 A/9 V 2.22 A/12 V 1.67 A/10 V 2.25 A (max. 22.5 W)

USB-C (OUT2) 5 V 1 A/5 V 3 A/9 V 2.22 A/12 V 1.67 A/10 V 2.25 A (max. 22.5 W)

Total output power 5 V 3 A (max. 15 W)

Package contents: power bank, charging cable with hanging strap, user manual

- Do not disassemble, do not throw into fire, keep away from sources of fire and high temperatures, avoid short circuits.
- Before use, check if the product shows any abnormalities. Do not use if any problems are detected.
- Do not leave the product unattended during use to prevent accidents.
- Do not expose the product to prolonged use in rain.
- It is prohibited to use strong chemicals or detergents for cleaning.
- Avoid placing this product in environments with extremely low or high temperatures and high humidity.
- Immediately stop using the product if any unusual sounds or excessive heating occur during use.
- If you notice any leakage from the battery, strange odors, or deformation, immediately stop using the product and dispose of it safely.
- This product contains a lithium battery and is subject to special transport restrictions.

Check the packaging before transport.

- Avoid storing the product with a completely discharged battery. Lithium-ion battery products should be charged at least every 3 months during storage.
- Children under 12 years of age must use this product under adult supervision.
- Do not attempt to repair or modify the product. If repair is necessary, contact FLEXTAIL.

This document is a translation of the original user manual created by the manufacturer.

Detailed information about the distributor/manufacturer warranty conditions is available on the website <https://serwis.innpro.pl/gwarancja>

The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. In the absence of information about necessary periodic or service maintenance actions in the user manual, the physical condition of the product should be assessed regularly, at least once a week, against that of a

physically new product. If any deviation is detected or noted, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detection of a deviation may lead to permanent damage to the product. The warranty does not cover damages resulting from neglect. Warnings and safety information for power banks
All information regarding operation and use can be found in the user manual or on the product label. Before starting to use the product, familiarize yourself with its content and follow the instructions contained therein. Also, review the following information before use:

User safety

Use the power bank as intended – Power banks are designed to store energy that can be used to charge portable devices. Using the power bank for purposes other than its original intent may lead to damage, overheating, or fire. Check the condition of the power bank before use – Before each use, ensure that the power bank has no visible damage, such as cracks, scratches, or port damage. A damaged power bank may not function properly or pose a hazard. Use compatible devices – Use the power bank only to charge devices compatible with its parameters, such as voltage and current. Incompatible devices may damage the power bank or the device being charged. Precautions

Protect against overheating – Power banks may heat up during charging or while charging other devices. Ensure that the power bank is used in well-ventilated areas to avoid overheating. Store under appropriate conditions – Store the power bank in a dry, cool place, away from heat sources, moisture, and extreme temperatures. Excessively high temperatures may lead to overheating, while extremely low temperatures may damage the battery.

Avoid dropping the power bank – Power banks contain delicate cells that can be damaged due to a fall. Ensure that you avoid dropping the device. Safe usage

Do not leave the power bank unattended while charging – Never leave the power bank unattended while charging. Make sure it is not exposed to shocks that could damage the device. Turn off devices after charging – After charging devices from the power bank, turn off the power bank to prevent overheating or excessive energy consumption. Safe connecting and disconnecting – Always connect and disconnect devices to the power bank gently, avoiding yanking on cables or ports, which can lead to damage. Usage guidelines in appropriate conditions

Optimal operating conditions – Avoid using power banks in places with extreme temperatures, as this may affect battery performance. Avoid contact with water and moisture – Power banks are not water-resistant, so avoid using or storing them in humid

conditions that may damage the electronics. Avoid contact with chemicals – Power banks can be damaged if they come into contact with chemicals such as greases, oils, or solvents. Maintenance instructions

Regularly check the condition of the power bank – Check the condition of the power bank to ensure there are no visible damages or deformations of the casing. If you notice any irregularities, stop using the device and contact the manufacturer. Cleaning ports and connectors – Regularly check the USB ports and connectors on the power bank. Use a dry cloth to remove dirt to ensure proper contact with devices. Keep the battery in good condition – Try to avoid completely discharging the power bank and overcharging it, as this may shorten the battery's lifespan. Safe disposal

Disposal of used power banks – Used or damaged power banks should be disposed of in accordance with applicable environmental protection and electronic recycling regulations.

Recycling materials – Power banks contain materials that can be recycled, such as metal parts, plastic, and batteries. Contact local recycling points to find out how to properly dispose of the used device. Do not throw the power bank in regular waste containers – Contact appropriate electronic waste collection points that handle the recycling of power banks. Compliance statement

Products have been designed in accordance with the safety requirements specified in Regulation (EU) 2023/988 on general product safety, ensuring their compliance with applicable safety and health protection standards for users. Safety measures

Before charging, check that the device contacts are clean. Never leave the device unattended during use and charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high temperatures. Charge the device in a dry and well-ventilated place away from flammable materials, maintaining a free space of at least 1m from other objects. Never cover the device while charging. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and certification. Take care of your property; the device is equipped with cells that are difficult to extinguish, equip yourself with a fire blanket. LI-ION battery

The device is equipped with a LI-ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal operating conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from the declared time in the offer and this is not a defect of the device but a product feature. To maintain maximum battery life, it is not recommended to discharge it below 3.18V or 15% of total capacity. Lower values, such as 2.5V for the cell, permanently

damage it and this is not covered by warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. LI-PO battery

The device is equipped with a LI-PO (lithium-polymer) battery, which, due to its physical and chemical structure, ages over time and with use.

Manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device are present, and the battery itself is new and fully charged. The actual operating time may differ from that declared in the offer and this is not a defect of the device but a product feature. To maintain maximum battery life, it is not recommended to discharge it below 3.5V or 5% of the total capacity. Lower values, such as 3.2V for the cell, permanently damage it and this is not covered by warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. Environmental Protection Used electronic equipment marked in accordance with the European Union directive must not be disposed of together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The system for collecting used equipment complies with locally applicable environmental protection regulations regarding waste disposal. Detailed information on this topic can be obtained from the municipal office, cleaning company, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) regarding issues related to user safety, health protection, and environmental protection, identifying hazards that should be detected and eliminated. Importer: INNPRO Robert Błędowski sp. z o.o. Representative in the EU: Rudzka 65c SUOCESS COURIER SL 44-200 Rybnik, Poland CALLE RIO TORMES 1 tel. +48 533 234 303 28947 Madrid, Spain hurt@innpro.pl succeservice2@hotmail.com www.innpro.pl Manufacturer: Changzhou Flextail Technology Co., Ltd. North Huashan 18 213022 Changzhou City, China support@flextail.com Battery information: Type: Lithium-ion battery Net weight: 147.4g Capacity: 10000mAh Power: 0.0387 kWh Cadmium (0.002%) or lead (0.004%) content exceeded: no Battery serial number: BH9058102