

Φορητός θερμαντήρας γάλακτος Grownsy

Grownsy · EAN
5905156102606

Machine translation from Polski. In
case of doubt the manufacturer's
original document prevails.



USER MANUAL BOTTLE WARMER

Before use, please read this manual carefully.
and keep it for future reference.

SINCERE THANKS

Thank you for shopping at our store and for trusting our brand.

GROWNSY – the best helper for parents. Care, support, and assistance at every stage of development.

GROWNSY creates products for mothers and infants.

We offer a wide range of products, including bottle warmers, nasal aspirators for infants, bottle sterilizers, baby food makers, breast pumps... Our goal is to create a comprehensive brand of products for mothers and infants. If you have any questions or issues, please contact us via email:

service@grownsy.com

Or send a text message with the word GROWNSY to (833)524-0498

We will do our best to resolve any customer issues within 24 hours.

Randell
Founder of GROWNSY



Precautions

For your own safety, please read this user manual carefully before using the product. After reading, store it properly for future reference. Do not use this product without reading and understanding this manual, as it may result in product-related accidents. We are not responsible for any bodily injuries, property damage, or other losses caused by non-compliance with the user manual or appropriate precautions.

Prohibited actions

1. Keep this product out of reach of infants and children.
2. Stop using this product if it is damaged or not functioning properly.
3. Do not turn on the device without water to avoid overheating.
4. Before cleaning, turn off the device and gently wipe the main part. Do not rinse directly with water to avoid damage.
5. The device is not intended for use by specific user groups (e.g., children).
6. Children should not play with plastic film and packaging, as this may lead to choking hazards.
7. Only use parts supplied by our company; do not modify the product components or disassemble it on your own.
8. Do not insert or remove the plug with wet hands to avoid electric shock.
9. The device contains a rechargeable polymer battery. Do not use it in environments with strong electrostatic charges or magnetic fields, nor place it in a microwave or sterilizer.

Mandatory operations


1. Clean the product before use.
2. The product should be used at a temperature range of 0 to 35°C.
3. In case of malfunction, please contact our after-sales service for assistance. Do not disassemble the device on your own.
4. Use a UL-certified power adapter for charging the product to avoid unstable charging or accidents.
5. After fully charging, disconnect the charger plug. Prolonged charging may cause fire and other safety hazards.
6. If the product is not in use, return the battery to a designated recycling station for proper disposal according to national regulations.

Specifications

Specification	Value
Product name	Portable milk warmer
Product model T6	
Rated voltage	14.8V
Rated capacity	600mL
Charging voltage $\geq 5V$	
Charging current $\geq 2A$	
Working power 80W	
Lithium battery capacity	2700 mAh (equivalent to 3.7 V 10800 mAh)
Temperature range of insulation	32-50°C
Fast/slow charging time	Approximately 2-4.5 hours
Net weight	Approximately 664 g

Product user manual

Component names:



Note: The image is for illustrative purposes only.
The actual appearance of the product may vary.

Operational steps

1. Before use, ensure that the device is fully charged.
2. Power on:
 - Fill the warmer with water or breast milk, then press the power button to turn on the device.

- Use the “+” or “-” buttons to set the temperature. The temperature can be adjusted from 90 to 122°F.
- After confirming the temperature, the screen will blink three times, and then the device will start working. The real-time temperature will be displayed on the screen.
- After finishing its work, the device will automatically maintain warmth for 24 hours.
- Note: The device has a memory function. When powered on, it defaults to the last used temperature.

3. Power off:

- Press the power button once to turn off the water cup.

4. Charging:

- When the battery level of the device is low, charge it as soon as possible.
- During charging, the battery charge indicator will blink sequentially. After fully charging, the battery indicator will light up continuously.

Tips:

1. Before going out, ensure that the device is fully charged to prevent battery depletion and the inability to heat water/milk to the desired temperature.
2. After spilling breast milk, promptly clean the milk stains inside the warmer.
3. Do not immerse the device directly in water to prevent damage.

WARRANTY AND CUSTOMER SERVICE

GROWNSY strives to create user-friendly products for newborns and household items. Our goal is not only to create products but also items filled with the care and love we give to our customers. If you have any problems, please contact us directly (service@grownsy.com), and we will be happy to assist you.

**Or send a text message with the word
GROWNSY to (833)524-0498**



REGISTER YOUR FREE WARRANTY

At GROWNSY, we use only the highest quality products – but just in case, don't forget to register for a FREE annual warranty...

www.grownsy.com/warranty



Warnings and safety information

All information regarding the use of the products can be found in the attached user manual. Before starting to use the device, familiarize yourself with its content and follow the manufacturer's recommendations.

Also, review the following information before use:

Usage warnings

Risk of damage to electrical devices:

Hazard to children:

- Electrical products, such as bottle warmers and sterilizers, are not intended for unsupervised use by children.
- Accessories such as thermoses, milk storage bags, or bottles should be kept out of reach of children when not in use.
- Milk storage bags should be kept away from small children to prevent accidental choking.

Overheating hazard:

- Food processors and bottle warmers may become hot during operation. Do not touch hot parts of the devices – follow the manufacturer's instructions.
- Do not leave devices turned on unattended.

Information on proper usage

Preparation and use:

- Before first use, thoroughly wash all parts that come into contact with food according to the user manual.
- Ensure that all electrical devices (e.g., food processors, sterilizers) are properly assembled before connecting to power.
- For sterilizers and warmers, always use the appropriate amount of water according to the instructions.

Storage and cleaning:

- After use, disconnect electrical devices from the power source.
- Store milk storage bags in the refrigerator or freezer according to the manufacturer's recommendations.
- Clean warmers, sterilizers, and food processors regularly to prevent the accumulation of food residues or deposits.

Precautions when working with hot liquids:

- When transferring hot liquids in thermoses or warmers, exercise special caution to avoid burns.
- Before giving food or drink to a child, check the temperature of the heated food or drink.

Additional precautions

- Service and maintenance: In case of technical problems, contact an authorized service point. Do not attempt to repair devices yourself.
- Cleaning: Use only gentle cleaning agents to avoid damaging the surfaces of the devices.

Declaration of conformity

Products have been designed in accordance with the safety requirements specified in Regulation (EU) 2023/988. They meet the requirements for materials intended for contact with food and safety of use in a domestic environment.

Environmental protection



Used electronic equipment marked according to the European Union directive must not be disposed of together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The system for collecting used equipment complies with locally applicable environmental protection regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, waste management facility, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) regarding safety of use, health protection, and environmental protection, specifying hazards that should be detected and eliminated.



This document is a translation of the original user manual created by the manufacturer.

Detailed information on the distributor/manufacturer warranty conditions is available at <https://serwis.innpro.pl/gwarancja>

The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. In the absence of information about necessary periodic or service maintenance actions in the user manual, the user should regularly, at least once a week, assess the physical condition of the product against that of a physically new product. If any deviation is detected or noted, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detecting a state of deviation may lead to permanent damage to the product. The warranty does not cover damages resulting from neglect.

Importer **INNPRO**
:

INNPRO Robert Błędowski sp. z o.o.
ul. Rudzka 65c
44-200 Rybnik, Poland
tel. +48 533 234 303
hurt@innpro.pl
www.innpro.pl

Manufacturer:
DORABOX CO., LIMITED
ADD: SHOP 185 G/F HANG WAI IND CTR NO
6 KIN TAI ST TUEN MUN NT HONG KONG
Email: xiao@grownsy.com

Responsible person in the EU:
CET PRODUCT SERVICE SP. Z O.O.
Ul. Długa 33 102 Zgierz 95-100 Poland
info@cetproduct.com

Safety measures

Before charging, check that the device contacts are clean.

Never leave the device unattended during use and charging.

Ensure that you can quickly disconnect the device from the power source in an emergency.

Never expose the device to high temperatures.

Charge the device in a dry and well-ventilated area away from flammable materials, maintaining a minimum distance of 1m from other objects.

Never cover the device while charging.

Never use a power adapter, charging station, cables, etc., without the manufacturer's recommendation and certification.

Take care of your property; the device is equipped with cells that are difficult to extinguish, equip yourself with a fire blanket.

LI-ION Battery

The device is equipped with a LI ION (lithium-ion) battery, which ages over time and use due to its physical and chemical structure. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from the declared offer and this is not a defect of the device but a feature of the product. To maintain maximum battery life, it is not recommended to discharge it below 3.18V or 15% of total capacity. Lower values, such as 2.5V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures.

LI-PO Battery

The device is equipped with a LI PO (lithium-polymer) battery, which ages over time and use due to its physical and chemical structure. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from the declared offer and this is not a defect of the device but a feature of the product. To maintain maximum battery life, it is not recommended to discharge it below 3.5V or 5% of total capacity. Lower values, such as 3.2V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures.

Product battery specifications

Feature	Value
Battery category	Portable battery
Battery type	Portable lithium-ion batteries (Li-Ion)
Contains Cadmium/Lead (>0.002% Cd, >0.004% Pb)	No
Net weight (kg)	0.185
Capacity (mAh)	-