

Huion Kamvas Pro 27 144Hz GT2702 tablet γραφικών

Huion · EAN 6930444806064

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

GT2702

Kamvas Pro 27 (144HZ)

Thank you for choosing the HUION Kamvas Pro 27 (144HZ) creative pen display. As a new generation of professional pen displays, the Kamvas Pro 27 (144HZ) allows for drawing and creating with greater efficiency. With this pen display, you can freely write and draw, creating lines of varying widths, painting images in different shades of color, and experiencing the effect of pen on paper. To ensure a full understanding and effective use of the product, we strongly recommend carefully reading this user manual. Note: The images in the manual are for reference only and are intended to assist in understanding the construction and functions of the product. Changes in design or specifications may occur without prior notice. www.huion.com

1/48

GT2702

1. Product Introduction

1.1. Product Overview

Power button/display settings button

1

Short press: Turning the pen display on or off.

Long press for 3 seconds while the pen display is on:

Calling up the on-screen adjustment menu (OSD menu operated by pen).

2 Indicator light

www.huion.com

2/48

GT2702

- White light on: Working state
- Red light on: Sleep state
- Light off: No power/pen display is off

3 Slide switch

Slide the switch left or right to turn the touch function on or off.

4 Power input

For connecting the 19V 4.74A power adapter to provide power.

5 Full-function Type-C port

For connecting to a computer with a full-size USB-C cable and transmitting handwritten data.

6 DisplayPort

For transmitting DisplayPort signals.

7 HDMI port

For transmitting HDMI signals.

8 3.5mm headphone jack

For connecting a 3.5mm plug.

9 USB-A×2 port

For connecting USB drives, keyboards, mice, etc.

10 Built-in stand

Two built-in stands, adjustable from 0° to 20°, provide the appropriate viewing height and stable support.

11 VESA mounting hole pattern

www.huion.com

3/48

GT2702

With a VESA hole pattern of 100mm × 100mm, the Kamvas Pro 27 (144HZ) pen display can be mounted on various VESA-compatible brackets (available at the HUION Store) or on other brackets or arms, allowing for flexible adjustment of the angle and position of the pen display. Note: Since the Kamvas Pro 27 (144HZ) pen display weighs approximately 6.4 kg, please ensure that the separately purchased bracket or arm can support this weight; otherwise, safety hazards may occur during installation.

1.2. Accessories

After unpacking, please ensure that you have received the following items:

Kamvas Pro 27 (144HZ) pen display

AC power adapter

AC power cable (1.5 m)

HDMI cable (1.8 m)

Full-size USB-C cable (1.8 m)

www.huion.com

4/48

GT2702

USB-A to USB-C cable (1.8 m)

Digital pen PW600

Digital pen PW600S

Pen nib PN06 Standard x 5 (inside the pen case)

Pen nib PN06F Felt x 5 (inside the pen case)

Pen case (with built-in nib holder, nibs)

K40 Keydial remote

Cleaning cloth

Glove

Quick start guide

G1 GTCOLOR calibrator

1.3. Installation and use of the stand

The Kamvas Pro 27 (144HZ) pen display has two built-in stands at the back that can be unfolded for use.

Note:

1. In addition to the built-in stands, the pen display can also be mounted on various VESA-compatible brackets (available at the HUION Store) or on other brackets or arms that allow for more convenient adjustment of angle and position. Below is an example of installing the adjustable Huion ST100 stand, however, the stand is not included and must be purchased separately:

- ① Align the 4 mounting holes of the stand with the 4 VESA mounting holes on the back of the pen display and tighten the screws.
- ② After installation, slide the lever to adjust the angle of the stand (30°-85°).
- ③ Set the appropriate angle and you can start using the pen display.

2. The pen display can be used together with a keyboard tray (available at the HUION Store) or other mounts that facilitate the positioning of a keyboard, mobile phone, or other devices.

www.huion.com

6/48

GT2702

Below is an example of installing the Huion KH01 keyboard tray, however, the keyboard tray is not included and requires separate purchase.

- ① Clamp the keyboard tray in the appropriate position on the pen display;
- ② Tighten the screws at the back of the keyboard tray;
- ③ After installation, you can start using it together with a keyboard, mobile phone, or other devices.

2.

Connection

The pen display can be connected to computers and devices with the Android system. Please familiarize yourself with the connection methods below.

2.1. Connection via HDMI cable

1. Connect one end of the HDMI cable to the HDMI port on the computer and the other end to the HDMI port on the pen display;
2. Connect the USB-C connector of the USB-A to USB-C cable to the USB-C port of the pen display, and then connect the USB-A connector to the USB-A port on the computer;
3. Connect the power adapter plug to the power port of the pen display;
4. Connect the power adapter to the power cable, and then plug the cable into an electrical outlet.

2.2. Connection via full-size USB-C cable

1. Connect one end of the full-size USB-C cable to the USB-C port of the pen display and the other end to the USB-C port of the computer, tablet, Android device, or docking station to transmit signals and data;
2. Connect the power adapter plug to the power port of the pen display;
3. Connect the power adapter to the power cable, and then plug the cable into an electrical outlet.

3. Driver Installation

3.1. Windows

Note:

1. Before installing the driver, please close all graphic programs and antivirus software.
2. Please ensure that your computer's operating system is Windows 10 or newer.
3. If the connection fails, please restart the driver or the computer.
4. If you uninstall the driver, unknown keyboard issues may occur in some applications. In this case, please reinstall the driver, and the keyboard will return to default settings.

Driver installation instructions:

1. Connect the pen display to the computer.
2. Click Driver-Kamvas Pro 27 (144HZ) to download the latest driver for your device.
3. Double-click the driver and click "OK" to continue.

4. Check the box to accept the user agreement and click "Install Now."
5. After the installation is complete, click "Try Now."
6. An image of Kamvas Pro 27 (144HZ) will appear on the driver interface, indicating a successful connection. You can now use the pen display.

3.2. macOS

Note:

1. Please ensure that your computer's operating system is macOS 10.12 or newer.
2. If the connection fails, please restart the driver or the computer. For more information, please refer to Troubleshooting.
3. If you uninstall the driver, the pen display may not detect pressure sensitivity or may experience other unknown issues in some applications. In this case, please reinstall the driver, and the pen display will return to factory settings.

Driver installation instructions:

1. Connect the pen display to the computer.
2. Click Driver-Kamvas Pro 27 (144HZ) to download the latest driver for your device.
3. Unzip the driver file and drag the "HuionTablet" icon to the "Applications" folder.
4. Open the folder and then find and double-click the HuionTablet driver application.
5. Connect the pen display to the Mac and click "Open System Preferences" when the dialog box appears. Go to Security & Privacy > Privacy > Accessibility and click the lock icon to unlock the settings. Check the box next to the HuionTablet driver application to enable accessibility. Then click the lock icon to lock the settings again.
6. An image of Kamvas Pro 27 (144HZ) will appear on the driver interface, indicating a successful connection. You can now use the pen display.

4. How to Use the Digital Pen

Both digital pens are equipped with a non-slip silicone grip that reduces fatigue from prolonged holding of the pen. The PW600 model features 3 programmable side buttons and 1 eraser button, while the PW600S model has 2 programmable side buttons and 1 eraser button, allowing quick access to frequently used functions and significantly increasing work efficiency.

Holding the pen:

Hold the digital pen like a traditional pen. Adjust your grip so that you can easily operate the pressure-sensitive keys with your thumb or index finger. Be careful not to accidentally press the button while drawing with the pen.

Note: Please do not place the pen on the pen display when not in use, as this may interfere with the operation of the mouse and other devices and prevent the computer from entering

sleep mode.

Cursor movement:

Move the pen just above the working area of the pen display without touching its surface, and the cursor on the screen will move accordingly to the new position. Click:

Touch the working area of the pen display with the pen to register a click. Press lightly to highlight or select an item on the screen, press and hold to drag it, and double-clicking will open that item. www.huion.com

17 / 48

GT2702

Move:

Grab a file or icon, then move the pen tip across the screen to move it. Erase:

Move the eraser button across the area you want to erase, just like a pencil eraser. Use pen buttons:

The functions of the pen buttons can be programmed in the driver. The pen buttons work when the vertical distance between the pen tip and the pen display is within the detection range (10 mm). If you do not want to use the pen buttons, you can set them to no function in the driver. Replacing the pen tip:

Tip: When the pen tip is significantly worn, it should be replaced with a new one in a timely manner.

1. Open the pen case and remove the replaceable tip.
2. Tilt the pen and pull out the worn pen tip using the built-in tip holder located on the back of the pen case.
3. Insert the replaceable tip straight into the pen body until the tip stops in the correct position. www.huion.com

18 / 48

GT2702

5. How to use capacitive touch

Equipped with a capacitive touch panel, the Kamvas Pro 27 (144HZ) model supports 10-point capacitive touch, significantly enhancing creative work efficiency. Slide the switch left or right to turn the multi-touch function off or on. * Note:

1. The capacitive touch function is currently supported only on Windows. Besides Windows touch gestures, other functions may be supported depending on the specific program.
2. The capacitive touch function is enabled by default when the pen display is first powered on. General functions

Finger Gestures Action

Touch Select

Double tap Open file

One finger

Press and hold Show more commands (e.g., right-click)

Press and drag Move file

Move horizontally or vertically Scroll

Two fingers

Pinch or stretch fingers Zoom out or zoom in

Swipe up Show all open windows

Three fingers Swipe down Show desktop

Swipe left or right Switch between open applications or windows

Swipe up Show all open windows

Four fingers Swipe down Show desktop

Swipe left or right Switch desktops

www.huion.com

19 / 48

GT2702

6. Huion tablet driver

6.1. Driver home page

① ②

③

6.1.1. Guide to new features

Users can familiarize themselves with the guide to new features here and quickly master the basic functions and settings of the driver. The page can be closed by clicking the Close box in the upper right corner or after completing the guide. www.huion.com

20 / 48

GT2702

6.1.2. Application settings

Users can customize the global settings of the driver here, including driver version, updates, problem reporting, theme, language, software shortcuts, privacy agreement, etc.

www.huion.com

21 / 48

GT2702

Feature overview:

Automatic When enabled, updates are checked and installed automatically. Update log Click to access the official update log. Check Click to verify if the driver version is the latest, and then follow the

Updates update instructions if necessary. If you encounter issues such as inability to click, draw lines, or pressure sensitivity in the application, you can click "Run Diagnostics" to determine the cause. Official website Click the brand icon to visit the official Huion website. After clicking "Feedback," the mail application on the computer will automatically launch, and device information will be pre-filled along with a standard question format. Change the theme color and restart the software to apply

Theme

the changes. Language Click the dropdown button to select your preferred language and www.huion.com

22 / 48

GT2702

restart the software to apply the changes.

Open the driver interface: use the default shortcuts to quickly invoke the driver interface. You can also set your own shortcuts according to your personal preferences. Switch mapping screen: use the default shortcuts to change screens. Keyboard shortcuts are written for the pen tablet/pen display. You can also set your own shortcuts according to your preferences. The screen-switching shortcut only works for the currently selected device in the Huion tablet driver. To restore the default shortcuts for opening the driver interface, click "Reset to default settings." Share diagnostic data and usage information: Automatically send diagnostic data and usage information to help improve our products and services. Automatic startup on system boot: The driver will automatically start when the computer is turned on. Permissions Administrator permissions: This option is available only on Windows. The driver will determine if the current driver page is running with administrator permissions. This option will only be displayed if the current driver page is not running with administrator permissions. 6.1.3. Device Click the device image to go to the device page, where users can customize the settings of the selected device. 6.2. Device page www.huion.com 23 / 48 GT2702 ② ③ ① ④ ⑤ 6.2.1. Device name The name of the selected device is visible in the upper left corner of the page. Click the dropdown box to switch between devices. www.huion.com 24 / 48 GT2702 After successfully connecting a new device, a reminder will appear. 6.2.2. Add new software The feature set can be configured individually for the selected software. After clicking the plus button in the upper right corner, a list of recently

opened software on the device will appear. Select the software to be configured and add it as preset software. You can also click the delete button to remove it by hovering the cursor over the software icon. When switching to preset software, the configuration options will automatically adjust to the settings of that software. If you cannot find the required software, click "Other programs" to add new ones from the computer. www.huion.com 25 / 48 GT2702

6.2.3. Device settings In the device settings window, you can check the firmware version and configure cursor calibration, pen settings, and backup settings. www.huion.com 26 / 48

GT2702 Device settings options: Information Contains the device model and firmware version. Click "Cursor Calibration" to go to the calibration page and follow the instructions to start calibration. If you accidentally click incorrectly and the cursor calibration is inaccurate, click "Factory Reset" to perform the calibration again. Simulates the tilt of the actual pen. Click the switch on the right side to enable or disable the tilt function. Pen tip functions include pressure sensitivity, clicking, etc. Click the switch on the right side to enable or disable the tip. After opening the file manager, select and open the configuration file to import a backup. Export backup Export the current settings to a local file and name it. Default settings Reset all device settings to default values.

6.2.4. Functional navigation bar You can customize the pressed keys, workspace, virtual keyboard, and digital pen according to your preferences. Click each icon on the navigation bar to go to the corresponding settings page. www.huion.com 27 / 48 GT2702

6.2.5. Battery and common issues Battery: Check the remaining battery level of the device. Common issues: Click the question mark icon and go to <https://www.huion.com/support.html> for the user manual or to report issues.

6.3. Pen display settings Select the Workspace tab to adjust the ratio between pen movement on the pen display and cursor movement on the monitor. By default, the entire active area of the pen display is mapped to the entire screen of the monitor. If more than one monitor is used and they are in extended mode, the user must select the one that will be mapped in the driver interface, and set the other as an external display. In mirror mode (all monitors display the same content), the pen display is mapped to the full screen of each monitor, and the cursors move simultaneously on them.

6.3.1.

Workspace Setup

Define the area of the pen display that will be mapped to the monitor. In the driver interface, three modes can be selected:

www.huion.com

28 / 48

GT2702

[1] Full Area:

The entire active area of the pen display will be mapped to the monitor. This is the default setting.

[2] Screen Ratio:

The ratio of the active area of the pen display corresponds to the ratio of the monitor connected to the pen display. For example, if you select "Screen Ratio" and draw a circle on the pen display, the circle will maintain its original shape on the monitor as well. Note that some features of the pen display may not work in Screen Ratio mode. However, if the "Screen Ratio" option is not selected, the drawn graphics may become distorted. For example, if you draw a circle, it may turn into an oval on the monitor. To ensure optimal display and workspace utilization, it is recommended to select the "Screen Ratio" option when drawing or performing precise operations.

www.huion.com

29 / 48

GT2702

[3] Custom Area:

1 Enter coordinate values.

2 Users can customize the workspace of the pen display by modifying the contours of a smaller rectangle. Users can also drag two blue rectangles to select the active areas of the digital pen on the screen and on the pen display (see Figures 1 and 2).

Figure 1

www.huion.com

30 / 48

GT2702

Figure 2

6.3.2. Rotating the Workspace

Change the orientation of the pen display to accommodate left or right-handed use. You can rotate the pen display by 0°, 90°, 180°, or 270°.

www.huion.com

31 / 48

GT2702

Image 1

Figure 2

6.4. Virtual Keyboard

The virtual keyboard is a highly configurable interactive on-screen tool that supports text

input and command execution using a mouse or digital pen. You can create and save 20 keyboard layouts, each allowing customization of the name, size, transparency, and key functions to meet individual needs.

①

②

③

④

⑤

⑥

6.4.1. Creating/Removing a Virtual Keyboard

① Click “+” to create a virtual keyboard.

② Select the desired type of keyboard from the available options: radial keyboard, rectangular keyboard, horizontal list keyboard, and vertical list keyboard.

③ Turn on the “Virtual Keyboard” switch to activate the virtual keyboard on the desktop and start using it.

④ Select the keyboard you want to remove.

⑤ Click the delete icon.

www.huion.com

33 / 48

GT2702

⑥ A confirmation dialog will appear. Click “OK” to remove the selected keyboard.

6.4.2. Enabling the Virtual Keyboard

Once enabled, the virtual keyboard appears on the desktop and is set to disappear after a single use. You can click the pin button in the upper right corner to keep the keyboard always visible. Press and hold any area of the virtual keyboard except the buttons to move it.

6.4.3. Name

You can change the name of the virtual keyboard in the name input field. The default name is the type of keyboard, and the name cannot be empty.

www.huion.com

34 / 48

GT2702

6.4.4. Size

You can move the slider or click on the slider bar to adjust the size of the virtual keyboard according to your needs. When adjusting the size of a virtual keyboard that is not enabled,

the corresponding keyboard will automatically open and adjust its size. It will then automatically close after 3 seconds from the end of the adjustment.

6.4.5. Transparency

To avoid obstructing the view with the virtual keyboard, you can adjust its transparency as needed by moving the slider or clicking on the slider bar. When adjusting the transparency of a virtual keyboard that is not enabled, the corresponding keyboard will automatically open and adjust its transparency. It will then automatically close after 3 seconds from the end of the adjustment.

6.4.6. Key Settings

Click the key of the Virtual Keyboard to set the corresponding key value.

www.huion.com

35 / 48

GT2702

The functions of the Virtual Keyboard keys can be set as:

Click to change the name of the pressed key. The new name will be highlighted along with the key value.

Key: Click the input field and enter the correct key combination to create a shortcut.

Text: Display predefined text up to 500 words.

Tools: Select Switch Screen or Switch Brush. You can assign the following functions to the keys: Previous Track, Next Track, Play/Pause, Increase Volume, Decrease Volume, and Mute.

Show/Hide: Show or hide driver settings and key values.

Enter the URL of the application, file, or website, or click "Browse" to select a file, and then click "OK". After completing the settings, press the key to open the corresponding file. No Function When no option is selected, the key does not perform any function when pressed.

Note: The functionality of the features presented in the table below depends on the connected device. This table may change without notice. www.huion.com

36 / 48

GT2702

6.5. Digital Pen

Users can configure pen functions in this interface, including assigning functions to buttons, adjusting pressure sensitivity, and testing pressure sensitivity. ④

② ⑤

①

③

6.5.1. Switching Digital Pen

Paired digital pen models are displayed on the navigation bar, allowing for their separate configuration. The system automatically recognizes the connected digital pen and applies the appropriate settings for it. When switching between different digital pens, the system will automatically switch to the settings interface for the corresponding pen. Hovering the cursor over the digital pen icon will display its name. Clicking the "x" symbol in the upper left corner of the digital pen icon will remove the corresponding digital pen settings. www.huion.com

37 / 48

GT2702

6.5.2. Press Key

This digital pen can be used to interact with the device, including drawing, writing, moving files, and activating the functions of the pen's press keys. Press key functions can be configured as: Click to rename the press key. The newly entered name will be displayed along with the key value. Keyboard key Click in the input field and enter the correct key combination to create a shortcut. Text Display defined text up to 500 words. Select Switch screen or Switch brush. Tools You can assign the following functions to press keys: Previous track, Next track, Play/Pause, Increase volume, Decrease volume, and Mute. Show/Hide Show/hide driver settings and press key values. Enter the URL of the application, file, or website, or click the "Browse" button to select a file, and then click "OK". After completing the configuration, www.huion.com

38 / 48

GT2702

press the key to open the corresponding file. Move the slider to set the desired precision level. Higher precision results in a smaller precision mode window. Mode After pressing this shortcut key, the precision mode window will appear at the cursor's location, and the working area of the pen tablet or pen display will be mirrored in this window. Press the shortcut key again to exit precision mode. This function allows you to scroll and pan the document or item by moving the pen tip up and down or left and right. After selecting Panning/Scrolling, a scrolling speed adjustment window will appear. Move the slider to your preferred scrolling speed. Virtual Select this option to assign a shortcut key to invoke the corresponding function of the Virtual Keyboard. Click here to learn more about the Virtual Keyboard. Enter the URL of the application, file, or website, or click "Browse" to select a file, and then click "OK". After completing the configuration, press the key to open the corresponding file. None After selecting the None option, pressing the key will not invoke any

function. Note: The functionality of the features presented in the table below depends on the connected device. This table may change without notice.

6.5.3. Enable Windows Ink

The Microsoft Windows system offers extensive support for pen input. When the "Enable Windows Ink" option is checked, pen functions are supported in software such as Microsoft Office, Windows Whiteboard, Adobe Photoshop CC, SketchBook 6, etc. Note: macOS and Linux systems do not support this function.

6.5.4. Pressure Sensitivity Adjustment

Users can adjust the pressure sensitivity level by moving the slider in the Pressure Sensitivity Adjustment field according to their usage habits. Users can also check five options from soft to hard on the right side of the field to find the appropriate pressure sensitivity level for themselves. Click the reset button in the upper right corner to restore the default pressure sensitivity. ① To determine the force required to trigger a click or feel pressure with the pen. ②③ You can change the slope of the pressure sensitivity response curve. Draw lines in the pressure test field with the pen, and the bar on the right will simultaneously show the changes in pressure on the pen tip.

Click the "Delete" button above to remove lines, reset the pressure sensitivity level, and test it until the correct sensitivity level is found. A steep curve indicates a more sensitive response.

6.5.5. Pressure Test After modifying the pressure curve or adjusting the maximum pressure force, you can observe the relationship between the applied pressure and the resulting effect in real-time by pressing the pen tip in the pressure test area. The bar chart on the right displays pressure changes in real-time. Clicking the "Clear" button at the top of the pressure test area removes the drawn traces and starts the test again. This feature allows for intuitive adjustment and testing of the digital pen's pressure sensitivity settings, ensuring they align with your usage preferences.

6.5.6. Advanced Configuration

In the Advanced Configuration, you can adjust the maximum pressure force. The lower the maximum force, the less pressure is needed to achieve maximum pressure; the default setting is the hardest.

www.huion.com 41 / 48 GT2702 7. OSD Menu Controlled by Pen Press and hold the power button for 3 seconds to bring up the OSD menu, then use the digital pen

to adjust the on-screen settings. Display Resolution Finish Current Signal Source Current Color Space Adjustment Settings General Settings Scene Mode Color Temperature Color Gamut Color Correction Gamma

www.huion.com 42 / 48 GT2702 7.1. Scene Mode Click the sun icon to adjust brightness. In the upper left corner of the interface, there are four modes to choose from: "StandardMode," "GameMode," "MovieMode," and "USER" mode. In the upper right corner, there are options for "Brightness," "Contrast," and "Saturation." When "StandardMode," "GameMode," or "MovieMode" is selected, only the third slider is

highlighted in blue, and the user can move it to adjust saturation. When "USER" mode is selected, all three sliders are highlighted in blue, and the user can adjust brightness, contrast, and saturation by dragging them. www.huion.com 43 / 48 GT2702 7.2. Color Temperature Settings In the upper left corner, there are three standard color temperatures ("6500K," "7500K," and "9300K") and a configurable "USER" mode. In the upper right corner, the RGB color values are displayed: "R (Red)," "G (Green)," and "B (Blue)." If "6500K," "7500K," or "9300K" is selected, all three sliders will be dimmed, and users will not be able to adjust "R (Red)," "G (Green)," or "B (Blue)." When "USER" mode is selected, all three sliders will be blue, and users can adjust "R (Red)," "G (Green)," and "B (Blue)" accordingly by moving them. www.huion.com 44 / 48 GT2702 7.3. Color Gamut Settings The interface displays the following color space options: "Native," "sRGB," "Display P3," "Black & White," "Adobe RGB," "DCI-P3," and "USER." Note: In the Native color space, values in the "Scene Mode" adjustment interface and in the "Color Temperature" adjustment interface can be freely adjusted or selected. To maintain color gamut compliance, brightness adjustment is limited to "USER" mode when using the sRGB, Display P3, Black & White, Adobe RGB, or DCI-P3 color spaces. www.huion.com 45 / 48 GT2702 USER Color Space: Create and save your own color profiles effortlessly using the G1 GTCOLOR calibrator along with the GTCOLOR calibration software. Details can be found in the G1 GTCOLOR calibrator user manual and in the software download instructions. www.huion.com 46 / 48 GT2702 7.4. Gamma Correction The gamma value is set in specific color spaces (e.g., 2.2 for sRGB/Adobe RGB/Display P3, 2.6 for DCI-P3). Custom gamma adjustment is available in Native and Black & White modes, allowing optimization in various scenarios. 7.5. General Settings ①USB-C/HDMI/DP: Connect using a USB-C/HDMI/DP cable. ②FULL: Change the display area to full screen. ③4:3: Change the aspect ratio of the displayed area to 4:3. ④Reset: All OSD menu settings will be restored to default values. www.huion.com 47 / 48 GT2702 8. Troubleshooting Issues Solutions It is possible that other drivers were installed or graphics software was running during the driver installation. Please uninstall all drivers, remove graphics software, and then reinstall the Huion driver. It is recommended to restart the computer after the installation is complete. The pen tablet does not detect pen pressure while the cursor may be moving. Additionally, if the application is incompatible with the driver or does not support pressure sensitivity, it will not be available in that application.

1. Make sure you are using the pen originally included with the tablet. The digital pen does not work. 2. Ensure that the driver has been installed correctly. 1. Make sure you are using the pen originally included with the tablet. The pressed key does not work. 2. Ensure that the

driver has been installed correctly. Please do not place the digital pen on the working area of the pen display when not in use; otherwise, the computer will not be able to enter sleep mode. The pressed keys of the digital pen will not work if the vertical distance between the pen tip and the tablet exceeds 10 mm. If the vertical distance is within 10 mm and the pressed keys of the pen still do not work, please check if the driver is functioning correctly and if it has properly assigned functions to both keys. If the keys still do not work, it is possible that the pen is damaged. In this case, please contact our service department, provided that the pen is under warranty. The computer does not recognize the pen display. Please check if the USB port on the computer is functioning correctly. If not, please try another USB port. Please restart the computer or the driver; ensure that the USB port and cable are working correctly; disconnect the USB cable and reconnect it; try another USB port; download and reinstall the latest driver; a message "Device disconnected" appeared on the screen. Please add the driver to the whitelist on macOS devices. If the problem is not resolved, please click FAQ for additional solutions or email us at (service@huion.com).

www.huion.com

48 / 48

Warnings and Safety Information

All information regarding the operation of the device can be found in the user manual. Before you start using it, familiarize yourself with its content and follow the guidelines provided. Also, review the following information before use:

Usage Warnings

1. Screen Safety:

- Tablet screens are larger and more prone to mechanical damage. Use a case with corner protection and a film or tempered glass.
- Avoid excessive pressure on the screen, especially when using styluses or accessories.

2. Battery and Charging:

- The tablet, like a smartphone, should be charged using original chargers. Avoid using the tablet while charging to prevent overheating.
- For tablets with larger screens, battery life may be shorter – use power-saving modes if available.

3. Waterproofing and Protection:

- If the tablet is waterproof, follow the manufacturer's guidelines regarding depth and immersion time. Remember that waterproofing does not mean resistance to saltwater or detergents.
- Avoid using waterproof tablets in harsh conditions, such as under running water, unless the manufacturer recommends it.

4. Using 5G:

- Tablets equipped with 5G support may significantly increase battery consumption during intensive mobile data use.
- In areas with weak 5G coverage, it is recommended to use Wi-Fi to optimize device performance.

5. Child Safety and Privacy:

- Tablets, especially those used by children, should be secured with parental controls. Enable appropriate locks to restrict access to applications, online purchases, and age-inappropriate content.

Information on Proper Use

1. Cameras and Video:

- Tablets with advanced cameras offer features such as wide-angle photos or 4K recording. Use them according to the manufacturer's instructions for best results.
- Remember that tablets cannot replace professional cameras – their main advantages are convenience and functionality.

2. Biometric and Data Security:

- Tablets equipped with biometric features, such as facial recognition or fingerprint scanning, should be configured to protect the device from unauthorized access.
- Regularly update the operating system to secure the device against potential threats, such as malware.

3. Maintenance and Storage:

- Tablets are more susceptible to mechanical damage than smartphones. Store the device in a protective case, especially during transport.
- Avoid storing the tablet in high humidity or extreme temperature conditions.

4. Accessories and Extended Functionality:

- Take advantage of the possibilities to extend the functionality of the tablet by using dedicated accessories such as keyboards, styluses, mounts, or wireless chargers.

Additional precautions

●Environmental protection:

- Used batteries and devices must be disposed of in accordance with local regulations regarding electrical waste. Return them to an e-waste collection point.
- Choose energy-saving modes of operation for the device (e.g., battery saver mode) to reduce energy consumption.

●Usage efficiency:

- Turn off the device when not in use for an extended period to save battery.
- Use original accessories, such as headphones or styluses, to ensure compatibility and full utilization of the device's features.

Environmental protection

Used electronic equipment marked in accordance with the European Union directive must not be placed together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The collection system for used equipment complies with locally applicable environmental protection regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, waste management facility, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning issues related to user safety, health protection, and environmental protection, specifying hazards that should be detected and eliminated. This document is a translation of the original user manual created by the manufacturer. Detailed information about the distributor/manufacturer's warranty conditions is available on the website <https://serwis.innpro.pl/gwarancja>

The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. In the absence of information about necessary periodic or service maintenance actions in the user manual, the user should regularly, at least once a week, assess the physical condition of the product against that of a physically new product. If any deviation is detected or noted, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detecting a state of deviation may lead to permanent damage to the product. The guarantor is not responsible for damages resulting from neglect.

Importer:

INNPRO Robert Błędowski sp. z o.o.

Manufacturer:

ul. Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

hurt@innpro.pl

www.innpro.pl

Shenzhen Huion Trend Technology Co., Ltd.

Park, Keji 1st Road, Tangtou Community,

Bao'an District Bld.1 Shiyuan Street Fl.1, 518000

Shenzhen, China

katherine@huion.cn

Representative in the EU:

Dilectro Spółka z Ograniczoną Odpowiedzialnością

ul. Brukselska 4

03-973 Warsaw, Poland

rafal.pacula@dilectro.pl

Charging capabilities of radio devices and compatible chargers

5-10

Safety measures

Before starting to charge, check if the device contacts are clean. Never leave the device unattended while in use and charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high temperatures. Charge the device in a dry and well-ventilated area away from flammable materials, maintaining a minimum space of 1m from other objects. Never cover the device while charging. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and certification. Take care of your property; the device is equipped with cells that are difficult to extinguish, so have a fire blanket on hand.

LI-ION Battery

The device is equipped with a LI-ION (lithium-ion) battery, which ages over time and usage due to its physical and chemical structure. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from the declared offer and this is not a defect of the device but a characteristic of the product. To maintain maximum battery life, it is not recommended to discharge it below 3.18V or 15% of total capacity. Lower values, such as 2.5V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months.

Store the battery and device in a dry place, away from sunlight and negative temperatures.

LI-PO Battery The device is equipped with a LI PO (lithium-polymer) battery, which due to its physical and chemical structure ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the device but a characteristic of the product. To maintain maximum battery life, it is not recommended to discharge it below 3.5V or 5% of total capacity. Lower values, such as 3.2V

for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. Product Battery Specifications Feature Value Battery Category Portable Battery Battery Type Portable lithium-ion batteries (Li-Ion) Contains Cadmium/Lead (>0.002% Cd, >0.004% Pb) No Net Weight (kg) 0.01746 Capacity (mAh) 950 Power (kWh) 0.003515