

Ανταλλακτικές λεπίδες για τη γκιλοτίνα LIENE του εκτυπωτή PixCut S1

Liene · EAN 6971398602319

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Replaceable blades for the guillotine

LIENE for the PixCut S1 printer

Replace the blade

Warning:

- * The blade is a consumable item, and its cutting quality may deteriorate after some time of use.
 - * When the cutting quality is not as good as before or when the blade is damaged, it is recommended to replace it with a new one.
 - * The blade is sharp. Exercise extreme caution. This product is intended for adults only.
 - * The blade is sharp; handle it carefully! It is recommended to hold the cylindrical part and avoid touching the upper and lower parts of the blade.
 - * The blade is sharp. When replacing the blade, do not touch its tip to avoid cuts.
 - * The cart moves left and right. Do not touch it while in motion to avoid pinching.
1. Remove the protective cover. 2. Open the blade clamp, remove the used blade, and insert a new one.
- *

3. Firmly close the blade clamp. 4. Close the protective cover.

Precautions

- Always disconnect the device from the power supply before replacing the blade.
- The blades are very sharp and should be handled with care and utmost diligence.
- To avoid injury, prevent the blade from coming into contact with hands and body.
- The blade is already installed. It easily cuts complex shapes!
- Blades and other small parts pose a choking hazard and should be kept out of reach of children. The device is intended for use by adults only.

Manufacturer: Hannto Technology Co., Ltd.

Address: Room 704, Building 1, No. 88, Shengrong Road, Pudong, Shanghai, China

Representative in the EU: Global E-Commerce Experts Europe BV

Rijnlanderweg 766 Unit H, 2132 NM Hoofddorp, Netherlands

rp@globalecommexperts.com

Importer: INNPRO Robert Błędowski Sp. z o.o.

ul. Rudzka 65c

44-200 Rybnik, Poland

www.innpro.pl