

Προβολέας Magcubic HY310

Magcubic · EAN 0757047110499

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Smart Projector

HY310

※Quick installation guide※

Warning

Please read this manual carefully before use and keep it for future reference.

1. The projector is not dustproof or waterproof.
2. To reduce the risk of fire and electric shock, do not expose the projector to rain or mist.
3. Please use only the original power supply. The projector should operate at the specified nominal power supply.
4. Do not look directly into the lens while the projector is in operation, as the strong light may cause blindness and mild discomfort. Children should use the projector under adult supervision.
5. Do not cover the projector's ventilation openings. Overheating shortens the projector's lifespan and may pose a hazard.
6. Regularly clean the projector's ventilation openings, as dust may cause cooling system failure.
7. Do not use the projector in oily, humid, dusty, or smoky environments. Oils and chemicals may cause damage.
8. Please handle the device carefully during daily use.
9. Please disconnect the power supply if the projector will not be used for an extended period.
10. Unauthorized persons are prohibited from disassembling the projector for testing and maintenance.

Construction Description

This manual is for informational purposes only. It may change without prior notice. Hotack reserves the right to final interpretation.

Lens

TURN

Air inlet

Speaker

USB

POWER ON/OFF

Ventilation

BT Air Remote

MUTE ON/OFF

DIRECTIONS

OK

BT AIR REMOTE

MENU

BACK SWITCH TO

MOUSE CONTROL

ELECTRONIC

VOLUME +/-

FOCUS

HOME

Mouse Mode Calibration

After connecting the remote control to Bluetooth, simultaneously press and hold the "OK" and "HOME" buttons on the remote for 2 seconds. During this time, the indicator light will remain on. Then place the remote flat on the desk surface. After leaving it still for 5 seconds, the light will turn off, indicating successful mouse mode calibration.

Pairing the Bluetooth Remote

Note: Bluetooth remote pairing interface,

Press the "Voice Input" button to start the pairing guide. Select your language.

App Store

In the App Store, applications can be installed with one click and used immediately after installation. Our company also offers applications on the market, allowing users to easily and conveniently acquire and use them.

Settings

Go to projection settings, network settings, Bluetooth, app management, language, date and time, other settings, and system information.

Projection Settings

Settings – projector settings, go to configure projection mode, display settings, installation mode, digital scaling, automatic keystone correction, automatic focus adjustment, manual keystone correction. Manual Keystone Correction.

Network Settings

Settings – network settings – WIFI settings, WIFI "ON", select the target WIFI identifier and enter the password to connect to the internet.

BT Settings

Settings – BT settings, BT "ON", click Refresh Devices and select the target device for pairing.

Language Settings

Settings - Language settings, enter to configure the language and select the input method.

Date and Time Settings

Settings - Date and time settings, enter to set the date, time, and select the 24-hour format.

Other Settings

Settings - Other settings, enter to configure button sound, screensaver, auto power off, and restore factory settings.

Screensaver

Settings - Other settings - Screensaver, set the screensaver time (the projector will enter screensaver mode after the set idle or playback time), the screensaver mode can be turned off by pressing the power button.

System Information

Settings - System Information, enter to check the user interface version, resolution, RAM, and storage space.

Signal

After connecting the projector to another output device, switch to HDMI or Audio/Video.

Wireless Screen

Ensure that Android devices (phone, tablet, etc.) are on the same local wireless LAN as these devices.

Operations on devices:

Home screen → My apps → ScreenCast → Enable ScreenCast service → Enable phone screen mirroring → Connection.

Safety Instructions

- Please pay attention to important information regarding the operation and maintenance of the projector. Carefully read this information to avoid issues.

Following safety instructions will increase the projector's lifespan.

- Please consult qualified personnel regarding installation and repairs and do not use damaged cables, accessories, and other peripheral devices.

- The projector should be kept away from flammable materials, explosives, and strong sources of electromagnetic interference (e.g., large radar stations, power plants, transformer stations), etc.
- Avoid strong ambient lighting, especially direct sunlight, etc.
- Do not cover the projector's ventilation openings.
- Use only the original power supply.
- Ensure proper ventilation and make sure that the ventilation openings are not covered to prevent the projector from overheating.
- Do not look directly into the lens while the projector is in operation, as the strong light can blind and cause mild discomfort in the eyes.
- Do not bend or pull the power cord.
- Do not place the power cord under the projector or under heavy objects.
- Do not cover the power cord with any soft materials.
- Do not heat the power cord.
- Avoid touching the power supply with wet hands.

Disclaimer

This manual contains general guidelines. The images and features presented in the manual may differ from the actual product. Our company continuously strives to improve product specifications. We reserve the right to change the features and interface described in this manual without prior notice. Please store the device appropriately. We are not responsible for any losses resulting from improper handling of software or hardware, repairs, or other causes. We are not liable for any claims from third parties. This manual has been thoroughly verified by a professional engineer; please understand if there are any inevitable omissions.

Note:

Do not look directly into the lens during projection to prevent eye damage caused by strong light. Children should use the projector only under adult supervision.

Thank you for your purchase! Do you need assistance? Please send an email with the product name to our Brand Support Team (support@magcubic.com) for better support, a quick response, and further assistance. This document is a translation of the original user manual created by the manufacturer. Detailed information about the distributor/manufacturer warranty conditions is available on the website <https://serwis.innpro.pl/gwarancja>.

The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. If there is no information about necessary periodic or service maintenance actions in the user manual, the user should regularly, at least once a week, assess the physical condition of the product against that of a physically new product. If any deviation is detected or identified, urgent maintenance (cleaning) or service actions should be taken. Failure to properly maintain (clean) and respond upon detecting a deviation may lead to permanent damage to the product. The warranty does not cover damages resulting from neglect.

Warnings and safety information

All information regarding the use of the product can be found in the user manual. Before using it, familiarize yourself with its content and follow the guidelines contained therein.

Also, review the following information before use:

Usage warnings

Risk of product damage:

- Ensure that the projector is connected to a power source that complies with the device's technical specifications. Using inappropriate adapters or cables may lead to device damage.
- Portable projection screens should be set up on a stable surface to prevent tipping over. The mount or stand must be properly installed according to the user manual.
- When transporting projectors or screens, avoid shocks and impacts that may damage the lens, projector matrix, or screen deployment mechanism.

Risk of overheating:

- Ensure that the projector is used in a location with adequate ventilation. Never cover the ventilation openings or use the device near flammable materials.
- Provide at least 20 cm of free space around the projector for proper cooling.

Hazard to children and unqualified users:

- Projectors emit an intense beam of light that can be dangerous to eyesight, especially for children. Ensure that children do not look directly into the lens while the device is in operation.
- Portable projection screens, especially larger models, can be unstable. Do not allow children to play near the stands or attempt to fold and unfold the screens, as this may lead to them tipping over and causing injuries.
- Projector accessories, such as remote controls, adapters, or connectors, contain small parts that may pose a choking hazard. Store these items out of reach of children.
- When using the projector or screen, ensure that power and

signal cables are properly routed and secured to prevent children from tripping or damaging the devices. • Projectors and screens are not toys. Never allow children to operate devices that require technical knowledge and caution without supervision. • Ensure that the projector is placed on a stable surface out of reach of children to prevent it from being accidentally knocked over. Compatibility: • Ensure that devices such as computers, laptops, or players are compatible with the standards supported by the projector (e.g., HDMI, USB-C, Wi-Fi). • Match the projector's resolution and aspect ratio to the projection screen (e.g., 16:9 or 4:3) to avoid distortion. Environmental hazard: • Used projectors, screens, and accessories should be disposed of properly at e-waste collection points, in accordance with local environmental protection regulations. Avoid throwing them in regular waste bins to prevent harmful effects on the environment. Information on proper usage Recommendations for use: • Use the projector in a dimly lit room for the best image quality. • Position the projector at the recommended distance from the screen. Details can be found in the product manual. • Adjust the brightness, contrast, and sharpness of the image according to lighting conditions and projection size. • Use screens according to the manufacturer's instructions, avoiding excessive tension on the material that may lead to damage. • Ensure that the projector has adequate space around the ventilation openings. Avoid covering these openings to prevent overheating. • Do not use the projector for extended periods without breaks. For intensive use, take breaks to allow the device to cool down. Maintenance and storage: • Regularly clean the projector lens and screen surface with a soft, dry cloth. Do not use chemicals that may damage the device. • Store projectors and screens in a dry, cool place. Protect them from moisture, dust, and direct sunlight. • When transporting, use dedicated covers or cases to protect the device from shocks and mechanical damage. Additional precautions User customization: • Choose a projector and screen tailored to your needs, such as business presentations, home cinema, or gaming. Pay attention to parameters such as brightness (lumens) and resolution. • If the projector supports smart features, such as streaming apps, ensure that your device is compatible with these features. Damage and service: • In case of damage, such as cracks in the casing, difficulties in displaying images, or power issues, immediately stop using the device and contact an authorized service center. • Do not attempt to repair the projector or screen yourself. Only authorized service will ensure compliance with warranty conditions. • Check the condition of cables, connectors, and the projector lamp. Replace them with original parts from the manufacturer if worn out. Declaration of conformity Products have been designed in accordance with the safety requirements specified in Regulation (EU) 2023/988. They meet the relevant technical standards, including those concerning electromagnetic compatibility

(EMC), electrical safety, and protection of users against mechanical and environmental hazards. SIMPLIFIED EU DECLARATION OF CONFORMITY SHENZHEN HANYING INTERNATIONAL IMPORT&EXPORT CO., LTD hereby declares that the type of radio equipment Projector Magcubic HY310 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following website:
<https://files.innpro.pl/magcubic> Manufacturer's address: Shuntai Zhongsheng Tower, Longguan Road, 13A10 0000 Shenzhen, cn Radio frequency: 2.4GHz (2400MHz - 2483.5MHz), 5GHz (5150-5350MHz - 5470-5725MHz) Maximum radio frequency power: <20dBm Environmental protection Used electronic equipment marked in accordance with the European Union directive must not be placed together with other municipal waste. It is subject to selective collection and recycling at designated points.

By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The waste equipment collection system complies with local environmental protection regulations regarding waste disposal. Detailed information on this topic can be obtained from the municipal office, waste management facility, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning issues related to user safety, health protection, and environmental protection, specifying hazards that should be detected and eliminated. Importer: INNPRO Robert Błędowski sp. z o.o. Rudzka 65c 44-200 Rybnik, Poland tel. +48 533 234 303 hurt@innpro.pl www.innpro.pl EU representative: E-CrossStu GmbH Mainzer Landstr. 69 60329 Frankfurt am Main, Germany E-CrossStu@web.de