


USER MANUAL

MERACH 2 IN 1 HYDRAULIC STEPPER



Questions or Concerns?

IMPORTANT!

Please read all details before use, and keep this user manual for future reference.

PLEASE FEEL FREE TO CONTACT US: Mon-Fri, 9:00 am-5:00 pm PST/PDT

Phone: +44 1942 946399 Mon-Fri 10am-7pm PST UK/DE/FR/ES/IT/NL/PT/PL

support.eu@merach.com

MODEL: MR-2403

WHO WE ARE

Our customers aren't just important; their health, fitness, and pure enjoyment for life is at the core of everything we do at MERACH. From innovative fitness research and cutting-edge product development, to our exceptional purchasing & after-sales service, we are our customers' life-long partner in crafting a better fitness future.

Through quality fat-burning & muscle-building fitness equipment such as our quality rowing machines and exercise bikes, plus our innovative MERACH APP, and digital courses, we give the opportunity and support to all to pursue their health and fitness goals and discover a new way of healthy living.

Welcome to MERACH



THANK YOU FOR YOUR PURCHASE!

(We hope you love your new Hydraulic Stepper as much as we do.)



Explore

Explore fitness courses

EU: merachfit.eu

DE: merachfit.de

FR: fr.merachfit.com

UK: uk.merachfit.com

(You can find the official website address based on your region. If your region is not listed below, please contact customer service.)



Enjoy

Enjoy weekly, featured courses

made exclusively by our in-house fitness instructor



Train

Unlock unlimited guided classes and never train alone again with **MERACH**.

WARRANTY REGISTRATION

Please register your warranty to keep yourself protected !



Email your item model to
register@merach.com

If you purchased the product from an authorized distributor, please contact them directly to register for the warranty.



SAFETY INSTRUCTIONS

Please keep this manual in a safe place for future reference.

- It is the responsibility of the stepper owner to inform all persons using the stepper of all precautions and to follow the instructions strictly.
- Please use the stepper indoors on a level surface, away from moisture and dust. Put a mat under the machine to help protect the floor and carpet. For safety reasons, please make sure to keep at least 2m of free space around the equipment.
- Before the product is used, please make sure that each screw and nut is locked tight.
- Children should not be near the equipment. Do not leave children unattended in the room where the stepper is placed.
- Please wear appropriate sportswear when using the machine, do not wear too loose clothing to avoid being involved in the machine.
- If you feel unwell while exercising, please stop exercising immediately.
- The stepper is indoor fitness equipment for home use, its maximum weight limit: 330 lbs.
- This equipment is only suitable for indoor and home use, not for outdoor use.
- Two or more people are not allowed to use this equipment at the same time.
- Please use it under the guidance of a doctor if you are not feeling well.
- Children, people with disabilities and pets should stay away from this equipment to avoid accidents.



WARNING

Please consult your physician before beginning any exercise. Especially important for individuals over the age of 35 or with existing health problems. Please read all instructions before using any equipment.



This symbol stands for "Conformité Européene", which means "Conformity with EU directives". With the CE-marking the manufacturer confirms that this product complies with applicable European directives and regulations.



This symbol stands for "UK Conformity Assessed", which means "Conformity with British Standards 11". With the UKCA-marking the manufacturer confirms that this product complies with applicable British Standards.

SIMPLIFIED EU DECLARATION OF CONFORMITY

- Hereby, Zhejiang Yulu Electronic Technology Co.,Ltd. declares that the fitness equipment MERACH MR-2403 is in compliance with Directive 2014/53/EU.
- The full text of the EU declaration of conformity is available at the following internet address: <https://merachfit.com/pages/declarations-of-conformity>

NOTES ON DISPOSAL



Packaging materials are raw materials and can be recycled. Separate the packaging materials correctly and dispose of them properly in the interest of the environment.

Your local administration can provide additional information.



Used devices do not belong in household waste!

Dispose of used devices properly! Doing so helps fulfill our responsibility to protect the environment. Your local administration can provide information on collection points and opening hours.



Batteries do not belong in household waste!

As the end user, you are legally required to return discharged batteries to a collection point. You can take your old batteries to the public collection points in your community, or you can take them to any place where batteries of that type are being sold.


Manufactured by:

Zhejiang Yulu Electronic Technology Co.,Ltd.
Room 805, 8th Floor, Xianfeng Technology Building, 298 Weiye Road, Binjiang District, Hangzhou, Zhejiang Province, China
yulu_mrk@merach.com

Imported by:

HANGZHOU JINGGE E-COMMERCE LTD
Room 1205, Xianfeng Technology Building, 298 Weiye Road, Puyan Subdistrict, Binjiang District, Hangzhou, Zhejiang Province, China
jingge_mrk@163.com

SPECIFICATION



Name:	MERACH 2 in 1 Hydraulic Stepper
Model:	MR-2403
Power:	AAA Battery * 1
Max Load:	330lbs/150kg
Net Weight:	21.8lbs/9.9 kg
Product Dimensions:	16.9*13.4*10.4inch/428*340*265 mm
Radio Frequency:	2.4GHz
Radio Frequency Band:	2402-2480MHz
Maximum RF Power:	5.40dBm

ASSEMBLY GUIDE




Tips

Scan QR code to watch installation video

Step 1:


- A. Put the attached batteries into the battery box of the Monitor(4).
- B. Connect the Induction Wire(a) with the Wire(b).
- C. Assemble the Monitor(4) back in the Main Frame(1) as shown in Figure.



Step 2:

A. Align the Foot Tube Cover(5) into the left and right foot tube respectively.


B. As shown in right Figure, open the latch of the Elastic Rope(2), connect it with the hook of Main Frame(1).



PRODUCT USAGE INSTRUCTIONS


Operation Mode

There are 2 operation modes can be switched through the L-shaped Adjustment knob (3), when the pedal height is the same.




Up and Down Mode :

When the L-shaped Adjustment Knob (3) is moved to the lower position, the machine can only move up and down (As shown in Figure P2).



Left and Right Mode:

When the L-shaped Adjustment Knob (3) is moved to the upper position, the machine can swing left and right (As shown in Figure P3).



Caution: Please make sure the pedals height is same when switch the operation mode.

Elastic Rope Usage

Elastic rope (2) is used together with the stepper machine. When the elastic rope is not needed, it can be removed and the stepper machine can be used alone.

MONITOR INSTRUCTIONS

COUNT	TIME	CAL	REPS/MIN
0—9999 TIMES	0:00—99:59 MIN:SEC	0—9999 KCAL	0—9999 TIMES/MIN

KEY FUNCTION

MODE/SELECT: To select the function you want. Hold the key for 4 seconds to have all function values reset(total reset).

OPERATION PROCEDURES

AUTO ON/OFF: The monitor will be automatically shut off if there is no signal coming in for 4 minutes. The monitor will be auto-powered when start exercise or press the key.

FUNTION


<1>.COUNT(CNT) Accumulate the steps while exercising.

<2>.TIMER(TMR) Auto-memorize the workout time while exercising.

<3>.CALORIES(CAL) Auto-memorize calories amount consumed while exercising.

<4>.REPS/MIN(CN/M) Display the steps per minute while exercising.

<5>.SCAN Automatically scan through each function between ①TIME ②CAL ③REPS/MIN




BATTERY INSTRUCTIONS

Step 1: As shown, take out the Monitor from the Main Frame.

Step 2: Replace the battery on the back of monitor, pay attention to the installation position as shown in the picture and install it correctly.

Step 3: Assemble the monitor back in the Main Frame.



Please note.

1. The final disposal of the battery should be done in accordance with laws and regulations.
2. Do not dispose of the battery in the fire.

MAINTENANCE & CARE

Stepper is a simple but powerful fitness equipment, without the need for power, you can easily exercise at home for the whole body. The following is the maintenance advice for the stepper.

Cleaning: After each use, wipe the surface of the stepper and all contact surfaces with a damp cloth to remove sweat and dust.

Lubrication: Periodically check if the stepper's drive system needs lubrication. You can use the appropriate lubricant on the pulley or crank to keep it running smoothly.
(Lubricant should be provided by yourself)

Adjustment: Make adjustments as needed, for example, adjust the angle at which you use the machine to ensure proper posture and maximum comfort.

Check bolts: Periodically check all bolts and nuts for tightness. If they are found to be loose, they should be tightened immediately.

Check the parts: Periodically check the parts of the stepper for damage or wear, and replace them as needed.

Moisture: Store the stepper in a dry place to prevent moisture damage to the machine.

These suggestions will help you ensure that your stepper stays in good working condition and lengthens its life.

Please note: Each stepper may have slightly different maintenance requirements, so refer to your equipment's owner's manual or ask the manufacturer for advice on its specific maintenance requirements.

By following these maintenance steps, you can ensure your fitness equipment remains in excellent condition and prolong its life span for many workouts to come.

WARM-UP

Do stretches before exercising. Warm muscles are easier to stretch, so start with a 5-10 minute warm-up, then do some stretches shown below - 5 times, 10 seconds or more per leg. Do it again after the workout.

1. Stretch down

Bend your knees slightly, slowly bend your body forward, relax your back and shoulders, and try to touch your toes with your hands. Hold for 10-15 seconds, then relax. Repeat 3 times (see Figure 1).




2. Seated hamstring stretch

Sit with one leg straight. Bring the other leg in so that it is snug on the inside of the straightened leg. Try to touch your feet with your hand's toe. Hold for 10-15 seconds, then relax. Repeat 3 times for each leg (see Figure 2).




3. Calf and Achilles tendon stretch

Stand with both hands against the wall or a tree, put one foot behind another. Keep the back leg straight and your heel on the ground, lean toward a wall or a tree. Hold for 10-15 seconds, then relax. Repeat 3 times for each leg (see Figure 3).



4. Quadriceps stretch

Reach back with your right hand, grab your right foot and slowly pull it toward your hips until you feel the muscles in the front of your thigh tense. Hold for 10-15 seconds, then relax. Repeat 3 times for each leg (see Figure 4).



5. Sartorius (inner thigh muscle) stretch

Sit with your feet facing each other and your knees facing out. Grab your feet with both hands and pull toward your groin. Hold for 10-15 seconds, then relax. Repeat 3 times (see Figure 5).



WARRANTY INFORMATION

Product Name	MERACH 2 in 1 Hydraulic Stepper
Model	MR-2403
Default Warranty Period	12 Months
For your own reference, we strongly recommend that you record your order number and date of purchase.	
Date of Purchase	
Serial Number	

Terms & Policy

The MERACH products are premium in material, craftsmanship, and service. MERACH 1-year limited warranty is effective from the date of purchase. MERACH will replace defective products based on eligibility. Refunds are available to the original purchasers of our products within the first 30 days of purchase. This warranty extends only to personal use, doesn't apply to the commercial, rental, or any other uses for which the product is not intended for. There are no warranties other than the warranties expressly set forth with each product.

This warranty is non-transferable. MERACH is not responsible for any damages, losses or inconveniences caused by equipment's failure, user's negligence, user's abuse, or improper operation that does not follow the included user manual.

This warranty does not apply to the following situations:

- Damage due to abuse, accident, alteration or vandalism.
- Improper or inadequate maintenance.
- Damage in return transit.
- Unsupervised use by children under 18 years old.

MERACH and its subsidiaries are only responsible for damages caused by the intended use or as instructed in the user manual. Some states do not allow this exclusion or limitation of incidental or consequential losses, so the above disclaimer may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which may vary from state to state.

All expressed and implied warranties, including the warranty of merchantability, are limited to the period of the limited warranty.

Additional 12-month Warranty:

You can enjoy an additional 12-month warranty. Just active your warranty by sending the product's model name via **register@merach.com**, or log onto **merachfit.com/pages/warranty** and enter your order number (i.e. Amazon) within the first 14 days of purchase to register your new product for the extended warranty. If you are unable to provide the order number for your product, please type a short note in the order number field along with the date you received your product.

Defective Products & Returns:

Should your product prove defective within the specified warranty period, please contact the Customer Support via **support.eu@merach.com** with your invoice and order number. **DO NOT** dispose of your product before contacting us. Once our Customer Support team has approved your request, please return the product with a copy of your invoice and order number.

Customer Support

Your satisfaction is our goal! Should you encounter any issues or have any questions about your new product, feel free to contact our Customer Support Team via **support.eu@merach.com** or Phone Support:

 **+44 1942 946399 Mon-Fri 10am-7pm PST UK/DE/FR/ES/IT/NL/PT/PL**

Tiktok Shop Exclusive after-sales: **service@merach.com**

*** Please have your Order ID and serial number (usually on the equipment) ready before contacting Customer Support.**