


neakasa

Quick Start

MULTIFUNCTIONAL PET GROOMING SYSTEM P2 PRO

EN/ FR/ DE/ NL/ SV/
NO/ FI/ DA/ ES/ PT/ IT

— Package Includes



— Hose Storage Method





— Get Ready

Put the dust cup gently in the direction of the arrow.




— Connect the Accessory to the Main Unit Through the Hose

When using accessories, please pay attention to the edges of the accessories to avoid scratching your hands.




— Adjustment of Electric Clippers




Reduce hair retention length
Slide up (don't press the yellow self-locking button in the above figure)



Increase hair retention length
Slide down (press and hold the yellow self-locking button in the above figure)



— Use the Device




- OFF
- ✪ Eco mode
- ✪ Standard mode
- ✪ Boost mode

— Use of Accessories




Grooming Brush

It can clean the floating hair on pets and the garbage in the hair, and at the same time it has the function of lengthening the hair, making the hair more fluffy.




Cleaning Brush

It can clean the hair from pets or from people's clothes.



Rake

The parts between the teeth are designed to be edged to loosen hair knots so that brittle hair can be removed, allowing healthy hair to grow.
Note: Please exercise caution when using this tool, as the cutting edges are sharp and could cause skin scratches if too much force is applied.



Electric Clippers


It can shave your pet's hair and suck it into the dust cup to prevent it from falling elsewhere.
Note: Please be careful on the soft parts of the pet's skin and do not use excessive force to cause skin scratches.



Clipping Comb

According to different hair style needs choose. (optional use)


Note: The objects are scattered and small, please keep them properly placed when not in use.



Wind Cover

It is used to enhance the suction force when trimming hair.

Note: The objects are scattered and small, please keep them properly placed when not in use.







EN




Scan for tutorial video



— Clean HEPA



— Clean the Dust Cup





— Clean the Electric Clippers

1. Please retract the movable knife adjustment knob to the bottom before taking the knife.

2. Vacuum/clean debris from the blade and the clipper.




3. Drop some lubricant(not included) on the blade.



— Clean the Sponge Filter

1. Out the sponge.

2. And drain the water after washing.



3. Put it for at least 24 hours of drying treatment.

4. Be sure to install the sponge correctly.

