


Package Contents



Light Stand ×2



Filter ×4



LED Video Light ×2




User Manual ×1

Using the Product

1. Using the light stand:


- ① Loosen the center column lock then open the tripod legs. Tighten the lock when getting an ideal leg angle.



01

EN EN


Using the Product



- ② Loosen the ball head tilt lock and tilt the ball head. Tighten the lock when getting a needed angle.
- ③ Open the flip lock and stretch the center column. Fasten the flip lock when getting a desired height.

2. Using the LED video light:


- ① Install the LED video light on the stand and set it to the required angle.
- ② When replacing the filters, remove the existing one from the light and magnetically attach the new one in place.



02


1. Power On/Off

Connect the USB power port of the LED video light (input 5V/2A) to a charging adapter or another USB power source. The blue LED indicator will light up. Press the ON/OFF button to turn the panel light on or off.



2. Adjusting Brightness

When the light is on, press the "Up" or "Down" button as needed to gradually adjust the brightness (10 levels of brightness adjustment). Long press the "Up" or "Down" button for continuous adjustment.



Weight	0.177kg
Dimensions	149×103×17mm
Height (with Tripod Head)	135cm
Cable Length	2m
Rated Power	10W
Power Input	5V/2A
Number of LEDs	66
Max Illuminance (with Diffuser)	750lux@0.5m
Color Rendering Index (CRI)	95
Color Temperature	5600K/3200K

Notes

1. To protect your eyes, do not stare directly at the light when it is on.
2. Do not disassemble or repair the product by yourself. This will void the warranty.
3. Do not touch the product with wet hands to prevent damage to the electrical components.
4. Keep the product uncovered during use to ensure proper heat ventilation.
5. Power the product off when it is not in use.
6. Do not expose the product to sunlight for long periods of time.