

Oneisall διπλός αυτόματος διανομέας τροφής κατοικίδιων ζώων χωρίς WIFI

Oneisall · EAN 6934399225543

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Double Automatic Pet Food Dispenser

User Manual

Instructional Video oneisall Support

Thank you for choosing our brand's product! Before using the product, please read the user manual carefully. If any accessories are missing or if there are quality issues, please contact the distributor. Safety Precautions

1. Recommended for pets over 6 months old.
2. For indoor use only. Avoid direct sunlight. Keep away from fire.
3. Use the included adapter. Otherwise, the device may be damaged or may not work.
4. DO NOT immerse the main device in water.
5. To prevent the dispenser from being pushed by pets, we recommend using it against a wall.
6. Children should use the device under supervision.
7. Stop using the desiccant bag if it is found to be damaged.
8. Disconnect the power cord and remove the batteries from the bottom if you want to stop using the dispenser.

Contents of the Package

Food Dispenser x1 2 x Stainless Steel Bowl and Holder 1x Power Cord 1 x Desiccant with Adapter

1 x User Manual 1x Quick Start Guide 1 x Sponge 4x Support Feet 2 x Food Dispenser

Product Appearance

Cover Button Lid

Food Container

Desiccant Compartment

LED Display Container Switch

Battery Compartment

Food Dispenser Dial

Support Foot Stainless Steel Bowl

Bowl Holder

Type-C Port

LED Display Description

Feeding Schedule Manual Feeding

Setting Current Time Recording

Message

Dial for Setting

Current Time or Feeding Time Meal Serial Number, each

Serial Number indicates a different

Feeding Time or Portions. Lock/Unlock

Up to 6 meals can be set Battery Icon. The battery icon is displayed only daily. when using batteries as a power source.

Amount of food you want to dispense to your pet during this meal. Resetting the Device

1. The device will lock if not activated and left idle for 30 seconds.

2. Press and hold the dial for 3 seconds to unlock the device. Dispenser Assembly

Scan the QR code below for a detailed assembly video of the dispenser. Dispenser Assembly
Program Settings

Things to know before setting:

If the device is locked, press and hold the button for 3 seconds to unlock it. Rotate to select the menu and adjust the amount. Setting Current Time

1. Rotate the dial to select the TIME SET menu.

2. Press the button to enter the current time setting.

3. Rotate the dial to set hours and minutes. Press to confirm.

Tips:

You must confirm the number of hours and minutes separately. Setting the feeding schedule without entering the current time will result in inaccurate feeding, as time may elapse.

Feeding Schedule Settings

1. Rotate the dial to select the FEED PLAN menu.

2. Rotate the dial to select the device's serial number and press the dial to confirm.

3. Rotate the dial to set hours and minutes. Click to confirm.

4. Rotate the dial to set the portion number. Click to confirm.

5. Repeat steps 2-4 if you want to prepare the next meal.

6. To return to the main menu, DO NOT touch the dial and wait for 10 seconds.

Tips:

1. The number of PORTIONS displayed on the screen indicates the amount for each bowl.
2. It does not support delivering different portions to each bowl. Manual Feeding Setting

1. Rotate the dial to select the FEED menu.

2. Click to release 1 portion of food. Note:

When the FEED menu is flashing, press the dial multiple times within 1 second to release more portions. Recording Voice Message

1. Rotate the dial to the REC menu. Click to go to recording settings.
2. Press and hold the dial, speak into the microphone....
3. After finishing the recording, release the dial, and the device will automatically play the previous recording as a preview.
- 4.

You can repeat steps 1-3 to change the recording. Tips:

1. The message can be recorded within 10 seconds.
2. During the recording process, the dispenser displays a 10-second countdown. Resetting the dispenser

1. Turn the knob to select

2. Press and hold for 7 seconds to restore the device to factory settings. Tips:

After restoring factory settings, you will hear 2 beeps. LED Display Statement

1. When setting up the device, if no operation is performed within 10 seconds, the device will automatically return to standby mode. In standby mode, unlocked. Locked
3. When using only batteries, if not in use, the display will turn off within 30 seconds.
5. The battery icon appears only when the battery is the sole power source. The icon will blink when the battery is low.
6. The meal serial number will turn off after the scheduled plan is completed. It will light up again at 12:00. Desired amount of food

Note: The amount of each serving is not adjustable. Pet owners should adjust the number of servings based on their pet's daily meals and the appropriate amount per meal. The size of the pellets we used in our laboratory: 0.3 inches. Here are the data from our experiment:

Scoop Serving

This data is for reference only. You should test the appropriate amount for your pet based on the dry food used. Tips:

1. The PORTION number displayed indicates the amount for each bowl.
2. It does not support delivering different portions to each bowl. Here are the steps to follow:

1. In the steps below, let's assume both pets eat the same amount.
2. For example, scoops equal 6 servings, so scoops equal 3 servings.

scoops 6 servings

scoops 3 servings

3. Set the portion number to 3.

4. Measure the amount of pellets delivered. If the amount of pellets meets the demand, it means the setting is correct.

scoops

scoops

scoops

Cleaning

Scan the QR code below to watch a detailed cleaning video of the device.

Specification

Model: PFD-002

Product Size: 74x72x99 inches

Capacity: 20 scoops (47 lb dry food)

Serving Size: 6 servings=1/2 scoop=55 g

Material: ABS+304 stainless steel

Input: 5V DC/1A

Type of Food: Dry food with a diameter of less than 0.5 inches

Power Supply: Recommended cable/backup batteries

Battery Type: 4xAA batteries

Troubleshooting

Problem Solution

Check if the cable is properly connected. Device not working Do not use batteries, use another type C charging cable to check if the dispenser works. Disconnect the cable and use new batteries to check if it works. Replacement of desiccant Email us: support@oneisall.com

Knob not working Try pressing and holding the button for 3 seconds to unlock the device.

Make sure the diameter of the pellets is less than 0.5 inches. Food stuck or Check if the container and food outlet are dry. shows

Error Code E-01 Check if the food is dry and fresh. If the food gets stuck in the outlet, clean it. If you are using battery power, replace the batteries with new ones. LED display is When using batteries as the sole power source, the screen will turn off to save electricity.

off However, the device will function normally. Environmental Protection

Waste electrical and electronic equipment marked according to the European Union directive

must not be disposed of together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The waste collection system for used equipment complies with locally applicable environmental regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, cleaning facility, or store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning issues related to user safety, health protection, and environmental protection, identifying hazards that should be detected and eliminated.

This document is a translation of the original user manual created by the manufacturer. Detailed information about the distributor/manufacturer warranty conditions is available on the website <https://serwis.innpro.pl/gwarancja>. The product should be regularly maintained (cleaned) at the user's expense and responsibility, either by the user themselves or through specialized service points. In the absence of information regarding necessary periodic or service maintenance actions in the user manual, the user should regularly, at least once a week, assess the physical condition of the product against that of a physically new product. If any deviation is detected or identified, urgent maintenance (cleaning) or service actions should be taken. Failure to properly maintain (clean) and respond upon detecting a state of deviation may lead to permanent damage to the product. The warranty provider is not responsible for damages resulting from neglect. Importer: INNPRO Robert Błędowski sp. z o.o. Rudzka 65c 44-200 Rybnik, Poland tel. +48 533 234 303 hurt@innpro.pl www.innpro.pl

Safety precautions Before starting to charge, check if the device contacts are clean. Never leave the device unattended while in use and charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high temperatures. Charge the device in a dry and well-ventilated place away from flammable materials, maintaining a minimum distance of 1m from other objects. Never cover the device while charging. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and certification. Take care of your property; the device is equipped with cells that are difficult to extinguish, so have a fire blanket on hand.

LI-ION Battery The device is equipped with a LI ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the

device but a feature of the product. To maintain maximum battery life, it is not recommended to discharge it below 3.18V or 15% of total capacity. Lower values, such as 2.5V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. LI-PO Battery The device is equipped with a LI PO (lithium-polymer) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the device but a feature of the product. To maintain maximum battery life, it is not recommended to discharge it below 3.5V or 5% of total capacity. Lower values, such as 3.2V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. Manufacturer: NANBANQIU TECHNOLOGY CO., LIMITED Kin Tat Street Hang Wai Ind.Centre H3 Hongkong, China support@oneisall.com Responsible entity in the EU: Enbaoixin Germany Maternal and Infant Supplies GmBH Laubenhof 23 45326 Essen, Germany jasvigor2020@hmail.com Product battery specifications Feature Value Battery category Portable general-purpose battery Battery type Portable lithium batteries (other than button cells) Contains Cadmium/Lead (>0.002% Cd, >0.004% Pb) Net weight (kg) 95.1g Capacity (mAh) - Power (kWh) 18.5Wh