


F1-WM Cordless Pet Feeder with WiFi

Model: PF08



User Manual
ON-D174

Contents


Safety Warning	01
Product Overview	02
In the Package	03
Assemble the Feeder	04
Icon Introduction	06
Connect to APP	08
The Desired Amount of Kibbles	10
Troubleshooting	12
Warranty Information	13
GPSR Product Information	14

Safety Warning

1. Select a stable and firm location to install the feeder to avoid it from shaking or toppling over.
2. Ensure that the installation environment is dry and away from water sources and damp areas.
3. Before adding pet food, check if the food is suitable for feeding to avoid using deteriorated or unsuitable food.
4. Set an appropriate feeding amount and time, and do not overfeed to prevent pet obesity or indigestion.
5. Observe the pet's eating situation regularly and adjust in time if there is any abnormality.
6. Clean the feeder regularly to keep it clean and hygienic and prevent the growth of bacteria.
7. Pay attention to keeping the battery fully charged or the power connection normal.
8. These packaging bags may cause suffocation. Keep them away from children and pets.
9. Do not use the feeder when the pet cannot reach the food plate or has any physical disability.
10. Do not put your fingers into the food outlet or let your fingers touch the rotor.
11. Do not immerse the base part in water at any time, otherwise it may damage electronic components, such as the control panel.

01

Product Overview



02

In the Package




Specifications

Product Name:	F1-WM Cordless Pet Feeder with WiFi
Model:	PF08
Size:	12.83" * 7.17" * 11.81 inches (326 * 182 * 300mm)
Capacity:	5L
Rated Voltage/Current:	DC 5V $\approx$ 1A
Battery Type:	Built-in lithium-ion battery
Charging Time:	6 Hours
Battery Run Time:	100 Days
Battery Capacity:	5000 mAh
Wi-Fi Frequency:	2.4G Hz
FCC ID:	2BBAWPF0608
Material:	SUS 304 Stainless Steel+ ABS

03


Assemble the Feeder

1. Open the food tank, and take out the bowl and accessories.
2. Lift the front side of the machine. Insert the plastic bowl holder into the machine, press down and install it.
3. Lay the machine on its side, insert the power cord into the type-C part, and snap the cord into the wire slot.
4. Turn the power switch to the "on" position.



04

5. Fill the tank with pet dry food and connect the charging cord to the power supply.
Note:
Kibble size allowed: 2-18 mm/0.07-0.7 inch in diameter.
Do not use it for canned food or wet food.
6. Put the desiccant bag into the desiccant box and put the stainless steel bowl on the bowl holder.




05

Icon Introduction

Operating Guide	
Unlock the Feeder:	Press and hold the dial for 3 seconds
Menu Selection/Adjust Numbers:	Rotate the dial
Setting Confirmation:	Click the dial
Back to Previous Menu:	Double click on the dial

Icon Description	
Feed	Manual feeding. The maximum setting is 12 servings of cat food.
Time	Set the clock time of the feeder device.
Plan	Set the feeding plan for the feeder. The maximum setting is 10 plans.
Mic	When the icon is flashing, press and hold the button to record sound. Do Not support to record a calling message via APP currently.
Wifi 2.4G	In the case of flashing icon, the feeder can search for and connect to Wi-Fi.
Reset	Clear the device's feeding plan and restart the device.
Li-ion battery built in.	
When the battery power is low, the device emits a beeping alarm sound.	
Charging reminder for the device. The device is powered by an external charging cable.	

06




07

Connect to APP

1. Download and install the Oneisall APP from the app store.




2. Connect the feeder according to the instructions.



- Select the 2.4G Hz Wi-Fi network and enter the password.
- If your Wi-Fi is 5G Hz, please set it to 2.4G Hz first Common Router Settings.
- When connecting to the device, please make sure that the Bluetooth on your mobile phone is turned on.

08



09

The Desired Amount of Kibbles

Note:


The amount of every portion is not adjustable. Pet owners should adjust the number of portions based on their pet's daily meals and appropriate amount per meal. The size of the kibble we used in our lab: 0.7 inch. Here's the data from our experiment.

Cup	Portion	Gram
1/8	3	15
1/4	5	29
1/3	7	38
1/2	10	57
1	19	114

This data is for reference only. You need to test out the right amount for your pet, based on the dry food you used.

Here are the steps:


1. For example, 1/4 cup equals to 5 portions, so 1/8 cup would equal to 3 portions.



10

2. Set the portion number to 5.

3. Measure the delivered kibbles. If the kibbles are measured as the amount you need, it means this setting is OK.



4. Otherwise, adjust the portion number to let it get close to the desired amount.



11

Troubleshooting

Please attach your troubleshooting and order ID, contact us via email support@oneisall.com. We would help you solve the problem fast.

Problems	Solutions
The feeder can not work	Check if the power switch at the bottom of the device is set to the "on" position.
	Check if the cord is connected well.
Desiccant Replacement	Email us: support@oneisall.com
The dial does not work	Try to press and hold it for 3 seconds to unlock the feeder.
	Make sure the kibble size is less than 0.7 inch in diameter.
Food stuck	
	If the food stop in the outlet, clean it.

12

Warranty Information

Oneisall offers a standard 2-year warranty. If you have any issues with your Oneisall product, please do not hesitate to contact us. Be sure to include your proof of purchase, model number, and any relevant photos or videos in your message to expedite the process. Our Oneisall support team is available 7 days a week and will respond to your inquiry within 24 hours. Thank you for choosing Oneisall.

Please note that the Oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty also does not cover consumable parts such as blades, guards, filters, brushes, and similar items. These parts may require regular replacement or maintenance.

support@oneisall.com
+877-522-8578 (US) Mon-Fri 8am-5pm (PST)
www.oneisall.com



13

GPSR Product Information

UK REP
Name: APEX CE SPECIALISTS LIMITED
Add: 6f East Union Street, Manchester, England, M16 9AE
Contact: Wells
Tel: +441616371080
E-Mail: info@apex-ce.com

Product Name: F1-WM Cordless Pet Feeder with Wifi
Brand: Oneisall
Product Model: PF08
Input: 5V $\approx$ 1A

GPSR Manufacturer Information
Business Name: chuzhouguanyidianshishangwuyouxongongsi
Manufacturer Address: CN, 239200, anhui, chuzhou, laianxian, xianzhongjingluixu, taixinxiangzhangyuanlongdonglianyuan2403shi
Tel: +86 130 4980 3796
E-Mail: oneisallofficial@hotmail.com



14

Warnings and safety information
All information regarding the use of the product can be found in the user manual. Before using it, read its contents and follow the instructions contained therein. Also read the following information before use:

Warnings for use
Risk of product damage:
Only use the products for their intended purpose as described in the instructions for use. Regularly check the condition of the feed dispenser or bowl, especially the mechanical components such as lids, handles, feeding mechanisms or feed hoppers. In the event of visible damage, discontinue use and contact service.
Do not overload the feed or water tanks - adhere to the recommended capacities specified by the manufacturer.
Hazard to animals:
Make sure the food dispenser is suitable for the size, age and nutritional needs of the animal.
Regularly check the quality of the stored food - make sure it is fresh and stored in dry conditions to prevent spoilage.
Place the unit in a stable location that is easily accessible to your pet, but away from areas exposed to excessive sunlight, moisture or contact with other animals.
Danger to children:
Food dispensers are not toys. Keep them out of the reach of children to avoid accidental damage to the unit.
Do not allow children to operate the appliance without adult supervision, especially when filling the feed or maintaining the mechanisms.
Risks associated with electronic components:
Regularly check the condition of the power cables, batteries and electronic components. In the event of damage, discontinue use of the unit.
For electrically powered models, make sure the unit is connected to a stable power source. If the unit is powered by batteries, replace them in accordance with the operating instructions and only use batteries recommended by the manufacturer.
Information on correct use
Recommendations for use:
Before first use, read the instruction manual and ensure that all components, such as lids, dispensing mechanisms and feed hoppers, are correctly fitted.
Regularly fill the hopper with feed according to the manufacturer's recommendations, avoiding products that may cause blockages in the mechanisms.
For models with automatic functions, ensure that the feed dosing schedule is set correctly.

Maintenance and storage:
Store products in a dry and clean place, away from moisture and extreme temperatures. Clean dispensers and bowls regularly according to the manufacturer's instructions, using mild detergents and soft materials. Do not use harsh chemicals or tools that could damage the dispenser.
Replace consumable parts such as filters (if applicable) as recommended by the manufacturer.
Battery safety:
Use only batteries recommended by the manufacturer in battery-operated devices. Dispose of used batteries according to local environmental regulations.
If the device will not be used for a long period of time, remove the batteries to prevent leakage.
Additional precautions
Adaptation to the animal:
Observe your pet's reaction to the food dispenser or bowl - ensure that using the device does not cause stress or discomfort.
For pets with a tendency to overeat, set appropriate food portions or feeding schedules to prevent health problems.
Damage and servicing:
Any repairs to mechanical or electronic equipment should only be carried out at authorised service centres.
Do not modify the unit yourself, as this may affect its safety and functionality.
Declaration of conformity
The products have been designed in accordance with the safety requirements of Regulation (EU) 2023/988. They comply with the relevant technical standards, including safety in use, electromagnetic compatibility and durability of materials.

Any problem you have, please contact us:
support@oneisall.com



ON-D174