




ONIKUMA

CW905

English

1.Product sketch



1. Left button

2. Right button

3. Roller/Middle button

4. Forward

5. Backward

6. DPI+

7. DPI-

2.Product parameters

Default DPI:	800Green/1600Pink/2400Blue/3200Red/ 4800Cyan/6400Yellow
Light Color:	RGB
working Voltage:	5V
Interface:	USB
working Current:	Less than 100MA
Cable length:	About 1.5M
Weight:	Around 132g
Product dimension:	127X71X40mm

3.Product manual

- ① Adjustable Your DPI Speed: 6 Speed DPI Adjustment, up to 6400 DPI;
- ② RGB Light: 6 single color breathing light, each color represents different DPI. 800 DPI green breathing light, 1600 pink, 2400 blue, 3200 red, 4800 cyan, 6400 yellow.
- ③ 7 Buttons: Optical Gaming Mouse: Left/Right/Mid/Forward/Backward/DPI +/DPI-. Quick thumb function: fast forward or backward when browsing the web, forward or backward at the same folder window.
- ④ Light switch: press and hold the "Left" button, then simultaneously press "DPI-" button to switch;

Light switch: press and hold the "Roller/Middle "button, then simultaneously press "DPI+"button to switch;

- 5 Compatible System: Windows 98/ 2000/ ME/ NT / XP/ Win7/ Win 8/ Win 10/ Mac OS and other OS, plug & play.

4.Matters needing attention

incorrect use will damage the mouse, so please pay attention to the following usage points:

- 1.Avoid using the mouse on surfaces with low finish such as carpets, and rough wood.
- 2.Do not bump the mouse
- 3.Do not use the mouse under high temperature and strong light
- 4.Do not put the mouse in the liquid The mouse light is on.

合格证

检测员 Q8

执行标准：GB/T14471-2013



深圳市讴旋科技有限公司

Shenzhen Ouni Technology Co., Ltd .

深圳市龙华区民治街道民治大道1049号 吉盛楼 A1栋

Jisheng building, No.1049 Minzhi Road , Minzhi street

Longhua District , Shenzhen .

品牌名称 (Brand name) : ONIKUMA

电话/Tel: +86-755-23736285

Website: www.onikumagaming.com

Warnings and safety information

All information concerning the use of the products, can be found in the enclosed instruction manual. Before using the product, read its contents and follow the manufacturer's recommendations.

Also read the following information before use:

Warnings for use

Risk of damage to the device:

- Use the gaming mouse only for its intended purpose - for gaming, office work or other computer activities.
- In case of contact with liquid, immediately disconnect the device and dry it according to the manufacturer's instructions.
- Do not use damaged cables or batteries - they may cause a short circuit or damage to the device.

Hazard to the user:

- Use the mouse in the correct position, providing support for the wrist, especially for prolonged use. For vertical mice, make sure your hand remains in a natural position.
 - For models with RGB backlighting, do not look directly into intense light for long periods of time to protect your eyesight.
 - Make sure the cable of the wired mouse is not kinked or stretched, which can affect the precision of movements.
- Compatibility and interference risks:**
- Before connecting the mouse, check that the device is compatible with your computer's operating system and software.
 - For wireless models, make sure it is within the recommended operating range.

Information on correct use

Preparation and configuration:

- Before first use, install the software provided by the manufacturer to configure the button functions, DPI and backlight.
- For wireless mice, make sure the batteries are fully charged or replace them with new batteries if the device requires disposable batteries.
- For mouse-keyboard combinations, make sure both devices are paired correctly with the computer.

Safe use:

- Use the mouse on a suitable surface - preferably on a mousepad suitable for a gaming mouse to ensure precision of movement.
- If your mouse uses Bluetooth or Wi-Fi connectivity, regularly check that the connection is stable and there is no interference with operation.

Maintenance:

- Regularly remove dust and debris from the mouse, especially from the space between the buttons and the optical or laser sensor.
- For wired mice, make sure the cable is clean and untangled to prolong its life.

Additional precautions

- **Cleaning and maintenance:** Use a soft, dry cloth to clean the mouse or a slightly damp cloth for more difficult dirt. Avoid using chemicals that may damage the finish.
- **Batteries and power:** For wireless mice, use only batteries recommended by the manufacturer. Dispose of used batteries according to local environmental regulations.
- **Storage:** When you have finished using your wired mouse, disconnect it from your computer and store your wireless mouse in a dry, dust-free place.

Compliance Statement

The products have been designed in accordance with the safety requirements of Regulation (EU) 2023/988. They meet the requirements for electromagnetic compatibility (EMC), durability and safety of use.

Product Battery Specifications

Feature	Value
Battery Category	Portable battery
Battery Type	Portable lithium-polymer rechargeable batteries (Li-Po)
Contains Cadmium/Lead (>0.002% Cd, >0.004% Pb)	No
Battery weight net (kg)	12.2g
Rated capacity (mAh)	650mAh
Power (kWh)	2.405Wh