



ONIKUMA

Gaming keyboard

G55

— 使用说明书 —
user's manual

■ Mechanical Gaming Keyboard




■ Keyboard specifications

Model	G55	Number of buttons	61
Switch Type	mechanical keyboard	Button life	20 million times
Operation schedule	4.0±0.5MM	Workload	60g±10g
cable length	PVC3.5*1.5M	Keyboard size	290*101*40mm±5mm
Keyboard weight	380±10g	Operating Voltage	5V±0.5V
Working current	<180mA	Nterface Type	Type-C - USB
support system	Win2000、 Win XP、 Win7、 Win8、 Win10、 Win11、		
	Android, Mac, and other operating systems		

■ Installation steps

- 1.Turn on computer
- 2.Plug the G55 keyboard's USB connector into your computer's USB port （It is better to choose the USB port on the back of the case rather than the front.）
- 3.Wait for a while, and your keyboard will be read by the computer automatically without the need for additional drivers.

（NOTE: The G55 is a plug-and-play keyboard and does not require any drivers.）



■ LED backlight adjustment

FN+J}	Brightness enhancement	Light brightness adjustment
FN+{{	Brightness reduction	Light brightness adjustment
FN+;	Slow down	Lighting speed adjustment
FN+''	Speed up	Lighting speed adjustment
FN+	Lighting effect switching	Lighting effect cycle adjustment, a total of 12 groups of backlight modes
FN+back	Backlight switch	

■ Multimedia and features

FN+Y	Print Scr	FN+U	Scroll Lock
FN+I	Pause	FN+H	Insert
FN+J	Home	FN+K	Page Up
FN+N	DEL	FN+M	End
FN+,<	Page Down		
FN+Z	Previous track	FN+C	Next track
FN+X	Play / Pause	3FN+V	Stop

■ Keyboard operation and switching

FN+Enter	Arrow key conversion FN + Enter Press /? at the same time,、 Alt、 APP、 Ctrl			
	Directly output with arrow keys.No arrow keys needed, just repeat the last step.			
\?	↑	Alt	←	
APP	↓	Ctrl(right)	→	
FN+W	WAS D and arrow keys swap		FN+ESC	..~
FN+WIN	Lock WIN		FN+1=	F1~F12
FN+Space bar	Reset Restore keyboard to d efault state			

FN+Ctrl （Left）

Number keys and F area conversion

ESC	1	2	3	4	5	6	7	8	9	0	-	=
↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑
~	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12

Y	U	I	H	J	K	N	M	,<
↓	↓	↓	↓	↓	↓	↓	↓	↓
Print Scr	Scroll Lock	Pause	Insert	Home	Page Up	DEL	End	Page Down

Installation reminder

- 1.Connect the keyboard to an available Us port on your computer;If this is the first time you are using the peripheral, wait approximately 15 seconds for the generic driver to install.
- 2.When using the keyboard for the first time,WIN2000 and WIN XP systems will automatically identify and install the driver;Earlier operating systems may require installation of Microsoft's standard USB drivers.

Precautions

- 1.Keep the device dry. Keep it away from rain, moisture, and all types of liquids or condensation, which may contain minerals that can corrode electronic circuits.
- 2.Do not use this product with wet hands.
- 3.Do not use or store the device in dusty or dirty locations.
- 4.Do not store the device in a high temperature environment (this may damage the device).
- 5.Do not store the device in low temperature conditions (when the device returns to normal temperature, condensation may form inside it and may damage the device).
- 6.Do not drop, knock or vibrate the device (use may cause breakage).）。

Troubleshooting

If this doesn't work, follow these steps:

- Check the integrity of the connector;
- Check whether the connection with the computer is correct;
- Check the correctness of the computer settings
- Disconnect and reconnect the device; restart the computer.