



**ONIKUMA**  
**Gaming keyboard**  
**G83**

— —  
user's manual

## ■ Keyboard specifications

Number of keys: 83

Switch type: Gote pink linear axis

Key life: 50 million times

Operation stroke:  $2.0 \pm 0.5$ mm

Operation load:  $40 \pm 10$ gf

Cable length: PVC3.5\*1.8M

Keyboard size:  $336 \times 146.1 \times 37$ mm $\pm 5$ mm

Keyboard weight:  $950 \pm 10$ g

Working voltage:  $5V \pm 0.5V$

Battery capacity: 8000mAh

Charging time: 15H


Battery life: 40H

Working current:  $<200$ mA

Interface type: TYPE-C

Supported systems: Win10, Win11, Android,

Mac and other operating systems



## ■ Combination functions of keys


| Combination keys | Trigger function (Win mode)                                                             | Trigger function (Mac mode single press) |
|------------------|-----------------------------------------------------------------------------------------|------------------------------------------|
| FN+F1            |                                                                                         | Display brightness +                     |
| FN+F2            |                                                                                         | Display brightness -                     |
| FN+F3            |                                                                                         | Mission Control                          |
| FN+F4            |                                                                                         | Launchpad                                |
| FN+F5            | Mute                                                                                    |                                          |
| FN+F6            | Volume-                                                                                 |                                          |
| FN+F7            | Volume+                                                                                 | Previous song                            |
| FN+F8            | Calculator                                                                              | Play/Pause                               |
| FN+F9            | Play/Pause                                                                              | Next song                                |
| FN+F10           | Stop playing                                                                            | Mute                                     |
| FN+F11           | Previous song                                                                           | Volume-                                  |
| FN+F12           | Next song                                                                               | Volume+                                  |
| Fn+Tab+5         | 2.4G pairing                                                                            |                                          |
| FN+ 1- 4         | wireless channel                                                                        |                                          |
| FN+ 9            | Switch Win                                                                              |                                          |
| FN+0             | Switch Mac                                                                              |                                          |
| FN+Backspacs     | Battery query                                                                           |                                          |
| FN+Del           | Press for 3 seconds, all indicators flash white three times to restore factory settings |                                          |

## ■ Lighting control

1. Fn+Ins adjusts lighting effect, power-off memory state, Fn+PgUp adjusts color, Fn+PgDn backlight switch
2. Backlight frequency and brightness adjustment (white light)  
Fn+←, lighting mode frequency slows down, power-off memory state (reaches the slowest, all indicators flash to prompt)  
Fn+→, lighting mode frequency speeds up, power-off memory state (reaches the fastest, all indicators flash to prompt)  
Speed adjustment 5 levels, default 4 levels  
Fn+↑, increase brightness, power-off memory state (reaches the highest brightness, all indicators flash to prompt)  
Fn+↓, reduce brightness, power-off memory state (reaches the lowest brightness, all indicators flash to prompt)
3. Side light effect (does not support side light frequency and brightness adjustment)  
Fn+ — adjust lighting effect, power-off memory state, Fn+ = Color Switching

## ■ Installation Reminder

1. Connect the keyboard to an available USB port on the computer; if it is the first time to use the peripheral device, please wait for about 15 seconds to install the universal driver.
2. When the keyboard is used for the first time, WIN2000 and WIN XP systems will automatically recognize and install the driver; earlier versions of the operating system may require the installation of Microsoft's standard USB driver.



# **“Information to User”**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.