


ONIKUMA

HEADSET

X31

— User's Manual —



Product introduction

1. High-quality sound production unit offers high, medium and low audio experience;
2. Earmuff
3. Lightweight design, self-adjusting head beam design, the best game wearing experience;
4. High sensitivity microphone delivers more accurate, clear and smooth voice;
5. Volume control button
6. Microphone on-off button
7. 3.5MM international standard (CTIA) interface (left channel-right channel-ground and microphone)
8. USB interface for power supply for the LED lights
9. Used for single hole interface
10. Used for one_to_two tieline

Product parameters

Speaker size	50mm	Microphone impedance	≤2.2K Ω
Impedance	32Ω±15%	Directionality	omni-directional
Sensitivity	105± 3dB	Cable length	2.2±0.15M
Frequency range	20Hz-20KHz	LED working voltage	DC5V±5%
Microphone	6.0x5.0mm	Working current	≤180mA
Microphone sensitivity	- 43 ± 3dB	Headset jack	USB+3.5mm

Range of application and operating instructions

1. The headset is applicable to 3.5MM quadrupole single plug audio device such as laptop, tablet PC, mobile phone, etc. With the bisected adapter cable of 3.5mm interface, the 3.5mm dual plug of the computer can be used.
2. Generally, the cable end or microphone end is designed on the left-side, so wear the cable end or microphone end on the left ear when wearing headset.
3. When using the headset on computer, please make sure the headset microphone switch is turned on; then make sure the computer microphone switch is turned on. Please find the "speaker" icon in the computer taskbar, and double-click to enter the volume control for settings. And enter into the "voice" for settings on the "Control Panel".
4. Please make sure the headset volume adjustment button is at the minimum volume, and can be adjusted to the appropriate volume.
5. Please use the headset to enjoy the game
6. Support the 32-bit and 64-bit Win7 / Win8 / Win8.1 / Win10/XP.

Frequently asked questions

1. When playing music by headset , there is accompaniment but no singing?

A) The headset plug is quadrupolar single plug type. The international (CTIA) standard 3.5 mm interface: pin connection is left channel - right channel – ground wire – microphone, which is the most popular connection in the market and the largest application. If the international standard headset is connected to a non-international standard interface, there will arise the phenomenon of background sound only. If the audio device is non-international standard, the adapter cable is needed.

2. When playing music with headset, there is sound but the voice chatting can’t work?

A) When using the headset, please make sure that the tone control microphone switch of headset is turned on, and make sure that the microphone works normally;

B) The headset plug is quadrupolar, single plug type with the function of audio/voice combination, and is applicable to single-hole audio device. Please make sure that if your device fits the audio/voice combination interface;

C) The headset plug is quadrupolar, single plug type, while your device may be of tripolar interface.

D) With the bisected adapter cable of 3.5mm interface , you can use the 3.5mm dual plug (headphone and microphone jack) interface of the computer. You can enjoy beautiful music and voice chatting at the same time

3. When playing music with the headset, there arises the phenomenon of noise , small volume, unclear sound, or one side with sound and the other side without sound?

A) Please check if the plug is well inserted into the interface device;

B) The headset plug is quadrupolar, single plug type, while your device may be of tripolar interface.;

4. When using the headset, there is current sound?

A) Please check if the plug is well inserted into the interface device;

B) There are electrics of strong magnetic field at hand, please take away them (such as the mobile phone, fan ...);

C) Please check if the microphone boost of the computer microphone is turned on. Please open the control panel → sound→ record →level →microphone boost to adjust the microphone boost mode.

Matters needing attention

A) Please enjoy music at a moderate volume to prevent adverse effects on the hearing;

B) Please be careful to wear when driving or cycling so as not to affect safety;

C) Product specifications are subject to change without notice;

D) If disassemble the headset without authorization, we can not guarantee the quality.

Packing list

1) Gaming headset

2) Operating instructions

“Information to User”

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

ONIKUMA

Gaming keyboard

G32

— User's Manual—

Keyboard Specs

Number of keys: 104

Switch type: Membrane button

Button life: 8 million

Operating stroke:4+/-0.2

Operating load: 55±7g

Cable length: 1.35±0.3m

Keyboard size: 448*172*29m±1m

Keyboard weight: 530±10g

Working voltage: 5V±0.5V

Working current: <300mA

Port type: USB

Support system: Win98, Win2000, Win XP, Vista, Win7, Win8, Win10 operating system

- Multimedia and office functions


FN+F1	Media Player	FN+F2	Volume-
FN+F3	Volume+	FN+F4	Mute
FN+F5	Stop	FN+F6	Previous
FN+F7	Pause/Play	FN+F8	Next
FN+F9	Mail	FN+F10	Web/Home
FN+F11	Lock Key	FN+F12	Calculator

Lighting control

1. Light brightness control: F N+PGUP increases the brightness, FN+PGDN reduces the brightness, the default is the brightest.
2. Backlight breathing rate control: Press the "FN+Backlight" key to start the backlight breathing, the breathing rate is controlled by FN+"-"/FN+ "=", FN+ "-" reduces the frequency the period, FN+ "=" extends the frequency period, press "FN+" Backlight" key to exit or just press the "Backlight" key to turn off the backlight.

INSTALLATION

1. Connect the keyboard to the available USB port on your computer; if the peripherals are used for the first time wait approx.15 seconds to install the generic driver.
2. When the keyboard is used for the first time, WIN2000 and WIN XP systems will automatically recognize and install the driver; earlier versions of the operating system may need to install Microsoft's standard USB driver



TROUBLE SHOOTING

1.Keep the equipment dry. Keep away from Precipitation, humidity and all types of liquids or condensation may contain minerals that corrode electronic circuits.

2.Never use the product with wet hands.

3.Do not use or store the equipment in dusty or dirty areas.

4.Do not store the equipment under high temperature conditions(this may damage it).

5.Do not store the equipment under low temperature conditions(when it returns to normal temperature, condensation may form inside it which may damage the equipment).

6.Do not drop, knock or shake the equipment (use may result in breakage).

TROUBLE SHOOTING

In case of incorrect operation follow the steps below:

-Check the integrity of the connectors;

-Check the connection to the computer correctly;- Check the correctness of your computer settings;

-Disconnect and reconnect the equipment; restart the computer.

ONIKUMA


MOUSE

CW917

— User's Manual—

English

1.Product sketch



1. Left button
2. Right button
3. Middle Button
4. DPI Switch
5. Forward key
6. Back key

2.Product parameters

Default DPI:	1200/1800/2400/3600
Light Color:	Colorful scattered
working Voltage:	5V
Interface:	USB
working Current:	≤100MA
Cable length:	About 1.5M
Weight:	Around 120g
Product dimension:	126X67X40mm

3.Product manual

❶ Adjustable DPI speed: 4-speed DPI adjustment, up to 3600DPI;

❷ Compatible System: Windows 98/ 2000/ ME/ NT / XP/ Win7/ Win 8/ Win 10/ Mac OS and other OS, plug & play.

4.Matters needing attention

Incorrect use will damage the mouse, so please pay attention to the following usage points:

1.Avoid using the mouse on surfaces with low finish such as carpets, and rough wood.

2.Do not bump the mouse

3.Do not use the mouse under high temperature and strong light

4.Do not put the mouse in the liquid The mouse light is on.



