



Descriptions



1. Left ear
2. Right ear
3. Earphone indicator light
4. (MFB) touch button
5. Mic
6. Charging box digital tube
7. Type-c charging port
8. Dongle indicator light
9. Type-c
10. Dongle

Wearing

1. The correct way to wear
L is the left ear, and R is the right ear.
For an more comfortable audio
experience, please try on each size of
ear tips. Try wear the earphone correctly
so that the earphones are closely and
firmly seated in your ears.



Instructions

1. Charging the Product
 - a. Use a DC5V Type-C charger to charge the charging case. The charging indicator on the case will flash, and the fully charged indicator will display 100.
 - b. To charge the earbuds, place the earbuds in the charging case and close the lid. The earbuds will automatically charge. The ticker lights on both sides of the case will flash, and the fully charged indicator will turn off.
2. Connecting Both Earbuds to a Device
 - a. Open the charging case lid. Both earbuds will automatically power on and pair.
 - b. Refresh your phone's Wireless settings, find the TX612, and tap Connect.
3. Connecting a Single Earbud to a Device
 - a. If using one earbud alone, search for and pair the TX612 using the dual-ear pairing method. (If using the left earbud alone, remove the left earbud and wait about 10 seconds for the search to connect.)
4. Resetting the Earbuds (Resetting the Earbuds if the left and right earbuds are not paired or Wireless cannot find a device)
 - a. Quickly press the MFB button on each earbud four times. The earbuds are powered on, outside the charging case, and not connected to a phone. (Clear the Wireless pairing history. The earbuds will automatically power off after resetting.)

Function control

Power on	Long press the MFB button for 3 seconds
Power off	Long press the MFB button for 5 seconds
Pause/play music	Double-click the MFB button
Increase volume	Single-click the right ear MFB button
Decrease volume	Single-click the left ear MFB button
Previous song	Long press the left ear MFB button for 2 seconds
Next song	Long press the right ear MFB button for 2 seconds
Answer/end call	Double-click the MFB button
Reject call	Long press the MFB button for 2 seconds
Turn on voice mode	Triple-click the left ear MFB
To turn on/off the game mode	Triple-click the right ear MFB

Product parameters

Wireless version	5.4
Support audio formats	SBC、AAC
Working time	≥7H
Charging time (box)	<2H
Charging time (headphones)	<2H
Working distance	≥15m
Product Size	64.5X28.4X46.5mm