



ONIKUMA

**MT707**

## ■ Keyboard specifications

Number of keys: 81

Switch type: Customized linear axis-lubricated

Key life: 50 million times

Operation stroke:  $4.0 \pm 0.4$ mm

Operation load:  $45 \pm 5$ gf

Cable length: PVC3.5\*1.8M

Keyboard size: 332.8\*144.3\*45mm

Supported systems: Win10, Win11, Android,

Mac and other operating systems

Keyboard weight:  $740 \pm 5$ g

Working voltage:  $3.7V \pm 0.5V$

Battery capacity: 4000mAh

Charging time: 5H

Battery life: 20H

Working current:  $<200$ mA

Interface type: TYPE-C

## ■ Combination functions of keys

|     |   |                                                                    |                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----|---|--------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FN+ | Q | Short press to switch wireless 1,<br>long press wireless 1 pairing | After dialing BT, press FN+Q/W/E to enter wireless mode. Press and hold the FN+Q/W/E key combination for 3 seconds, the keyboard enters pairing mode, the blue/green/red indicator light flashes quickly, and the indicator light stays on for 3 seconds after connecting. After failing to find a paired device for 30 seconds, exit pairing mode, the light goes out, and the keyboard goes to sleep.       |
|     | W | Short press to switch wireless 2,<br>long press wireless 2 pairing |                                                                                                                                                                                                                                                                                                                                                                                                               |
|     | E | Short press to switch wireless 3,<br>long press wireless 3 pairing |                                                                                                                                                                                                                                                                                                                                                                                                               |
|     | R | Short press to switch 2.4G, long<br>press 2.4G pairing             | After the keyboard dials 2.4G, press FN+R to enter 2.4G mode, and then press the FN+R key combination for 3S to enter pairing mode, insert the receiver, the indicator light flashes quickly, and after pairing is successful, the pairing mode light stays on for 3S. After 30s of not finding a paired device, the light goes out when the keyboard exits the pairing mode, and the keyboard goes to sleep. |

**FN+**

| Combination key | WIN function                                                                                                     | MAC function<br>(single press trigger) | Description                                        |
|-----------------|------------------------------------------------------------------------------------------------------------------|----------------------------------------|----------------------------------------------------|
| F1              | This computer                                                                                                    | Screen brightness down                 | Toggle switch<br>selection<br>MAC/WIN              |
| F2              | Home                                                                                                             | Screen brightness up                   |                                                    |
| F3              | Calculator                                                                                                       | Multitasking controller                |                                                    |
| F4              | Email                                                                                                            | Program list                           |                                                    |
| F5              | Player                                                                                                           | None                                   |                                                    |
| F6              | Stop playing                                                                                                     | None                                   |                                                    |
| F7              | Previous song                                                                                                    | Previous song                          |                                                    |
| F8              | Play/Pause                                                                                                       | Play/Pause                             |                                                    |
| F9              | Next song                                                                                                        | Next song                              |                                                    |
| F10             | Mute                                                                                                             | Mute                                   |                                                    |
| F11             | Volume down                                                                                                      | Volume down                            |                                                    |
| F12             | Volume up                                                                                                        | Volume up                              |                                                    |
| DEL             | INS                                                                                                              | INS                                    |                                                    |
| PGUP            | PrtSc                                                                                                            | PrtSc                                  |                                                    |
| PGDN            | Pause                                                                                                            | Pause                                  |                                                    |
| ECS             | One-click access to web driver                                                                                   |                                        |                                                    |
| BAKSPACE        | One-click access to web driver                                                                                   |                                        | Keyboard backlight flashes three times to indicate |
| H               | Press and hold for 3 seconds to switch to ultra-low latency mode.<br>The red light on the H key flashes 3 times. |                                        |                                                    |

## ■ Lighting control

|     |                  |                                                                                            |                                                                                                                                                                                                                                                                                              |
|-----|------------------|--------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FN+ |                  | Keyboard backlight color switch                                                            | (sequence: colorful, red, orange, yellow, green, cyan, blue, purple, white)                                                                                                                                                                                                                  |
|     | Enter            | Keyboard backlight effect switch                                                           | 19 lighting effects, default to follow the flow                                                                                                                                                                                                                                              |
|     | Shift-R          | Keyboard LOGO lighting effect switch                                                       | Streamer (factory default), Breathing, Neon, Constant light, Off                                                                                                                                                                                                                             |
|     | Space            | Check battery power (battery power supply is valid in wireless mode)                       | Press the combination key Fn+Space, the backlight turns off, and the number keys 1 to 0 light up to show the battery percentage. For example: 1 lights up, indicating 10% battery, 1 and 2 lights up, indicating 20% battery. And so on. (Red below 30%, yellow below 50%, green above 50%). |
|     | T                | Keyboard backlight switch                                                                  | With memory                                                                                                                                                                                                                                                                                  |
|     | WIN-L            | Lock WIN                                                                                   | Win will light up white                                                                                                                                                                                                                                                                      |
|     | →<br>←<br>↑<br>↓ | Light speed increases<br>Light speed decreases<br>Light brightness +<br>Light brightness - | When in the limit gear, the up, down, left, and right lights flash 3 times to indicate.                                                                                                                                                                                                      |

## ■ Switch indication description



**MAC mode:** switch to MAC mode

Push left: 2.4G mode

Push right: Wireless BT mode

Win lock indicator: white light indicator

**WIN mode:** switch to Win mode

Middle: USB mode, factory default

CAPS indicator: white light indicator

## ■ Knob default function

Scroll wheel default: Press to mute/Left V-/Right V+

## **“Information to User”**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.