

USER MANUAL

Wireless CarPlay Adapter



U2AIR Pro

CONTENT

How to check a car has CarPlay or not	5
What's in the box	6
Interface and connector	6
Connection diagram	7
How to set up wireless CarPlay	8
Firmware update & report an issue	9

READ ME FIRST


This adapter is designed for iPhone to use Apple CarPlay wirelessly on factory car multimedia system which has built-in wired Apple CarPlay.

However, NOT every car with built-in CarPlay could fit this adapter. If there is any issue while using the adapter, please do not hesitate to email us at support@ottocast.com.


Function	Convert OEM Apple CarPlay to wireless Apple CarPlay
Compatibility	Car: with OEM Apple CarPlay
	iPhone: running iOS 10 or newer
Control	OEM touch screen, steering wheel, and joystick control
Input Power	USB 5V~1A
Connectivity	Wi-Fi & Bluetooth

How to check a car has CarPlay or not

1. Plug an iPhone (running iOS 10 or newer) into the car USB ports with genuine factory lightning cable. If there is a notification pop up on iPhone like below, that your car has built-in Apple CarPlay.



2. If there is a CarPlay icon in the car stereo menu, that your car has built-in Apple CarPlay.



3. Contact your car dealer for help.

What's in the box

- Wireless adapter *1
- USB cable (Type-C to A) *1
- USB cable (Type-C to C) *1
- User manual *1
- Double-sided sticky pad *1

Interface and connector

Type-C power



Smart button




Click once while working: disconnect the current iPhone.

Press and hold for more than 10s: factory reset, all connection history will be erased.

Connection diagram




or



NOTE! The adapter should be plugged into the USB port that is for wired Apple CarPlay connecting if there are multi USB ports in your car.

How to set up wireless CarPlay

- Turn on your iPhone's Wi-Fi and Bluetooth, then pair to the Bluetooth named "OTTO-xxxx"
- Tap "Pair-Allow-Use CarPlay" on the iPhone pop-up notifications
- It will then connect to CarPlay wirelessly after a few seconds.



NOTE! Before pairing to a new iPhone, please disconnect the currently connected phone from Bluetooth/Wi-Fi in iPhone's control center or click the adapter's buttons once.


Firmware update & report an issue

Firmware updating is NOT recommended when every function works well.

A form for reporting an issue and checking for updates. It is divided into two main sections. The top section is for reporting an issue, with fields for "Car Make" (E.g. Toyota), "Model Name" (E.g. Camry XLE), "Year" (E.g. 2020), and a "Detailed description of the problem:" (Please enter text here). Below these fields is a green "Submit" button. The bottom section is for checking for updates, with a grey header "Online Update", a message "New version is available", and a red "Update" button. Below the "Update" button is an "Update Notes" section with the text "1. fix some bugs".

Report the issue

Check for update



● How to update or report

- If your iPhone is connecting to the wireless CarPlay, enter **192.168.1.101** on iPhone's browser, next tap "**Update**" if there is an update available
- If your iPhone could not connect to the wireless CarPlay, please join the adapter's Wi-Fi network [**OTTO-xxxx**] by manual and the password is **88888888**
- Next enter **192.168.1.101** on iPhone's browser, tap "**Update**".
- At the same web interface, you could also fill in the car make, model years, and issue details, next tap "**Submit**" to report the issue. After the success notification appears, take a screenshot and email us at support@ottocast.com. We will fix it as soon as possible.

NOTE! The blue and red LED indicators will flash alternative while updating. Wait for more 30s after the white indicator is solid, then disconnect and reconnect the adapter from USB port to finish the whole update.

This device complies with part 15 of the FCC Rules.

Operation

is subject to the following two conditions:

- (1) This device may not cause harmful interference;
- (2) this device must accept any interference received, including interference that may cause undesired operation.

