

Petkit Έξυπνος Τροφοδότης για Κατοικίδια

Petkit · EAN 6975069307657

Machine translation from Čeština. In case of doubt the manufacturer's original document prevails.

Petkit Smart Pet Feeder

User Manual

PRESS

PACKING LIST

* Before installation and use, confirm that the following accessories are complete. (Batteries and screwdrivers are not included and must be purchased separately.)

OPEN

Main Unit Food Bowl

Container

DEHYDRATOR

USER MANUAL

Elevated Stand Adapter Dehydrator User Manual

* Due to continuous product improvements, there may be slight differences in the actual product (including but not limited to appearance, construction, and color). Images of the product on the packaging and promotional materials are for reference only. PRODUCT

INTRODUCTION

- Lid

...o Lid Release Button

- ○ Container

Dispensing Module

- ○

Notch

Camera

Non-removable

Main

Camera Indicator o. Unit

PUSH Button

Microphone

Feeding Button

Food Bowl

.. Wi-Fi Setting Button

Wi-Fi Indicator

Food Bowl Holder

Elevated Stand

- Scoops for
- dispensing food

Back of Main Unit

Main Unit

Speaker

- Power

Port

Inner Side

of Lid

Dehydrator

Compartment

INSTALLATION INSTRUCTIONS

3.1 Installing the Main Unit

Place the main unit on a flat surface or table. ① Lift the container, align the notches on both sides with the PUSH button on the main unit, and place it vertically down. 3 Press and hold the PUSH buttons until they fully 4 Turn the dispenser upside down. Remove the two rear fit into the notches. anti-slip pads. Insert the elevated stand marked “BACK” into the rear grooves of the dispenser. BACK

BACK

PRESS

Back

5 Align the elevated stand marked “FRONT” with the round 6 After installation, turn the dispenser to the correct position and place it on a flat surface. Ensure that the elevated stands are

base at the front bottom, then push firmly attached, then install the food bowl. FRONT

BACK

PRESS

Back

3.2 Connecting to Power

Remove the power adapter and plug it into the power port, then connect to the electrical

outlet. PRESS

3.3 Installing Batteries

Depending on your needs, you can choose to install batteries. If necessary, install the batteries before attaching the elevated stands. (Batteries must be purchased separately. Only alkaline batteries are supported.)

1 Unscrew the screw and remove the battery cover. 2 Insert five AAA batteries (pay attention to the correct orientation). 3 Replace the battery cover and tighten the screws. ▲

Note: Replace batteries immediately after depletion. Check and replace with new ones during prolonged absence. Bottom

Main Unit

AAA Alkaline

Batteries * 5

3.4 Installing the Dehydrator

1 Press the lid release button to the right and remove the lid. 2 Open the dehydrator compartment, insert the dehydrator, and close the compartment. , as shown in the picture

DEHYDRATOR

USER MANUAL

4.1 Adding Food

1 Remove the lid and add food. Do not exceed the MAX line. 2 Attaching the lid: Insert the back part of the lid into the two holes above the container, then press the lid down.

Recommended pellet size:

≤

12 mm (0.47 in)

Recommended freeze-dried food size: ≤

9 mm (0.35 in)

OPEN▶

4.2 Indicator Light

Slow Blinking Fast Blinking

Steady White

Indicator White White

Indicator

Device is Device is Device is

Status connecting to connected to camera

connecting to

Wi-Fi Indicator

The camera indicator can be turned on or off in the PETKIT app. In battery mode, the camera indicator is off. Camera Indicator Steady Green

Light Off

Status Camera is on Camera is off

4.3 Manual Feeding

Press and hold the feeding button. Release it to stop dispensing. PRESS

4.4 Connecting the App

1 Download the PETKIT app from the App Store or 2 Open the app, tap “+” to add a device, then complete the connection according to the instructions. Google Play. Or scan the QR code to download.

Set feeding schedules in the app and the dispenser will automatically dispense food at the scheduled times. You will receive notifications about the dispensing process and feeding status. The app supports real-time tracking and voice interaction with the option to share and view images. Discover more features in the app.

CLEANING AND MAINTENANCE

1 Open the lid, remove the used desiccant, and take out the

2 Press and hold the PUSH buttons on both sides and lift the container to remove it. DESICCANT

PRESS

PRESS

3 Pull the feeding paddles out of the container. Turn clockwise to remove the paddle cover, and take out the paddles.

... ○ Paddles Turn clockwise

for food

dispensing

paddles

paddles

Bottom

cover

container

4 Wipe the main unit and elevated stands with a soft cloth. To clean the elevated stands, turn the dispenser upside down and pull them out. ⑤ Gradually clean the container, paddles, paddle cover, paddles, top cover, and food bowl. It is recommended to add an appropriate amount of cleaning agent and rinse thoroughly. 6 After cleaning, allow all parts to dry

completely before gradually reassembling them. Detailed steps can be found in the maintenance and cleaning video (see QR code below). Clean the inside of the container with a sponge or soft cloth; avoid using sharp tools to prevent scratching the plastic parts or damaging the sensor. Do not submerge the main unit in water; instead, wipe it with a damp cloth. VIDEO GUIDE

6.1 Installation and usage video 6.2 Cleaning and maintenance video

Scan to view Scan to view

| BASIC TECHNICAL SPECIFICATIONS

PETKIT YUMSHARE SOLO 2 WITH CAMERA

Name

SMART PET DISPENSER

Capacity

Weight (with

approximately 3.94 lb (1.79 kg)

elevated stand)

Rated input

with elevated stand:

Connection 2.4 & 5GHz Wi-Fi

15.07 * 7.32 * 11.81 in (383 * 186 * 300 mm)

Dimensions

without elevated stand:

12.44 * 7.32 * 11.65 in (316 * 186 * 296 mm) Application range Cats and small dog breeds

| SAFETY INSTRUCTIONS

* Failure to comply with the safety instructions below may result in product malfunction or other unforeseen events. • This device can be used by children aged 8 years and older and by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge, provided they are supervised or have been instructed on the safe use of the device and understand the potential risks. • Children should not play with the device.

Cleaning and maintenance should not be performed by children without supervision. • Install and use the product in accordance with the user manual. • Do not forcefully disassemble the camera. • Do not scratch the camera with sharp objects. • Use the product indoors only.

Avoid placing it in direct sunlight or near heat sources. • This product is powered by safe low voltage, but chewing of cables by pets may cause electrical leakage. During use, secure and hide the power cable so that pets cannot chew on it. If animal chewing is observed, stop it immediately. • Use only the original adapter. Using non-original adapters may damage the

device or pose a safety risk. • Place the device on a flat surface. Do not turn the device upside down to avoid safety risks. • Do not place any items other than food in the container, as this may cause malfunction of the device or safety risks for animals. • To prevent animals from tipping over the product, it is recommended to place it in a corner or against a wall. • Do not place the product on high surfaces to avoid damage to the product or safety risks for animals due to falling. • Do not immerse or soak the main unit of the device in water, and the entire device should not be used in a damp environment. • After cleaning the container, ensure that all components are completely dry before reassembling and using the product. • If you wish to stop using the product, remove the batteries, disconnect the power cable, and clean and dry the product before storage. • Please disconnect the power cable before moving the product. • Children should use this device under adult supervision. • For safety reasons, do not attempt to repair this product yourself – repairs should only be carried out by qualified personnel to avoid accidental injury. • If you will be away from home for an extended period, please check that the batteries are fully charged (this product is compatible only with alkaline batteries). • In case of any problems while using the product, please contact customer support as soon as possible. This document is a translation of the original user manual created by the manufacturer.

Detailed information about the warranty conditions of the distributor/manufacturer is available on the website <https://serwis.innpro.pl/gwarancja> The product must be regularly maintained (cleaned) by the user or a specialized service center at the user's expense. If the user manual does not provide information on necessary periodic maintenance or service actions, the physical condition of the product must be assessed regularly, at least once a week, for deviations from that of a physically new product. If any deviation is detected or found, maintenance (cleaning) or service measures must be carried out immediately. Failure to perform proper maintenance (cleaning) and not responding to the identified different condition may result in permanent damage to the product. The guarantor is not responsible for damages caused by negligence. Warnings and Safety Information All information regarding the use of the product can be found in the user manual. Before use, read its contents and follow the instructions contained therein. Also, read the following information before use: Usage Warning Risk of product damage: • Use the products only for their intended purpose as described in the user manual. • Regularly check the condition of the feeder or bowl, especially mechanical components such as lids, handles, feeding mechanisms, or food containers. In case of visible damage, discontinue use and contact service. • Do not overload food or water containers - adhere to the recommended capacities

specified by the manufacturer. Risk to animals:

- Ensure that the feeder is suitable for the size, age, and nutritional needs of the animal.
- Regularly check the quality of the stored food - ensure it is fresh and stored in dry conditions to prevent spoilage.
- Place the device in a stable location that is easily accessible to the animal but away from areas exposed to excessive sunlight, moisture, or contact with other animals.

Risk to children:

- Feeders are not toys. Keep them out of reach of children to prevent accidental damage to the unit.
- Do not allow children to operate the device without adult supervision, especially when filling food or maintaining mechanisms.

Risks associated with electronic components:

- Regularly check the condition of power cables, batteries, and electronic components. If damaged, stop using the device.
- For electrically powered models, ensure that the device is connected to a stable power source.
- If the unit is battery-powered, replace the batteries according to the user manual and use only batteries recommended by the manufacturer.

Information on proper use

Recommendations for use: If necessary, check that the device is in order and functioning properly:

- Before first use, read the user manual and ensure that all components, such as lids, dispensing mechanisms, and containers, are properly assembled.
- Regularly fill the food container according to the manufacturer's recommendations and avoid products that may cause blockages in the mechanisms.
- For models with automatic functions, check that the feeding schedule is set correctly.

Maintenance and storage:

- Store products in a dry and clean place, away from moisture and extreme temperatures.
- Regularly clean feeders and bowls according to the manufacturer's instructions using mild cleaning agents and soft materials. Do not use harsh chemicals or tools that could damage the feeder.
- Replace consumable parts, such as filters (if available), according to the manufacturer's recommendations.

Battery safety: If necessary, ensure that batteries are kept out of reach:

- In battery-operated devices, use only batteries recommended by the manufacturer.
- Dispose of used batteries in accordance with local environmental protection regulations.
- If you will not be using the device for an extended period, remove the batteries to prevent leakage.

Additional safety measures

Adapting to the animal: Monitor the animal's reaction to the feeder or bowl - ensure that using the device does not cause stress or discomfort. For animals prone to overeating, set appropriate portions of food or a feeding schedule to prevent health problems.

Damage and service: Any repairs to mechanical or electronic devices should be carried out only at authorized service centers. Do not modify the device yourself, as this may affect its safety and functionality.

Declaration of Conformity

The products have been designed in accordance with the safety requirements of Regulation (EU) 2023/988. They meet the relevant technical standards, including safety in use, electromagnetic compatibility, and material durability.

EU DECLARATION OF CONFORMITY

JUNDE TECHNOLOGY HK LIMITED hereby declares that the type of radio device Feeder PETKIT Yumshare SOLO 2 is in compliance with Directive 2014/53/EU.

The full text of the EU Declaration of Conformity is available at the following internet address: <https://files.innpro.pl/petkit>

Manufacturer's address: HING YIP STREET KWUN TONG KL 1006 10/F PO YIP BUILDING 23 41468

Hong Kong, hk

Radio frequency: 2.4Ghz (2400Mhz - 2483.5Mhz)

Maximum radio frequency power: <20dBm

Environmental protection

Electronic waste marked in accordance with European Union directives must not be disposed of together with other municipal waste. It is subject to separate collection and recycling at designated locations. By ensuring its proper disposal, you will prevent possible negative consequences for the environment and human health. The collection system for used equipment complies with local environmental protection regulations for waste disposal. Detailed information on this topic can be obtained from the municipal office, processing plant, or the store where the product was purchased. The product meets the requirements of the so-called New Approach Directives of the European Union (EU), which address issues of safety in use, health protection, and environmental protection and specify hazards that should be identified and eliminated. Importer:

INNPRO Robert Błędowski sp. z o.o. Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

hurt@innpro.pl

www.innpro.pl

Representative in the EU:

Apex CE Specialists GmbH

Habichtweg 1 /

41468 Neuss, Germany

info@apex-ce.com

Warranty

The warranty will be voided in the event of changes and/or modifications to the product. The manufacturer is not responsible for any damages resulting from improper use of

this product. Disposal

- Dispose of this product at the appropriate collection point.
- Do not throw this product away with municipal waste.
- For more information, contact the retailer or local authorities responsible for waste management.

Documentation
This product has been manufactured and is supplied in accordance with all relevant regulations and directives applicable in all member states of the European Union. It also meets all relevant specifications and regulations in the country of sale. Official documentation can be obtained upon request. Official documentation also includes (but is not limited to) the Declaration of Conformity, Safety Data Sheets, and the product testing report.

Disclaimer
The design and specifications of the product may be changed without prior notice. All logos and trade names are registered trademarks of their respective owners and are protected by law.