





User Manual

System Requirements

Compatible Platforms	PC
System Requirement on PC	Windows XP/7/8/10

Product Overview



Connect with PC


Step 1 Plug the joystick into PC USB port, the computer will prompt new hardware and install automatically.

Step 2 Function testing is available on the computer. The specific steps show below :

WIN 7/8 : Open Control Panel → Device and Printer → Right mouse click PXN-F16 icon → Game Controller Setting, click Properties Testing.

WIN 10 : Open Setting → Devices → Device and Printer → Right mouse click PXN-F16 icon → Game Controller Setting, click Properties Testing.

Step 3 After entered testing screen(show below), you can test every axes and buttons function.



Attention

- Avoid strong vibration, don't disassemble or repair on your own.
- Don't keep in humid conditions, high temperature or a dusty location.
- Avoid getting water or other liquids into product.
- Please handle gently when connecting and removing product.
- Children should be under parent's supervision to use the product.

Product Specifications

Product Model	PXN-F16
Connection Type	USB Wiring
Power source	DC 5V
Working Current	20mA-100mA
Packaging Size	Appro. 215 * 195 * 250 mm
Product Size	Appro. 198 * 190 * 220 mm
Unit Weight	Appro. 517g
Usage Temperature	10 - 40 °C
Usage Humidity	20 ~ 80 %