


## 3-WAY HOSE SPLITTER

# USER MANUAL



**Model NO.: DZ03**


 **Email**  
 service@rainpointonline.com

 **Hotline**  
 US: +1 833-381-5659  
 DE: +49 800-182-0576  
 UK: +44 20-4628-3036

## PRODUCT OVERVIEW

The water hose splitter is designed to efficiently distribute water from a single source to multiple hoses or outlets, making it ideal for gardens, lawns, and other irrigation needs.

EN




## SPECIFICATION

| ITEMS                  | SPECIFICATION                                                                 |
|------------------------|-------------------------------------------------------------------------------|
| Water Inlet            | NH (US) for 3/4" faucets<br>BSP(EU) for 3/4" faucets                          |
| Water Outlet           | For 3/4" standard hoses                                                       |
| Working Water Pressure | 0-20 bar (0-300psi)                                                           |
| Working Temperature    | 41°F-140°F (5°C-60°C)                                                         |
| Material               | ABS Inlet Coverage+Brass<br>Inlet+Zinc Alloy Body/Outlet+TPR<br>Body Coverage |


EN EN

## HOW TO USE




### Step 1:

Align the inlet of the splitter with the faucet threads and gently screw in to secure the splitter, making sure the threads fit tightly;



### Step 2:

Align each water hose with the outlets of the splitter and screw in gently to ensure a tight fit of the threads;



### Step 3:

Turn on the faucet, then turn down the valve switch of the splitter to open the valve of the splitter. The valve switch on one side controls the water flow on and off on that side.

## TIP:

If there is a leak after connecting the splitter, check if the threads of the splitter are properly aligned and tightened with the threads of the faucet. If they are aligned, wrap some teflon tapes on the threads of the faucet and add a rubber washer at the splitter's inlet before reconnecting to the faucet.



## NOTE:

- Please do not use tools, only install the splitter by hand.
- When freezing temperatures are expected, the splitter should be removed from the faucet and stored indoors to prevent potential freeze damage.

## WARRANTY POLICY

We provide a 12-month limited warranty period for the original purchaser/user, which starts from the date of original purchase. The warranty covers any defect in material or workmanship. During the warranty period, we will fulfill its warranty obligations by repairing or replacing the parts or the entire unit covered by the warranty free of charge according to the actual situation.

However, the warranty does not apply to problems caused by: Normal wear and tear; Failure to follow the accompanying operating instructions; Products malfunction resulting from negligence, accident, improper use, maintenance or storage; Products that have been modified or repaired without authorization (including, but not limited to, modifications through the use of unauthorized parts or accessories).

## CUSTOMER SERVICE

Our local professional customer service team guarantees hassle-free solutions within 24 hours on working days. If you have any problems with this product or during use, please do not hesitate to contact us, we will try our best to solve it and offer you satisfactory service including replacement or refund.

In order to serve you better, please remember to provide us with your order number and fault description of the product and contact us by:

US Hotline : +1 833-381-5659  
 DE Hotline : +49 800-182-0576  
 UK Hotline : +44 20-4628-3036  
 Email: service@rainpointonline.com

EN