

E0575S 英文说明书

折后-95X145MM (THREM版)

Scan the QR code for more help.



or Email: support@baldronline.com

BaldrTherm™



USER MANUAL


KITCHEN TIMER

MODEL NO. E0575S

Thank you for your purchase, please read the manual and save it for future reference.

Email: support@baldronline.com

PRODUCT OVERVIEW



-01-

SPECIFICATION

- Alarm sounding time: 30 seconds
- Max. Settable time: 99minutes 99 seconds
- Operating temperature range: 0-40°C
- Waterproof Rating: IP67
- Battery Life: Approx. 12 months
- Battery: 2 x AAA batteries (not included)

BUTTON FUNCTION

BUTTON NAME	FUNCTION
0 - 9	Set time
Audio	Loud, small, silent mode loop switch
STOP CLEAR	Stop alarm/clear time
START REPEAT	Start timing/Repeat the last time set



Please note the specifications are subject to change without notice due to product improvement.

FEATURES

- Waterproof & grease-resistant keypad
- Straightforward & intuitive setting design
- Adjustable volume alarm
- Wash to clean
- Memory function

HOW TO USE

- Unscrew the battery cover and install 2*AAA batteries (not included).




Set the desired cooking time by pressing buttons on the key pad to select the minutes and seconds, then press "START" to begin the countdown.

Set the countdown

For example, 12 minutes and 30 seconds are required:

- Press [1]→[2]→[3]→[0] respectively in order, and the display will follow the following figure.



- Press "START REPEAT" button to start the countdown.
- when the alarm sounds, press any button will stop the sound.

WARRANTY

- BaldrTherm provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship.

MADE IN CHINA

FR BARQUETTE + ETUI

FR Cet appareil se recycle

Points de collecte sur www.ourfranceproducts.fr