


ROJECO




Wireless Pump Pet Water Fountain

User Manual Please read this manual carefully before using.

CATALOGUE

EN	English	01
DE	Deutsch	05
FR	Français	09
ES	Español	13
IT	Italiano	17
JP	日本語	21
KR	한국인	25
CN	简体中文	29

PRODUCT DESCRIPTION




HOW TO USE

1. Soak the filter in a clean bowl for 5-10 minutes, then rinse the filter thoroughly with tap water.

Note:


1) The filter must be fully soaked before the fountain is turned on; otherwise, the water may not flow through the filter smoothly and cause spillage.

2) Do not soak the filter in water tank of the fountain in case of any surface dust.




2. Insert the foam filter into the groove of the water pump. Position the pump according to the bottom slot shape.

Note: Please pay attention to aligning the recessed part of the pump with the protruding part of the water tank, otherwise the pump cannot be installed firmly.




3. Install the Outlet Pipe on the pump. Add water to the tank.


Note: Fill water into the water tank, make sure the water level is between the MAX and MIN marks.




4. Install the water tray, pass the water pipe through the hole of the water tray.




5. Install the soaked filter.



6. Fasten the inlet pipe to the drinking tray, pass the spout through the hole of the drinking tray, install drinking tray.




7. Connect the power adapter.



8. Install the water tank with the Main Body Base by aligning the protruding hole of the water tank with the Main Body Base.


Note: Do not immerse or soak the main body base in water, when the base gets wet, please wipe the outer surface dry before continuing to use it.




HOW TO CLEAN THE PUMP

1. Remove the foam filter, pump cover and impeller cover in sequence.


(Note: The foam filter affects the water yield very much, so please clean it frequently and replace it in time when cleaning the pump.)



2. Remove the impeller by the brush hook.




3. Use the brush to clean the parts with water.




HOW TO CLEAN THE INLET PIPE & SPOUT


1. Pull out the fishtail spout.



2. Use the principle of leverage to lift the inlet pipe on the narrow side, and remove the water inlet pipe and fish head spout.



3. Use the brush to clean the parts with water.



CARE INSTRUCTIONS

1. Replace the filter and the foam filter at least once every 2-4 weeks.
2. Clean the pump and fountain at least once every 1 weeks.

SPECIFICATIONS

Model	RYSJ-13
Adapter Input	100-240V 50/60Hz
Adapter Output	5V/1A
Capacity	2.5L/84oz
Material	ABS+PC
Dimensions	256*167*128mm/10*6.5*5in
Net Weight	880g

TROUBLESHOOTING

Problem	Solution
The fountain feels slimy?	The slimy caused by your pet' s saliva. More pets that use the fountain will increase the saliva contact and debris in the water, so the water fountain and pump will need to clean more frequently.
There' s Black residues in the water tank?	This black stuff is loose activated carbon from the filter and is completely harmless for your pet to drink. The carbon is made of organic coconut shells. Rinse the filter in cold water before placing it in the fountain to prevent this.
Noise Level Up / Stop Working / Defective Pump / Intermittent Flowing?	1) Disassemble and clean the pump. 2) Fill water into the fountain, make sure the water level is between the MAX and MIN marks. 3) Check if the pump is aligned in place 4) Please ensure that the power supply is connected, the water tank and base are installed correctly, and the water pump and water tank is installed correctly. 5) If the pump was exposed to low water levels for a prolonged period of time, the pump's motor may have burned out and the pump may need to be replaced.
The fountain is leaking?	1) The filter may not be fully soaked. Please soak the filter in the water for 5 minutes before the first use. 2) Check if the filter is clogged, Please clean and replace the filters in time. 3) Clean all fountain parts in water before reassembling the fountain. 4) First, look for visible cracks in the bowl. If there are no visible cracks in the bowl, place the fountain on a towel to see where the leak is. 5) Sometimes water around the fountain is caused by pets drinking. Some pets are prone to spilling.

ROJECO Wireless Pump Pet Water Fountain

Model: RYSJ-13

Manufacture: Jiangxi Chensheng Technology Co., Ltd.

Address: Room 1611,Cuilin Building,1266 fenghe Middle Avenue,Honggutan District,Nanchang City,Jiangxi Province,China

Made in China



Please read this manual carefully and avoid causing errors or damaged. If you have any questions, please feel free to contact us via email: rojecoservice@126.com and include your order number in it. We'll get back to you as quick as possible.