


ROJECO

Pet Smart Feeder

User Manual




Model: MC-W01

Please read this manual carefully before use.

1. Product Description


Front View

- 1. Lid
- 2. Operating Button
- 3. Food Outlet
- 4. Lid Lock
- 5. Food Tank
- 6. Rotor
- 7. Tank Base
- 8. Stainless Steel Bowl
- 9. Bowl Tray




Bottom View

- 10. Battery Compartment
- 11. USB-C Power Port




2. How to Install

1. Take out the machine and all accessories.




2. Connect the unit to the power cable and adapter.

If required, install 3*D alkaline batteries (not included) in case of power failure.




3. To install the impeller, place the impeller correctly into the feeder tank base as shown in the illustration.




4. Installation of food tank.

Put the food tank into the corresponding snap track as shown in the illustration, align it with the ($\triangle$) mark, and turn it clockwise from ① to ② until you hear a click and tighten it.




5. Place the stainless steel bowl on the base and insert it into the bottom of the food tank base.




6. Put in the desiccant (it is recommended to change it every month).
Add the dry pet food and close the lid.

Note: Pet food sizes range from 3-17mm.




7. Double feed bowl installation:

- (1) Insert the 4 support feet into the bottom of the food tank base.




- (2) Insert the food splitter and two bowl trays into the holder, and then insert the holder into the bottom of the food tank base.



3. Disassemble for Cleaning


1. Washable parts.

Note: Do not wash in dishwasher.



2. Wipe the main unit.

Note: Do not rinse.



Note: For the health of your pet, cleaning is recommended once a month.

4. Button Quick Guide



🎤 Voice recording: Press and hold for 3 seconds until you hear a 'beep' to start recording. Release the button when you hear two 'beeps' to finish recording.

🍲 Feed button/Unlock button:
Manual Feeding: Press once to dispense one portion of food, press multiple times in a row will dispense multiple portions of food.
Unlock/Lock: Press and hold for 4 seconds to lock with a 'beep', press and hold again for 4 seconds to unlock with two 'beeps'.

⌛ Reset: Under the unlocked state, press and hold ⌛ for 6 seconds to make a 'beep' sound, the device will restore the factory settings.

5. Indicator Light

Indicator light colour	Action	Meaning
White light	Blinking	Waiting for networking
	Always on	Successful networking
Red light	Fast flashing	App upgrade abnormality
	Slow flashing	Low battery/Motor blocking

Note: When the device fails (low battery/motor blocking) the app will push a fault alert.

6. How To Set Pet Feeder

Preparation Process

- System: iPhone ios system 9.0 or above; Smartphone Android system 4.4 or above.
- Mobile phone should connect with 2.4G wifi. If your wifi is 5G wifi, set it to 2.4G wifi.
- The WiFi password is composed of no more than 12 digits and letters. No special symbols are supported. Do not use Chinese.
- Make sure Bluetooth and Location Services "on" on your phone.
- Please keep the feeder close to the WiFi router. The distance between pet feeder and WiFi router doesn't exceed 33ft/10m and there is no wall barriers between them.

Download APP & Login

- Scan the QR code or search for "ROJECO" on App Store or Google Play to download the app.



ROJECO



App Store




Google Play


- Sign up or Login your account.

Note: APP language depends on your mobile default language.


Add Device

1. Press and hold  for 4 seconds to unlock and press and hold  for 6 seconds to enter the network state.







2. Turn on Bluetooth & WiFi on your phone first and then open **"ROJECO App"**, click **"Add Device"** or **"+"**.




3. **"ROJECO Feeder"** will show, click **"Add"**.



4. Enter WIFI password, click **"Next"**.




5. Click **"Done"** to connect successfully, the WiFi indicator light is always on.




6. Enter the main page. You can choose the portion, and then click **"Quick"** to start feeding immediately.


Add Meal Plan



1. Click **"Meal Plan"** to enter the setting page.




2. Click **"Add"** button to add feeding plan.



3. Set the schedule & portion based on needs. Click **"Save"** to finish.


Add Meal Interface Explanation



8:30

Every Wed.
Thur.Fri.Sat.

6



12:00


Every Sun.Mon.Tue.
Wed.Thur.Fri.Sat.

12


Plan1 08:30(Every Wed.Thur.Fri.Sat.)/6 Portions.

Plan2 12:00 Every Day/12 Portions.

Feed Record



1. Click **"Feed Record"**



2. Enter **"Feeding History"** page.

Note: After disconnecting your network, machine will keep feeding your pet according to your feeding plan without feeding record.

7. Hotspot Distribution Network

If there is no wifi signal at home. Please connect your mobile phone to another mobile phone's hotspot and make sure that Bluetooth is turned on on your mobile phone.

- ① Open the ROJECO APP, select Add Device-Manual Add-Small Home Appliances-Pet Feeder (Wi-Fi)-Enter WiFi Password Next-Wi-Fi Quick Connect in the upper right corner is changed to **"AP-Mode"** Next step-then connect to the WiFi signal of SmartLife-XXXX.
- ② After connecting, return to the previous interface, and then enter the network configuration interface to wait for the connection.

8. Specifications

Model MC-W01

Capacity 4.5L

Output 5V/1A

Dual power supply DC 5V/1A power adapter/3 * D (not included)

Dimensions 7.08*7.08*13.11 in

Material ABS+304 Stainless Steel

Input AC 100-240V

9. Troubleshooting

Problem	Solution
Can't configure the feeder on your phone	1) The WiFi account and password is composed of no more than 12 digits and letters. No special symbols are supported.Do not use Chinese. 2) Mobile phone should connect with 2.4G WiFi.If your WiFi is 5G WiFi, set it to 2.4G WiFi. 3) Make sure Bluetooth and Location Services "on" on your phone. 4) Program problem, some Application conflicts may happen. Please restart your mobile.
Feeder appears disconnected from WiFi	Weak disconnection, please check that the distance between your feeder and router is no more than 33ft/10m, and no concrete walls or too many obstacles between them.Otherwise the WiFi network can be weak and cause unstable connection.
Feeder not working	1) Check if the power cable is connected properly. 2) Please use a new battery as a power source to confirm that it is working properly. 3) Empty the food tank, unlock the state, click the feeder to confirm that the impeller is rotating. 4) Check whether the pet grain size meets the requirements (the maximum grain size is not more than 17mm).
Button not responding	Long press for 4 seconds to unlock

Please read this manual carefully and avoid causing errors or damaged.

If you have any questions, please feel free to contact us via email: rojecoservice@126.com and include your order number in it. We'll get back to you as quick as possible.

Warnings and safety information

All information regarding the use of the product can be found in the user manual. Before using it, read its contents and follow the instructions contained therein.

Also read the following information before use:

Warnings for use

Risk of product damage:

- Only use the products for their intended purpose as described in the instructions for use.
- Regularly check the condition of the feed dispenser or bowl, especially the mechanical components such as lids, handles, feeding mechanisms or feed hoppers. In the event of visible damage, discontinue use and contact service.
- Do not overload the feed or water tanks - adhere to the recommended capacities specified by the manufacturer.

Hazard to animals:

- Make sure the food dispenser is suitable for the size, age and nutritional needs of the animal.
- Regularly check the quality of the stored food - make sure it is fresh and stored in dry conditions to prevent spoilage.
- Place the unit in a stable location that is easily accessible to your pet, but away from areas exposed to excessive sunlight, moisture or contact with other animals.

Danger to children:

- Food dispensers are not toys. Keep them out of the reach of children to avoid accidental damage to the unit.
- Do not allow children to operate the appliance without adult supervision, especially when filling the feed or maintaining the mechanisms.

Risks associated with electronic components:

- Regularly check the condition of the power cables, batteries and electronic components. In the event of damage, discontinue use of the unit.
- For electrically powered models, make sure the unit is connected to a stable power source.
- If the unit is powered by batteries, replace them in accordance with the operating instructions and only use batteries recommended by the manufacturer.

Information on correct use

Recommendations for use:

- Before first use, read the instruction manual and ensure that all components, such as lids, dispensing mechanisms and feed hoppers, are correctly fitted.
- Regularly fill the hopper with feed according to the manufacturer's recommendations, avoiding products that may cause blockages in the mechanisms.
- For models with automatic functions, ensure that the feed dosing schedule is set correctly.

Maintenance and storage:

- Store products in a dry and clean place, away from moisture and extreme temperatures.
- Clean dispensers and bowls regularly according to the manufacturer's instructions, using mild detergents and soft materials. Do not use harsh chemicals or tools that could damage the dispenser.
- Replace consumable parts such as filters (if applicable) as recommended by the manufacturer.

Battery safety:

- Use only batteries recommended by the manufacturer in battery-operated devices.
- Dispose of used batteries according to local environmental regulations.
- If the device will not be used for a long period of time, remove the batteries to prevent leakage.

Additional precautions

Adaptation to the animal:

- Observe your pet's reaction to the food dispenser or bowl - ensure that using the device does not cause stress or discomfort.
- For pets with a tendency to overeat, set appropriate food portions or feeding schedules to prevent health problems.

Damage and servicing:

- Any repairs to mechanical or electronic equipment should only be carried out at authorised service centres.
- Do not modify the unit yourself, as this may affect its safety and functionality.

Declaration of conformity

The products have been designed in accordance with the safety requirements of Regulation (EU) 2023/988. They comply with the relevant technical standards, including safety in use, electromagnetic compatibility and durability of materials.

EU REP:

Enbaoixin Germany Maternal and Infant Supplies GmbH
Laubenhof 23 , 45326 Essen
jasvigor2020@hmail.com

Manufacturer: Flying Shuttle International Trading Co.,Ltd.
Address: ROOM 1201, 12/F, TAI SANG BANK BUILDING,
30-132 DES VOEUX ROAD, CENTRAL, HONG KONG