

Φακός Superfire L6-U - 1480 lm, 330 μ., 5 λειτουργίες, 20W, USB-C

Superfire · EAN 6956362999596

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Superfire L6-U Flashlight

User Manual

Manufacturer: Shenzhen Supfire Prosperity Equ. Co., Ltd. Address: 9th Floor, Building 10, Shuian Garden, Yuanyang

Xintiandi, Longgang District, Shenzhen, China

WARNING

1. The product heats up, which is completely normal and does not indicate that the product is defective.
2. Do not shine the light into eyes, as it may cause eye damage.
3. If the product has been used for too long or if it has not been used for an extended period, it should be charged at least once every three months.
4. During use, ensure that the battery cover is intact. Otherwise, it may cause fire or explosion and fire.

USB HANDHELD FLASHLIGHT L6-U:

1. Connect the USB cable to the USB port on the flashlight, and then to the USB port on the charging device (see 1.1).
2. When the battery is charging or discharging, the indicator will display (blink) red and change to blue/green when the battery is fully charged (as shown in the picture). Figure 1.2. Figure 1.2.
3. Some products may also serve as a power bank for charging mobile phones (figure 1.3). Figure 1.3.

USB CHARGING INSTRUCTIONS FOR SPOTLIGHTS

Different spotlights have different configurations and modes, refer to the actual product.

Product switch and mode switch:

- 1.1 Press the switch to turn on the light, and gently press the light to switch between different modes. A long press of 1-2s turns off the fixture; some fixtures do not support long press to turn off.

1.2 Some switches are designed for additional lights, and a long press of the switch will turn on the light.

1.3 Some lighting fixtures are designed for smooth brightness adjustment. Press and hold the button to smoothly change the brightness of the lamp from bright to dim or from dim to bright, and release the button to maintain the current brightness.

1.4 Some lamps are equipped with a sensor switch. Press the sensor switch to activate the sensor function. Wave your hand in front of the fixture to activate the brightness mode switch of the fixture. Press the induction function switch again to turn off the sensor control function. (As shown in figure 1.4). Figure 1.4.

2. Charging the product:

To charge the product, use a USB cable, and various standard USB interfaces can be used, e.g., for charging mobile phones. The location of the charging interface varies by model, and the rubber plug should only be inserted after charging. Note: Different products have different configurations and modes; refer to the actual product (as shown in figure 1.5).

Figure 1.5 - Operating method

3. Focusing function:

Some flashlights are equipped with a focusing function.

4. The size of the strap can be manually adjusted as needed (Figure 1.7). Figure 1.7.

INSTRUCTIONS FOR USING THE FLASHLIGHT CHARGER HOLDER

Remove the battery from the flashlight and insert it into the charging port. Pay attention to the positive and negative terminals of the battery (as shown in figure 1.8). Figure 1.8. Press the rear or middle button to turn on/off, tap to set modes, and then press the control to switch between modes; press and hold for 2 seconds to turn off any mode (as shown in figure 1.9). Middle button Rear button

Low SOS

High Medium Strobe

Figure 1.9 - Lighting modes

Note: The lighting modes in different flashlight models vary and are not limited to the five modes listed above.

APPLICATION SCENARIOS

Daily use

Outdoor lighting

Training

Field lighting

Workshop lighting

Work lighting

Night lighting Camping lighting

INNPRO Robert Błędowski sp. z o.o. ul. Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

hurt@innpro.pl

This document is a translation of the original user manual created by the manufacturer. The product should be regularly maintained (cleaned) by the user or by specialized service points at the user's cost and responsibility. If there is no information about necessary periodic or service maintenance actions in the user manual, the user should regularly, at least once a week, assess the physical condition of the product against that of a physically new product. If any deviation is detected or identified, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detection of a deviation may lead to permanent damage to the product. The guarantor is not responsible for damages resulting from negligence.

The device is equipped with a LI ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. The actual operating time may differ from that declared in the offer and this is not a defect of the device but a feature of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.18V or 15% of the total capacity. Lower values, such as 2.5V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and the device in a dry place, away from sunlight and negative temperatures.

The device is equipped with a LI PO (lithium-polymer) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. The actual operating time may differ from that declared in the offer and this is not a defect of the device but a feature of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.5V or 5% of the total capacity. Lower values, such as 3.2V for the cell, permanently damage it and this is not covered by the warranty. If the

battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and the device in a dry place, away from sunlight and negative temperatures.