

Φακός κεφαλής Superfire HE11 - 640 lm, 20W, 6 λειτουργίες, 100 μ.

Superfire · EAN 6975515775573

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Superfire HE11 Headlamp

USER MANUAL

Dear Customer, thank you very much for purchasing this product! Please read and familiarize yourself with the contents of this manual before using the product.

RECOMMENDED SAFETY PRECAUTIONS FOR USE:

1. The product may become warm in high light mode, which is normal and does not indicate a defect.
2. Do not shine the flashlight directly into eyes to avoid irritation caused by bright light.
3. Please charge the battery before first use or after prolonged inactivity.
4. Ensure that the battery is properly installed in the flashlight to avoid damage.
5. Disassembling the battery is prohibited. A damaged battery surface may cause a short circuit, fire, or explosion.
6. If the battery will not be used for a long time, please discharge and recharge it every 3 months to keep the battery in good condition.

CHARGING INSTRUCTIONS:

1. For flashlights and headlamps with USB charging:
 - 1.1. Using a USB cable, connect it to the USB port of the flashlight and the other end to a USB charger, phone charger, or other USB devices.
 - 1.2. The indicator light glows red while charging or when the battery is low, and changes to a steady blue/green when fully charged.
 - 1.3. Some flashlights can be used as power banks to charge mobile phones or other USB devices.

2. For flashlights with replaceable batteries:

Remove the battery from the flashlight and place it in the designated charger. Please pay attention to the battery polarity.

Note: Different products may have different configurations and modes, please refer to the actual product.

FLASHLIGHT INSTRUCTIONS:

1. Press the button at the end or in the middle of the device to turn the power on/off. Tap to adjust modes, then press the flashlight power button to switch between different modes, and a long press of 2 seconds in any mode will turn it off.
2. Some flashlights have a beam width adjustment feature - slide the head to adjust the size of the light spot.

HEADLAMP INSTRUCTIONS: Different headlamps have different configurations and modes, please refer to the actual product.

1. Product switch and mode switch:

- 1.1. Press the light switch to turn on the light, then click to switch between different modes. A long press of 1-2 seconds will turn off the lamp. Some lamps do not support long pressing to turn off.
- 1.2. Some switches are designed for additional lights, and a long press of the switch will turn them on.
- 1.3. Some lamps have a smooth brightness adjustment mode. Press and hold the button to change the brightness of the lamp from bright to dim or from dim to bright, then release the button to maintain the current brightness.
- 1.4. Some lamps are equipped with a motion sensor switch. Press the sensor switch to turn the motion sensor on or off. Wave your hand in front of the lamp to control its brightness.

2. SAFETY PRECAUTIONS

1. Before charging, check that the device contacts are clean.
2. Never leave the device unattended while in use or charging.
3. Ensure that you can quickly disconnect the device from the power source in an emergency.
4. Never expose the device to high temperatures.
5. Charge the device in a dry and well-ventilated area, away from flammable materials, maintaining a minimum distance of 1m from other objects.
6. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and certification.
7. Take care of your property; the device is equipped with cells that are difficult to extinguish, equip yourself with a fire blanket.

Environmental Protection

Used electronic equipment marked in accordance with the European Union directive must not be disposed of with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential

negative consequences for the natural environment and human health. The system for collecting used equipment complies with locally applicable environmental protection regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, cleaning facility, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning safety, health protection, and environmental protection, identifying hazards that should be detected and eliminated. This document is a translation of the original user manual created by the manufacturer.

Detailed information about the warranty conditions from the distributor/manufacturer is available on the website <https://serwis.innpro.pl/gwarancja>. The product should be regularly maintained (cleaned) at your own expense or by specialized service points at the user's cost and scope. In the absence of information about necessary periodic or service maintenance actions in the user manual, the physical condition of the product should be assessed regularly, at least once a week, to determine any deviation from that of a physically new product. If any deviation is detected or identified, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detecting a state of deviation may lead to permanent damage to the product. The guarantor is not responsible for damages resulting from neglect. Importer: INNPRO Robert Błędowski sp. z o.o. ul. Rudzka 65c 44-200 Rybnik, Poland tel. +48 533 234 303 hurt@innpro.pl www.innpro.pl Manufacturer: Shenzhen Supfire Prosperity Equ. Co., Ltd. 9th Floor, Building 10, Shuian Garden, Yuanyang Xintiandi, Longgang District, Shenzhen, China

Safety precautions Before starting to charge, check if the device contacts are clean. Never leave the device unattended while in use and charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high temperatures. Charge the device in a dry and well-ventilated place away from flammable materials, maintaining a minimum space of 1m from other objects. Never cover the device while charging. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and certification. Take care of your property; the device is equipped with cells that are difficult to extinguish, so equip yourself with a fire blanket.

LI-ION Battery The device is equipped with a LI ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal operating conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the

device but a product feature. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.18V or 15% of total capacity. Lower values, such as 2.5V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. LI-PO Battery The device is equipped with a LI PO (lithium-polymer) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal operating conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the device but a product feature. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.5V or 5% of total capacity. Lower values, such as 3.2V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. PL Warnings and safety information All information regarding the operation of the device can be found in the user manual. Before you start using it, familiarize yourself with its content and follow the instructions contained within. Before use, also familiarize yourself with the following information: Usage warnings 1. Child safety: ●The lamps are not intended for play by children. Keep them out of their reach to avoid the risk of burns (in the case of lamps with heat-generating bulbs) or electric shock. ●Children should use the lamps only under adult supervision. 2. Electrical safety: ●Lamps powered by electricity should only be connected to sockets that comply with the manufacturer's specifications. Do not use devices with damaged cords, plugs, or housings. ●Do not use lamps near water unless they are marked as waterproof and have the appropriate protection class (e.g., IP65 or higher). 3.

Safe use of solar lamps:

- Make sure that solar lamps are placed in areas with access to sunlight for proper battery charging.
- Do not cover the solar panels and clean them regularly to ensure maximum charging efficiency.

4. Fire and burn risk:

- Gas or battery-powered camping lamps can generate heat. Do not cover lamps while in use

or place them near flammable materials.

- Avoid touching hot lamp components immediately after use.

5. Protection against moisture and weather conditions:

- Outdoor and camping lamps should have an appropriate degree of protection to withstand contact with moisture and rain.

- Do not use lamps in extreme weather conditions (e.g., during a storm) unless the manufacturer recommends it.

6. Battery and accumulator protection:

- Use only batteries and accumulators that comply with the manufacturer's recommendations. Do not mix new and old batteries or different types of cells.

- Do not expose batteries to high temperatures. In case of battery damage, immediately stop using the device.

Information on proper use

1. Preparing the device for operation:

- Before first use, read the user manual and ensure that all components are correctly assembled.

- If using a gas-powered lamp, check the tightness of connections and use it only outdoors in well-ventilated areas.

2. Charging and maintenance of solar lamps:

- Position solar lamps in areas that receive as much sunlight as possible during the day. Avoid shaded areas.

- Regularly clean the solar panels of dust and dirt to avoid limiting their charging efficiency.

3. Setting up and using outdoor lamps:

- Ensure that the lamps are securely mounted or placed on a flat surface to avoid tipping over.

- Mount lamps with wall or ceiling mounting features according to the instructions, using appropriate screws and brackets.

4. Maintenance and cleaning:

- Before cleaning, disconnect the lamps from the power source. Use a soft, damp cloth for cleaning.

- Avoid using aggressive detergents that may damage the lamp's surface or solar panel.

5. Storage:

- Store lamps in a dry and cool place when not in use for an extended period.

- For lamps with batteries, charge them before storage to avoid deep discharge.

Additional precautions

●Environmental protection:

●Used batteries, accumulators, and lamps should be disposed of according to local electronic waste regulations. Do not throw them in regular trash bins.

●Choose lamps with energy-efficient light sources, such as LEDs, to reduce energy consumption.

●Energy efficiency:

●Choose lamps with brightness adjustment or energy-saving modes to extend the operating time of batteries and accumulators.

●Avoid unnecessarily leaving lamps on to maximize energy efficiency.