

Φακός Superfire L21

Superfire · EAN 6977502518040

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Superfire L21 Flashlight

User Manual

SAFETY PRECAUTIONS

1. In high light mode, the product heats up, which is a normal phenomenon.
2. Do not direct the flashlight beam directly into the eyes to avoid eye irritation caused by the bright light.
3. Please charge the device before first use or after a long period of non-use.
4. Please insert the battery into the flashlight in the correct direction to avoid damaging the flashlight.
5. Please ensure that the battery casing remains intact during use. Damage to the battery casing may cause a short circuit, fire, or explosion.
6. If the battery is not used for a very long time, please charge and discharge it every 3 months to keep it in good condition.

CHARGING INSTRUCTIONS

1. For flashlights and headlamps with USB charging:
 - 1.1. Using a USB cable, connect it to the USB port of the flashlight, and the other end to a USB charger, phone charger, or other USB devices.
 - 1.2. The indicator light shines red during charging or when the battery is low, and changes to a steady blue/green when fully charged.
 - 1.3. Some flashlights can be used as power banks to charge mobile phones or other USB devices. Pressing for 2 seconds in any mode will turn it off.
2. Some flashlights have a beam width adjustment feature - slide the head to adjust the size of the light spot.

FLASHLIGHT INSTRUCTIONS

1. Press the button at the end or in the middle of the device to turn the power on/off. Tap to adjust modes, then press the flashlight power button to switch between different modes, and a long press for 2 seconds in any mode will turn it off.
2. Some flashlights have a beam width adjustment feature - slide the head to adjust the size of the light spot.

HEADLAMP INSTRUCTIONS

Different headlamps have different configurations and modes, please refer to the actual product. Product switch and mode switch

1. Press the light switch to turn on the light, then click to switch between different modes. A long press of 1-2 seconds will turn off the lamp. Some lamps do not support long pressing to turn off.
2. Some switches are designed for additional lights, and a long press of the switch will turn them on.
3. Some lamps have a smooth brightness adjustment mode. Press and hold the button to change the brightness of the lamp from bright to dim or from dim to bright, then release the button to maintain the current brightness.
4. Some lamps are equipped with a motion sensor switch. Press the sensor switch to turn the motion sensor on or off. Wave your hand in front of the lamp to control its brightness.

HEADLAMP INSTRUCTIONS

Different headlamps have different configurations and modes, please refer to the actual product. Product switch and mode switch

1. Press the light switch to turn on the light, then click to switch between different modes. A long press of 1-2 seconds will turn off the lamp. Some lamps do not support long pressing to turn off.
2. Some switches are designed for additional lights, and a long press of the switch will turn them on.
3. Some lamps have a smooth brightness adjustment mode. Press and hold the button to change the brightness of the lamp from bright to dim or from dim to bright, then release the button to maintain the current brightness.
4. Some lamps are equipped with a motion sensor switch. Press the sensor switch to turn the motion sensor on or off. Wave your hand in front of the lamp to control its brightness.

SUPERFIRE

SHENZHEN SUPFIRE

PROSPERITY EQU. CO., LTD

Implementation standard: Q/SH 001-2017

Customer service phone number: +86 0755 84879237

Company website: www.superfire.com

Customer service email address: info@superfire.com

Company address: 9th Floor, Building 10, Yuanyang Xintiandi, Longgang District, Shenzhen

Responsible entity

MJCM SARL

78 Avenue Bureau 326

75008 Paris

France

mjcm190928@gmail.com

Environmental Protection

Used electronic equipment marked in accordance with the European Union directive must not be placed together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The waste collection system for used equipment complies with locally applicable environmental protection regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, cleaning facility, or the store where the product was purchased. The product meets the requirements of the directives referred to as

New Approach of the European Union (EU) regarding issues related to user safety, health protection, and environmental protection, defining hazards that should be detected and eliminated. This document is a translation of the original user manual created by the manufacturer. Detailed information about the distributor/manufacturer warranty conditions is available on the website <https://serwis.innpro.pl/gwarancja>.

The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. In the absence of information about necessary maintenance or service actions in the user manual, the user should regularly, at least once a week, assess the physical condition of the product against that of a physically new product. If any deviation is detected or noted, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detecting a deviation may lead to permanent damage to the product. The warranty provider is not responsible for damages resulting from negligence.

Importer:

INNPRO Robert Błędowski sp. z o.o.

ul. Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

hurt@innpro.pl

www.innpro.pl

Battery Information:

Type: Portable lithium-ion batteries (Li-ion)

Battery category: portable battery

Battery capacity (mAh): 21700/3000 mAh

Net weight of the battery: 50 g

Safety Precautions

Before starting to charge, check if the device contacts are clean. Never leave the device unattended during use and charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high temperatures. Charge the device in a dry and well-ventilated place away from flammable materials, maintaining a minimum distance of 1m from other objects. Never cover the device while charging. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and certification. Take care of your property; the device is equipped with cells that are difficult to extinguish, so equip yourself with a fire blanket.

LI-ION Battery

The device is equipped with a LI-ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the device but a characteristic of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.18V or 15% of total capacity. Lower values, such as 2.5V for the cell, cause permanent damage and are not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and the charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures.

LI-PO Battery

The device is equipped with a LI-PO (lithium-polymer) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time

may differ from that declared in the offer and this is not a defect of the device but a characteristic of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.5V or 5% of total capacity. Lower values, such as 3.2V for the cell, cause permanent damage and are not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and the charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures.

All information regarding operation and use can be found in the user manual or on the product label. Before starting to use the product, familiarize yourself with its content and follow the instructions contained therein. Before use, also familiarize yourself with the following information:

Warnings and Safety Information

1. Electrical Safety:

- Using appropriate batteries: Only use batteries recommended by the flashlight manufacturer to avoid the risk of overheating, explosion, or damage to the device.
- Charging batteries: Charge the batteries according to the manufacturer's instructions, using the appropriate charger, and never leave the flashlight unattended while charging.
- Do not use in damp conditions: If the flashlight is not waterproof, avoid using it in the rain or near water to prevent damage to the electrical circuits and the risk of electric shock.
- Warning against overheating: Flashlights, especially those with strong light sources, can become hot during prolonged use. Always check if the device is overheated to avoid burns or material damage.

2. User safety:

- Using in dark conditions: When using the flashlight in darkness or difficult conditions (e.g., during hiking, camping), pay special attention to your surroundings to avoid tripping or falling.
- Storing the flashlight: When the flashlight is not in use, store it in a dry and cool place to avoid damage, especially if it is powered by batteries that may overheat.
- Child safety: The flashlight should be stored out of reach of children, especially if it contains small parts, such as replaceable batteries or removable port covers, which may pose a choking hazard.

3. Risk of burns and damage:

- Exercise caution with bright light: Do not point the flashlight directly at the eyes, especially at high light power, to avoid eye damage.
- Safety warning regarding contact with hot surfaces: The outer parts of the flashlight may become hot, especially in the case of high-power LED flashlights. Always check the temperature of the flashlight before reusing it,

especially after prolonged operation. 4. Maintenance recommendations:

●Cleaning and maintenance: Regularly check the condition of the flashlight. Use a soft cloth to clean the casing to avoid scratches and damage. Ensure there is no moisture in the battery compartment to prevent damage. ●Battery replacement recommendations: Replace the batteries in the flashlight regularly, according to the manufacturer's instructions. Avoid using damaged or excessively worn batteries that may affect the device's performance and pose a risk of overheating. 5. Storing the flashlight:

●Storing under appropriate conditions: To ensure the flashlight operates correctly for a long time, store it in a dry and cool place, away from extreme temperatures, moisture, and heat sources. Avoid storing the flashlight in places where it may be exposed to direct sunlight or high temperatures.