

ULTIMEA

USER MANUAL

APOLLO P40 PROJECTOR

SMART AS YOUR CHOICE



Model No.: U0320

Apollo P40

WE ARE READY TO HELP



support@ultimea.com

Prefer video tutorial?

Setup guidance video and User Manuals on ULTIMEA website.



support.ultimea.com



@ultimea_official



+1 888-598-8875 (US) Mon-Fri 9am-5pm (PST)
+49 89-628-25828 (EU) Mon-Fri 9am-5pm (CET)

1 Safety Instructions

Read all instructions before you use this device. Do not make any changes or create settings that are not described in this manual. If physical injury, loss of data, or damage is caused by failure to follow instructions, the warranty does not apply.

Setup

- To avoid personal injury or property damage, please comply with the instructions in this manual carefully and do not use the product in any other way.
- To reduce the risk of fire and / or electric shock, do not expose the device to rain or moisture. Objects filled with liquids, such as vases, should not be placed on this device.
- Do not place this device on soft surfaces such as tablecloths or carpets, otherwise the device could be a fire hazard.
- Do not place this device in areas susceptible to excessive dust and dirt or near any appliance generating a strong magnetic field.

- To prevent overheating, do not block or clog the ventilation openings.
- Never place this device in a confined space. Always leave enough space around this device for ventilation.
- Avoid overexposing this device to direct sunlight, heat, large temperature fluctuations, and moisture. Avoid extreme temperatures.
- When this device is running for a long period of time, the surface may become hot. If this occurs, shut it down immediately and unplug the charger. Resume operation after the device has cooled down.
- Always handle this device with care. Avoid touching the lens.
- Do not allow children to handle the device without supervision.
- Do not place heavy or sharp objects on this device.
- To avoid electric shock, do not disassemble the device.
- Avoid extreme vibration. It may damage the internal components.
- Only use attachments or accessories specified by the manufacturer.

- Please comply with the laws and regulations of the country and region where the equipment is located (used), observe professional ethics, pay attention to safety obligations, and strictly prohibit the use of our products or equipment for any illegal purpose.
- When using a projector in a dark environment, be mindful of the safety of your audience. Ensure that equipment such as projectors and power cords are placed in locations where they cannot be easily tripped over or touched, and avoid crossing cords to minimize safety risks.

Power Supply

- Use only the provided power adapter.
- Power off the device before removing the power supply from the socket.
- Protect the power cord from being walked on or pinched, particularly at plugs.
- Unplug this device if there are lightning storms or when unused for a long period of time.
- Before you make or change any connections, ensure that all devices are disconnected from the power outlet.

- Never touch the power cable or the power connector with wet hands.

Hearing Safety

- To prevent hearing damage, do not listen for extended periods at high volume. Set the volume to a safe level.

Caution

- Do not stare directly at the operating beam. The bright light may damage your eyes.

Cleaning

- Use a soft, lint-free cloth. Never use liquid, gaseous, or easily flammable cleansers to clean.
- Do not use any liquid cleaning agents to clean the lens to avoid damaging the coating film on the lens.
- Wipe the surfaces gently. Be careful that you do not scratch the surface.
- Use lens cleaning paper to clean the lens.

Repairs

- Do not make any repairs to this device yourself. Only have your device repaired by an authorized service center.
- Improper maintenance can result in injuries to persons or damage to this device.
- Refer all servicing to qualified service personnel.

System

- In order to improve the user experience, the user interface will be updated through software upgrades. There may be some differences between the interface and the manual. If there is a difference between the manual and the user interface of the product you received, please refer to the actual display prevails.

2 Accessories List



Projector



Remote Control



Manual



AV Cable



HD Cable





Power Cable




Warranty Card

3 Product



4 Remote Control





LED Indication

LED Status	Description
Steady Blue	Powered On
Steady Red	Standby Mode
Light Off	Powered Off

5 Get Started

Prepare the Remote Control

- Open the battery holder cover of the remote control.
- Install two AAA batteries. Make sure to match the polarity (+/-) indicated and put back the cover.
- Please refer to the on-screen instructions to pair the remote control with Apollo P40.
- The distance between the remote and the projector should not exceed 10 m / 33 ft.



Power On/Off

- Inserting the power plug using the provided power cord.
- Press the power button or remote control power button once to power on.
- Press the power button or remote control power button twice to power off.




Plug the power cord into an outlet.



Press the power button to turn on the projector.

Placement



- Place Apollo P40 on a stable, flat surface in front of the projection surface.
- Please adjust the distance between Apollo P40 and the projection surface to get the desired projection image.

Projection Distance and Projection Image Size

Projection Image Size(inch)	Distance(m)	Distance(ft)
80	2.49	8.12
90	2.8	9.19
100	3.1	10.18
110	3.42	11.22
120	3.73	12.24

- Tips: The projection image size refers to the distance of the diagonal of the image size instead of the length of the image size.

Auto Focus


- Select [Settings]->[Projection Settings]->[Auto Focus]. Select On.
- Place the projector on a suitable projection surface or wall, and the projector will perform autofocus until it gets a clear image.

Focus Manual

Press **F+** or **F-** on the remote control to manually adjust the focus. Please carefully observe the focus icon until get a clear image.

Vertical / Horizontal correction

When fixing your projector in a place, select [Settings] -> [Projection Settings]. Please turn off Auto keystone and go back to the previous menu. Select [Vertical Correction] / [Horizontal Correction], press left or right button on the remote control to adjust.



Corner Correction

If the projected image is stretched or distorted along both axes due to the angle of the projection, select [Settings] -> [Projection Settings]->[Corner Correction], choose the corner you want and press button on the remote control to adjust.

Zoom in/out

Select [Settings]->[Projection Settings]->[Zoom In/Out]. Use the remote control to resize the picture size.

Intelligent Obstacle Avoidance

Select [Settings] -> [Projection Settings] -> [Intelligent Obstacle Avoidance]. Select On/Off.

Intelligent Screen Alignment

Select [Settings] -> [Projection Settings] -> [Intelligent Screen Alignment]. Select On/Off.

6 Projection Settings



Desktop Front Projection



Ceiling Front Projection




Desktop Rear Projection



Ceiling Rear Projection

Select [Settings] -> [Projection Settings]->[Projection Mode], select Desktop Front Projection/Desktop Rear Projection/Ceiling Front Projection/Ceiling Rear Projection.

7 Wired Connections



Play from an HD Playback Device

This Apollo P40 supports connections with various HD playback devices such as PC, TV stick, TV box, DVD player, set-top box (STB), game console or other devices.

- ① Connect this projector to an HD playback device with an HD cable.
- ② Press the  button on remote control to go to projector home menu, select [HD] and press .

Play from a USB Storage Device

With Apollo P40, you can enjoy music, video, and pictures, or install apps that are stored on a USB storage device.

- ① Plug in the USB storage device.
- ② Select "File Manager" on the homepage.
- ③ Open "File Manager" app and find the USB storage device. Select a file.
- ④ Press  to start playback.

Play Through External Sound Devices Via AUX Cable

- ① Connect one end of the 3.5mm AUX cable to the AUX port on this projector.
- ② Connect the other end of the 3.5mm AUX cable to the AUX port on headphones or external speakers.
- ③ Playback on the projector.

8 Bluetooth Connection

Bluetooth Speaker

Select "BT Speaker" on the homepage, or press  button then select "BT Speaker", and operate according to the prompts.

Play Through External Sound Devices via Bluetooth

If you want to connect to Bluetooth speakers/headphones, select [Settings]->[Bluetooth], search for Bluetooth device and click pair.

9 Wireless Connection

Android device

Select "Screen Mirroring" on the home page, select Miracast, and operate according to the system prompts.

iOS device

Select "Screen Mirroring" on the home page, select Airplay, and operate according to the system prompts.

Note:

1. Android devices do not need to be connected to Wi-Fi to use this function. But iOS devices need to be connected to the same Wi-Fi as the projector.
2. Due to copyright issues, some content such as Netflix and Prime video may not be played on the same screen. It is recommended to connect a TV box to play such content.

10 Specifications

Wi-Fi: 2.4 GHz / 5 GHz

Native Resolution: 1920*1080p

Speaker Drivers: 5W*2

Throw Ratio: 1.4:1

Aspect Ratio: 16:9 / 4:3

Recommended Screen Size: 80"-120"

Power Consumption: 90W

Power Input: 100-240V AC, 50-60Hz 2.5A

ULTIMEA

Apollo P40 Projector
Model No.: U0320



Ultimea GmbH
Buchenring 57, 22359 Hamburg, Germany



UK CROSSBORDER LIMITED
7 Bell Yard London WC2A 2JR, UK United Kingdom

Made in China

Manufacturer: Ultimea Technology (Shenzhen) Limited

Address: 20th Floor, Building 4, Tianan Cloud Park, Bantian St.,

Longgang District, Shenzhen, China 518000

@Dyanic Inc. All rights reserved, registered in the United States and other countries.

9804 Crescent Center Drive, Suite 604, Rancho Cucamonga, CA 91730



If you need our support, kindly reach out to our service team. We are always glad to help.
Bei Bedarf an unserem Kundenservice können Sie sich auf unsere freundliche und zuverlässige Unterstützung verlassen.

+1 888-598-8875 (US)
Mon-Fri 9am-5pm (PST)
+49 89-628-25828 (EU)
Mon-Fri 9am-5pm (CET)
 support@ultimea.com
 support@ultimea.com
 support.ultimea.com



@ultimea_official