

Utimea Poseidon D70 Soundbar

Utimea · EAN 4262533460034

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

User Manual

Poseidon D70

Model No: UC00Q

Poseidon D70 7.1-channel virtual soundbar with surround sound

Poseidon D70 WE ARE

User Manual READY TO

HELP support@ultimea.com

support.ultimea.com

Scan the code to

download the app

You can also search for "ULTIMEA" in

Google Play or Apple Store

to download the app.

@ultimea_official

+1 888-598-8875 (USA) Monday-Friday, 9:00 AM-5:00 PM (PST)

Model No: U2600 +49 89-628-25828 (EU)

Monday-Friday, 9:00 AM-5:00 PM (CET)

1 CONTENTS OF THE PACKAGE

Subwoofer Soundbar Surround speakers × 4

FL (3 m) FR (3 m) SL (6 m) SR (6 m)

Stereo audio cable Front left cable Front right cable Rear left cable Rear right cable

Power supply Power cable

3.5 mm to RCA surround (3 m) surround cable (3 surround (6 m) surround (6 m)
subwoofer

m)

1 6 1

12 6

Poseidon D70

2600

Optical cable

Remote control Wall mount User manual

HDMI cable

Mounting screw

Mounting kit for

speakers

on the wall

2 SOUND BAR CONTROL ELEMENTS

1 2 3 4 5 Control panel

1 “ ”: Power button

Press to turn the power on/off. 2 “ ”: Source

Press to switch channels: ARC-OPT(OPTICAL)-BT-AUX-USB. 3 “ ”: Bluetooth

Press to switch to BT channel and enter pairing mode. Hold for 3 seconds to disconnect the current device and manually select a new device to connect on your mobile phone/computer/TV (BT identifier: Poseidon D70). 4 “ ”: Volume down

5 “ ”:

Volume up

03

Remote control

“ ”: 1

1 power button

Press to turn the power on/off. “ ”: SOURCE 2

2

3

Press to switch channel: ARC-OPT-BT-AUX-USB 4

3 “ ”: ARC

Press to switch to HDMI ARC channel.

“ ”: OPT 5 7

4

Press to switch to the OPTICAL channel. 6

5 “ ”: AUX

8 9

Press to switch to the AUX channel. 6 “ ”: BT

Press to switch to the BLUETOOTH channel. 10

7 “ ”: USB

Press to switch to the USB channel. 12 13

8 “ ”: SUB PAIR

Press and hold the button for 3 seconds to put the soundbar in pairing mode with the subwoofer. 9 “ ”: USB REPEAT

USB mode: Press to toggle between single loop playback and playlist loop playback. 10 “ ”: Volume Up

“ ”: Volume Down

11

“ ”: Previous 17

12

12

18

Only in BT and USB mode: Go to the previous track. 13 “ ”: Next

Only in BT and USB mode: Go to the next track. 19

14 “ ”: Play/Pause

Only in BT and USB mode. “ ”:

MUTE 21

15

“ ”: LED DIMMER

16

20 22

Press to adjust the display brightness in 5 levels. Press and hold for 3 seconds to turn off the LED display.

17 “ ”: BASSMAX

23 25

Press to adjust the bass level, the display will show: 24

“ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”. 26

18 “ ”:

27

Press to adjust the treble level, the display will show: “ ”,

“ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”, “ ”.

19 " ":

Press to adjust the treble level. The display will show: " ",

" ", " ", " ", " ", " ", " ", " ", " ",

" ", " ", " ", " ", " ", " ". 20 " ": MOVIE

Press to switch to MOVIE mode, the display will show the message:

21 " ": MUSIC

Press to switch to MUSIC mode, and the display will show the message:

22 " ": VOICE

Press to switch to VOICE mode, and the display will show the message:

23 " ": SPORT

Press to switch to SPORT mode, and the display will show the message:

24 " ": GAME

Press to switch to GAME mode, the display will show the message:

25 " ": NIGHT

Press to switch to NIGHT mode, and the display will show the message: " " (Turn on NIGHT mode). 26 " ":

Press to adjust the surround sound level. The display will show: " ", " ", " ", " ", " ",

" ", " ", " ", " ", " ", " ", " ", " ", " ". 27 " ":

"

Press to adjust the audio signal level. The display will show: " ", " ", " ", " ". 04

3 CONNECT TO TV VIA HDMI ARC

eARC/ARC

ARC

HDMI

Step 1: Step 2: Step 3:

Connect one end of the HDMI cable to the eARC Then connect the other end to the ARC port

Press the "ARC" button on the remote to select

/ ARC port on the TV. of the soundbar. the "ARC" input. Note: Enable the "CEC" function on

the TV. After connecting ARC, the TV remote can control both the soundbar and the TV

simultaneously. 1 On/Off 2 Volume control

If there is no sound: try setting the TV audio output to PCM: TV Settings > Home > Settings

> Sound > Digital audio output > PCM

4 CONNECT TO TV VIA OPTICAL / AUX CABLE

OPTICAL AUX

DIGITAL AUDIO AUDIO IN

OUT R L

AUDIO OUTPUT

R L

OPTICAL

OPTICAL AUX

OPTICAL

OPTION 1: OPTICAL CABLE OPTION 2: AUX

1 1 Connect the 3.5 mm audio cable to RCA to connect it to the RCA AUDIO port

Make sure the TV port is OPTICAL OUT, connect both ends of the cable

to OPTICAL, both on the TV and the soundbar. OUT of the TV. 2 2 Ensure that the colors of the cable ends match the colors of the ports

Make sure the optical plug is correctly connected, as

shown in the picture. Do not connect the plug in reverse, as this may damage the optical connector. Note: Remember to disconnect the AUX cable from the TV and soundbar when

Note: If sound is playing through the TV's internal speakers, you want to switch to another

mode. mute or lower the volume of the TV. In optical mode: If you do not hear sound, try

setting the TV audio output to PCM: TV Settings > Home > Settings > Sound > Digital audio output >

PCM

5 CONNECT VIA BLUETOOTH

1 Press the “ ” button on the soundbar or remote to enter Bluetooth pairing mode. 2 Open the Bluetooth settings on your phone, find and select “Poseidon D70” to connect the soundbar.

Warning: If the device is already in Bluetooth mode and connected, press and hold the “ ” button for 3 seconds to disconnect the current device and manually connect to a new device using a mobile phone/computer/TV. Batteries are not included.

Poseidon D70

05

6 CONNECT THE SPEAKERS TO THE SOUNDBAR AND SUBWOOFER

FR (3 m) FL (3 m) SL (6 m) SR (6 m)

1 Use the front surround cables (FL and FR) to connect the soundbar and surround speakers. Make sure to match the interfaces of the same color in the surround speakers to the corresponding interfaces in the soundbar and properly position the surround speakers.

2 Use the rear surround cables (SL and SR) to connect the subwoofer and surround speakers.

Make sure to match the interfaces of the same color in the surround speakers to the corresponding interfaces in the subwoofer and properly position the surround speakers.

Note: After connecting the surround speakers as described above, looking from the front of the soundbar, the two surround satellite speakers on the right side will have red interfaces, and the two surround satellite speakers on the left side will have white interfaces. Ensure they are set correctly to provide optimal sound quality.

7 PAIRING THE SUBWOOFER

The subwoofer is factory paired with the soundbar. If there is no sound from the subwoofer, you need to re-pair the soundbar with the subwoofer.

5 s Step 1:

3s

Press and hold the "SUB PAIR" button on the remote for 3 seconds, and a message " " will appear on the display.

Step 2:

SUB

PAIR Press and hold the ON/OFF button on the subwoofer for 5 seconds, and the white LED will start blinking rapidly. The white LED will stay on steadily when the subwoofer is paired.

Step 2 . Step 1

8 PLACEMENT RECOMMENDATIONS

Full 360° surround sound

For better listening experience, arrange the entire system according to the diagram above.

06

9 WALL MOUNTING

Soundbar

41mm/1.6"

41mm/1.6"

30mm / 1.2" 310mm/12.2"

6.5mm/0.26"

Speaker

Note: The wall mount used for mounting the surround speakers is identical to the mount for the soundbar, so the spacing of the vertical holes is the same as for the soundbar, and the mounting method is also the same.

10 SPECIFICATION

Model number U2600

Power AC 100-240 V, ~50/60 Hz

Speakers 2.25" × 3 (soundbar) + 2.25" × 4 (surround speakers) + 6.5" (subwoofer)

Frequency response 35 Hz – 18 kHz

Power consumption in standby □ 0.5 W

Operating temperature -10°C – 45°C/14°F – 113°F

Dimensions and weight

Soundbar 400 (W) × 70 (H) × 90 (D) mm 15.7" × 2.8" × 3.5"

Subwoofer 185 (W) × 288 (H) × 260 (D) mm 7.3" × 11.3" × 10.2"

Surround speaker 135 (W) × 70 (H) × 90 (D) mm 5.3" × 2.8" × 3.5"

Packaging 476 (W) × 338 (H) × 346 (D) mm 18.7" × 13.3" × 13.6"

Net weight 7.8 kg / 17.2 lbs

Gross weight 10 kg / 22 lbs

07

SAFETY INSTRUCTIONS

Please read this user manual carefully and keep it for future reference. Do not make unauthorized modifications to the product, as this may affect safety, regulatory compliance, system performance, and void the warranty. Avoid dropping. Do not disassemble. Do not immerse in water. Avoid extreme temperatures. Do not use the device outdoors during a storm. Use original or certified cables. Do not place hazardous objects (e.g., liquid-filled objects, lit candles) on the device. Clean with a dry, soft, lint-free cloth. Do not use abrasive cleaners or oils. To avoid hearing damage, do not listen at high volume levels for extended periods. Do not expose batteries to extreme heat sources, such as direct sunlight or open flames.

power cables) in a place inaccessible to children under 8 years old. Do not allow children to charge the device on their own.

Ideal operating temperature for this product and its accessories is from 41°F/5°C to 95°F/35°C. The adapter should be installed near the device and should be easily accessible. Do not use this product in environments with extreme temperatures or cold. Never expose this device to strong sunlight or moisture. **INSTRUCTIONS FOR PROPER DISPOSAL** This symbol placed on the product or its packaging indicates that after the end of its useful life, the product should not be disposed of with other household waste. To prevent potential harm to the environment or human health from uncontrolled waste disposal, this product must be separated from other types of waste and recycled responsibly to promote the sustainable reuse of material resources. Waste electrical and electronic equipment Home users should contact the retailer from whom they purchased this product or the local

authority for detailed information on where and how to return this product for environmentally safe recycling. Business users should contact their suppliers and check the terms of their purchase agreement. The product should not be mixed with other commercial waste for disposal. CE WARNINGS 1) Do not install this device in an enclosed or built-in space, such as a bookshelf or similar furniture, and ensure good ventilation. Do not obstruct ventilation by covering ventilation openings with items such as newspapers, tablecloths, curtains, etc. 2) WARNING: To reduce the risk of fire or electric shock, do not expose this device to rain or moisture. The device should not be exposed to dripping or splashing water, and objects filled with liquids, such as vases, should not be placed on the device. 3) WARNING: The adapter plug serves as a disconnect device and should remain readily operable. 4) Frequency: 2.402 GHz–2.48 GHz 5) Maximum transmission power: 10 dBm This document is a translation of the original user manual created by the manufacturer. Detailed information about the distributor/manufacturer warranty conditions is available at <https://serwis.innpro.pl/gwarancja> The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. In the absence of information about necessary periodic or service maintenance actions in the user manual, the user should regularly, at least once a week, assess the physical condition of the product against that of a physically new product. If any deviation is detected or noted, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detecting a deviation may lead to permanent damage to the product. The warranty does not cover damages resulting from neglect. Warnings and safety information All information regarding the operation of the device can be found in the user manual. Before you start using it, familiarize yourself with its content and follow the instructions contained therein. Before use, also familiarize yourself with the following information: Usage warnings Speaker usage safety: Avoid exposing the speaker to moisture, rain, or liquids – unless the product has declared waterproofing (e.g., IPX). Do not use the speaker near open flames or high-temperature sources, such as heaters. • Avoid exposing the speaker to moisture, rain, or liquids – unless the product has declared waterproofing (e.g., IPX). • Do not use the speaker near open flames or high-temperature sources, such as heaters. Risk of electromagnetic interference (EMC): The Bluetooth function may cause interference with the operation of medical devices, such as pacemakers. Maintain a safe distance from such devices. Avoid using the speaker near other electronic devices that may be susceptible to interference. • The Bluetooth function may cause interference with the operation of medical devices, such as pacemakers. Maintain a safe distance from such devices. • Avoid using the speaker near other electronic devices that may be susceptible to

interference. Child safety: The product is not a toy. Store the speaker and its accessories (e.g., power cables) in a place inaccessible to children under 8 years old. Do not allow children to charge the device on their own. • The product is not a toy. Store the speaker and its accessories (e.g.

power cables) in a location inaccessible to children under 8 years old. • Do not allow children to charge the device independently. Battery and charging safety: Use only original chargers or cables supplied by the manufacturer. Do not charge the speaker near flammable materials. If you notice any damage to the battery or excessive heating of the device, immediately stop using it and contact service. • Use only original chargers or cables supplied by the manufacturer. • Do not charge the speaker near flammable materials. • If you notice any damage to the battery or excessive heating of the device, immediately stop using it and contact service. Information on proper usage Bluetooth setup: Before first use, ensure that the speaker has been paired with the device according to the user manual. The Bluetooth function works best at a distance of up to 10 meters without obstacles. Avoid connecting to incompatible or unsecured devices. • Before first use, ensure that the speaker has been paired with the device according to the user manual. • The Bluetooth function works best at a distance of up to 10 meters without obstacles. • Avoid connecting to incompatible or unsecured devices. Sound recommendations: To protect your hearing, avoid listening to music at maximum volume for extended periods. Do not place the speaker in locations where vibrations may cause it to fall. • To protect your hearing, avoid listening to music at maximum volume for extended periods. • Do not place the speaker in locations where vibrations may cause it to fall. Storage and maintenance: Store the speaker in a dry place at a temperature between 0°C and 40°C. Regularly clean the casing with a soft, dry cloth. Do not use chemicals or damp materials if the device is not waterproof. • Store the speaker in a dry place at a temperature between 0°C and 40°C. • Regularly clean the casing with a soft, dry cloth. Do not use chemicals or damp materials if the device is not waterproof. Additional precautions • Software updates: Regularly check for software updates for the device to improve performance and Bluetooth security. Download software only from the manufacturer's website. • Regularly check for software updates for the device to improve performance and Bluetooth security. • Download software only from the manufacturer's website. • Privacy security: When using the Bluetooth function, ensure that the device is visible only to your paired devices to avoid unauthorized access. • When using the Bluetooth function, ensure that the device is visible only to your paired devices to avoid unauthorized access. SIMPLIFIED EU DECLARATION OF CONFORMITY Utimea Technology (Shenzhen) Ltd.

hereby declares that the radio device type Soundbar Utimea Poseidon D70 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following website: <https://files.innpro.pl/> ultimea Manufacturer's address: 20th Floor, Building 4, Tianan Cloud Park, Bantian St., Longgang District 4 518000 Shenzhen, cn Radio frequency: 2.4GHz (2480MHz - 2483.5MHz) Maximum radio frequency power: <20dBm Environmental Protection Waste electrical and electronic equipment marked in accordance with the European Union directive must not be disposed of together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The waste collection system complies with locally applicable environmental regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, waste management facility, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning safety, health protection, and environmental protection, specifying hazards that should be detected and eliminated. Importer: INNPRO Robert Błędowski sp. z o.o. Rudzka 65c 44-200 Rybnik, Poland tel. +48 533 234 303 hurt@innpro.pl www.innpro.pl EU representative: Utimea GmbH Buchenring 57 22539 Hamburg, Germany support@ultimea.com Declaration of conformity We (the manufacturer is responsible for this statement) EN 55032:2015/A1:2020 EN Utimea Technology (Shenzhen) Limited (company name) 55035:2017/A11:2020 EN IEC 61000-3-2:2019/A1:2021 EN 20.

floor, building 4, Tianan Cloud Park, Bantian St., 61000-3-3:2013/A2:2021

Longgang District Shenzhen, China 518000 (company address)

ETSI EN 301 489-1 V2.2.3 (2019-11)

ETSI EN 301 489-17 V3.2.4 (2020-09)

We declare under our sole responsibility that the product Mark

ETSI EN 300 328 V2.2.2 (2019-07)

trade name: ULTIMEA

Product name: Poseidon D70 7.1-channel virtual soundbar with EN 50663: 2017

surround sound Model No.: U2600 EN IEC 62368-1:2020+A11:2020 IEC 62321-3-1:2013

The product to which this declaration relates is compliant with

IEC 62321-4:2013+A1:2017 IEC

the essential requirements set out in the Council directive on

62321-5:2013

the approximation of the laws of the member states

IEC 62321-6:2015

relating to the RED directive (2014/53/EU) and RoHS

IEC 62321-7-1:2015

(2011/65/EU). The product bears the CE mark and complies with

the following standards: IEC 62321-7-2:2017

IEC 62321-8:2017

Name and surname: Yoyo.Yu

Position: approval manager

Signature:

Place/date: Shenzhen, China / May 6, 2024 Trademarks:

The Bluetooth® name and logo are registered trademarks owned by Bluetooth SIG, Inc. and are used by Soundlab

Technology Co., Ltd. under license. Other trademarks and trade names are the property of their respective owners. The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI logo are trademarks

or registered trademarks of HDMI Licensing Administrator, Inc. Poseidon D70 7.1 Channel Virtual Surround Soundbar Utimea Technology (Shenzhen) Limited

Model No.: UC00Q

Utimea GmbH

Buchenring 57, 22359 Hamburg, Germany If you need our support, kindly reach out to our service

team. We are always glad to help. +1 888-598-8875 (US)

@Dynanic Inc. All rights reserved, registered in the United States and Mon-Fri 9am-5pm (PST)

other countries. +49 89-628-25828 (EU)

9804 Crescent Center Drive, Suite 604, Rancho Cucamonga, CA 91730 Mon-Fri 9am-5pm (CET)

support@ultimea.com

support.ultimea.com