



Jump Starter JS-One

USER MANUAL

Packing List

English



Jump Starter



Smart Clamps



DC Cigarette
Lighter Adapter



USB To
Type-C Cable




Carrying Case



User Manual

Layout



	Function	Situation
1	LED Flashlight	Normal, Strobe, SOS
2	Compass	Direction
3	Power Button	• Press the button to show the remaining capacity. • Long press the button to turn on / off the flashlight. • When the flashlight turn on, press the button to change the flashlight.
4	Power Level Indicator Lights	Showing the charging progress: 25%, 50%, 75%, 100%
5	Type-C Input Port	Charge the starter
6	EC5 Output Port	Insert the plug into the jump starting port
7	USB Output Port 1	Charge your phone, tablet, camera, etc. 75% faster than a standard charge
8	USB Output Port 2	Charge your phone, tablet, camera, etc.
9	DC 12V-16V/10A Output Port	Charge your devices
10	ON / OFF Button	Turn ON / Turn OFF the jump starter
11	LED Indicator	Show the work status of the battery clamp
12	Battery Clamps Plug	Insert the plug completely into the jump starter
13	Red Battery Clamp	Connect to positive terminal of the car battery
14	Black Battery Clamp	Connect to negative terminal of the car battery

Specifications

Car Jump Start Output	12V
DC Output	12V-16V/10A
Type-C Input	5V/2A, 9V/2A, 12V/1.5A
USB1 Output	5V/3A, 9V/2A, 12V/1.5A
USB2 Output	5V/2.4A
LED Light Power	White: 1W
Charging Time	Type-C Input: 4h-4.5h
Unite Size (L * W * H)	170mm * 87mm * 47mm

Operation Guide

Power Level Indicator Lights

Press the Power Button to check the battery power level of the Jump Starter.

The number of solid lights indicates the battery level.

Indicator Lights	1 Solid	2 Solid	3 Solid	4 Solid
Battery Capacity	25%	50%	75%	100%

Charging your Jump Starter



• At Home :

1. Plug the USB cable into computer or any USB 2A wall adaptor (not included).
2. Connect the Type-C port into the Jump Starter.

• In Car :

1. Plug the car adaptor (not included) into the socket.
2. Connect the Type-C port into the Jump Starter.

NOTE: It is recommended to recharge the Jump Starter every 3-4 months to maintain the efficiency and prolong the service life of the internal battery even if the unit has not been used.



Charging your Smart Phones or any other Devices

Your Jump Starter comes with two USB charging ports located at the front of the unit:

- Plug the USB cable into the USB output ports on your Jump Starter.
- Connect it to your phone, tablet or other devices you want to charge. You can charge 2 devices at the same time.
- Power on your Jump Starter to start charging!

Flashlight

1. Please press & hold Power Button for 3 seconds to turn on / off the flashlight.
2. In flashlight mode, press Power Button to select from 5 modes (normal strobe, SOS, warning, off).

Jump Starting a Vehicle

By owning a Jump Starter, you have everything you need to jump start a vehicle —no need to wait for help, JS-One to the rescue!

We know you're excited, but before jumping your vehicle, please be sure to take some precautionary steps:


- Read your vehicle owner's manual first as the manufacturer may have specific steps and precautions that pertain to your vehicle.
- Be sure to turn off all electronics in your car (radio, lights, etc.) before jump starting.
- Make sure you are in a dry, well-ventilated area. Never jump start a vehicle in an enclosed area.
- Remove any moisture from your JS-One unit, accessories, and your vehicle's battery. Never attempt to jump start a vehicle when moisture is present.
- Check that the vehicle's battery terminals are clean to ensure the best conductivity.
- Properly identify the vehicle battery's positive (+, red) and negative (-, black) terminals before connecting the clamps.
- When using the clamps, do not allow the metal teeth of the black clamp to touch the metal teeth of the red clamp.

- When using the clamps, DO NOT connect the RED clamp to the vehicle battery's negative (-) terminal, or the BLACK clamp to the vehicle battery's positive (+) terminal.
- When connecting smart clamps to the battery terminals, ensure the copper teeth on each side of the clamp make good contact with the terminal. The better the connection, the easier it will be to start your vehicle.


NOTE: When adjusting the clamps please be sure to disconnect your Jump Starter first. This will prevent the occurrence of minor sparks.

• How to Jump Start Your Car

Step 1: Insert the plug of the battery clamps completely into the jump starter, the red and green lights flashing alternately.




Step 2: Connect the red clamp to the positive electrode (+) of the car battery and the black clamp to negative one (-). The green light is always on.




Step 3: Start the vehicle.

If the engine does not start on the first try, disconnect it from the car battery and wait for at least 20 seconds before reconnecting.



Step 4: When the vehicle is started, remove the battery clamp from the car battery and the jump starter within 30 seconds.



In any of the following situations, the smart clamp turns protection on:

LED Indicator	Situations
The red / green light flashing alternately	Ready to work
The green light is always on	Work status
The red light is always on and sound an alarm	1. Battery clamp is reversely connected Please check whether the clamp is reversely connected. 2. The clamp is short-circuited Please check whether the red and black clamps together connect or connect both cable clamps to the same piece of metal.
The red light flashing	Low power of the jump starter Please try to replace the startup power supply or charge it in time.

Important Safety Information

WARNING: Read all instructions and warnings prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion, for which Corporation is not responsible.

- Always read all instructions carefully before using your Jump Starter.
- Do not submerge your Jump Starter in water, or expose it to rain or moisture.
- Never open or disassemble your Jump Starter as it will void your warranty.
- Do not expose your Jump Starter to fire, intense heat, or flammable liquids.
- Keep away from and out of reach of children.
- Do not insert foreign objects into ANY inputs or outputs.
- Do not allow the metal teeth of the red clamp to touch the metal teeth of the black clamp when connected to your Jump Starter.
- Do not connect the black clamp to the vehicle battery's positive(+) terminal when connected to your Jump Starter. Do not connect the red clamp to the vehicle battery's negative(-) terminal when connected to your Jump Starter.
- Do not open your Jump Starter to replace the internal battery. No user-replaceable parts are inside your Jump Starter.
- Always disconnect the jump start cables from your Jump Starter after use and store separately.
- For protecting this unit, make sure the battery capacity of jump starter is above 75% before jumping start your car.
- Check the power of the product at least every three months, and charge the product in time.

CUSTOMER SUPPORT

If you meet any questions or problems, please feel free to contact us by Email or Facebook anytime, we will try our best to help you as soon as possible.

Contact Us by Email: marketing@utrai.com

Find News, Deals, and Events on our official website and social medias. You can also download Electronic User Manual on our official website. Watch product Unboxing Videos by influencers and How-to Videos on our Youtube channel.



Official Website
www.utrai.com



Facebook
[@utraicompany](https://www.facebook.com/utraicompany)



Youtube
UTRAI Company