

Colmi V75 smartwatch (μαύρο)

COLMi · EAN 6972436985807

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

We invite you to use our high-performance smartwatch to create

2.1.3 Screen switching:
Based on the main watch face, hold the screen to 4. Da Fit app features 12. Quick screen preview: Wake up the screen (open and select an important time period)

a thoughtful health experience. switch between different watch faces. The watch face can be downloaded from the app. As a watch face, you can 4.1 Data synchronization 13. Water drinking reminder: It is recommended to drink at least 1955 ml of water every day

Before use, it should be fully charged. upload favorite photos. All measurement data from the watch will be synchronized with the Da Fit app (upon opening, you can customize the start time, drinking frequency, and drinking interval)

App: Da Fit 2.2 Function menu mobile phone, such as step count, sleep monitor, heart rate, blood pressure, 14. Weather (open the Weather tab, select the desired city or locate it automatically,

1. Downloading and pairing 2.2.1 Activity recording (step recording) blood oxygen level and other data, as shown in the figure below. if not, the band will display the weather in the located city)

1.1 Press and hold the side button to open. 4.2 Watch connection interface 15. Physiological cycle reminder

1.2 Scan the QR code below to install the Da Fit app, or download "Da Fit" from 4.2.1 Watch face (multiple interface options, 1 custom watch face, users can (Note: please remember that the above functions work based on activation and saving the app store and install it from Google Play.

manually replace images or user-defined photos) appropriate settings)

V75 Compatible systems: Android 4.4 and newer, iOS 8.0 and newer 2.2.13 Player (music playback BT; press the center icon to pause or

GPS sport mode requires waiting for GPS positioning to complete 2.2.6 Bluetooth

Connections continue, press the left icon to play the previous track, press the right

Frequently Asked Questions

icon to play the next track) Why does the smartwatch automatically disconnect Bluetooth

after the system screen

User Manual is turned off? The startup takes about 30 seconds, rebooting takes about 15 seconds). It is recommended to use the device in open spaces. Any Note: These measurement data are for reference purposes only and should not be used for medical purposes. will disconnect from the phone. 1> Close the app running in the background. After the Da Fit app process is completed, the smartwatch buildings may cause deviations in positioning. be used for medical purposes. will disconnect from the phone. 2> Set the app to autostart

2.2.2 Sleep Monitor 3> Grant the app unrestricted background operation rights. Android phones that install

Sleep monitoring time: from 8:00 PM to 10:00 AM.

Make sure you wear the wristband.

4.2.2 Notification (Open the push message from social media applications, such as WeChat, Facebook, WhatsApp, Twitter, etc.)

2.2.7 Altitude Pressure Function (Pressure is measured using a barometer, and altitude is calculated based on the barometric value. Altitude can change daily and is related to the weather. The altitude function is used only during climbing, and as the altitude increases, the value changes depending on how many meters the altitude rises.)

2.2.14 Push Notifications (Open the Da Fit social media app "Notifications")

1> Make sure you have enabled push notifications in the app.

Pay attention to the settings on your Android phone: Da Fit app/notifications

2> Make sure the message can be normally displayed on the notification bar.

1.3 Open the mobile app and select the device to be connected on your mobile phone.

Sending messages to the smartwatch is done through reading messages on the notification bar of the phone. If there are no messages on the notification bar of the phone, the smartwatch will not receive notifications.

Step 1: Turn on Bluetooth on your phone.

2.2.5 Sports (107 sports modes: walking, running, cycling, jump rope, badminton, basketball, soccer, etc.) All exercise data for this week)

Step 2: Open the "Da Fit" app and press "Add Device" to connect.

4.2.3 Alarm (3 options)

Why can't the smartwatch receive push notifications? (Only for downloading the app)

2.2.11 Weather (Swipe up on the screen to display weather information)

will be synchronized with the mobile application Da Fit App push. (You need to find the notification settings in your phone settings and enable notifications for WeChat, QQ, Call,

SMS, and mobile applications). Step 3: Open the phone menu on the watch. Step 4: Open phone -> Settings. Type "Notification usage rights" in the top field 2.2.3 Heart rate monitor (if 24-hour monitoring is required, you need to open 4.2.4 Snapshot and reopen Da Fit. 3. the "All-day heart rate" option in the "Other" menu in the Da Fit app). reminder for sedentary lifestyle, all-day heart rate monitoring, all-day stress, power-saving mode, unit format, screen time, quick screen preview, heart rate warning, handwashing reminder, weather, drinking reminder, cycle reminder Why can't you use the smartwatch during a hot bath? Answer: The water temperature in the shower is relatively high and generates a large amount of steam. This steam creates a low molecular radius gas phase that can easily penetrate the smartwatch through the gap between the outer casing. When the temperature drops, the steam condenses into liquid droplets, which can easily cause internal short circuits in the smartwatch, damage the circuit board, and ultimately damage 2.2.8 Compass function (requires calibration by shaking, place the watch flat on a horizontal surface during measurement) 1. Open the "Find My Watch" mode. Once the Bluetooth connection between the phone and the smartwatch is successfully established, it will start vibrating and emitting sound 2. Time format (2 options for 12-hour and 24-hour format) Step 4: Check the last four digits of the MAC address in the "About" menu of the watch, such as "0000", and then go to "Set Bluetooth" on the phone and search for this 2.2.12 Snapshot Do Not Disturb mode 3. Do Not Disturb settings mode Battery level 4.

Reminder for prolonged sitting (important from 10:00 to 22:00) smartwatch. Use the Bluetooth name "0000" as the last four digits to end the connection - press the icon to take a photo. Connection status with the app 5. All-day heart rate monitoring (enabling allows detection of all-day heart rate) not BT, as shown below. Note: Turn on the connection switch in the menu IOS: Type "shutter" in the app, make sure the camera is enabled in Configuration 6. Stress throughout the day: (Upon opening, the smartwatch will record stress levels in real-time) shake the watch or press the icon. Brightness adjustment of watch settings. The iOS app will display a window to check if 2.2.4 5 exercise modes GPS (GPS Walk, GPS Run, GPS Outdoor Cycling, GPS Off-road Running, GPS Hiking). Select the desired exercise mode, start the test, and display all exercise data: distance, calories, heart rate, as follows Quick display of QR code 8. Unit format: metric/imperial selection 2. Watch functions mobile app Da Fit. As shown in the figure; The sliding screen on the left allows you to exit Flashlight 9. Backlight time setting: (backlight time can be selected from 5-30 seconds) 2.1 Time interface When using the GPS function for the first time, it is necessary to connect to the app to update ephemeris data to be able to use it normally. or pause the exercise test.

As shown in the figure; The sliding screen on the left can be hidden. 10. Heart rate warning: (By default, the user's maximum heart rate is 187 BPM. If exceeded - 2.1.1 Turning on: Press and hold the side button for 3 seconds. update ephemeris data to be able to use it normally. The sliding screen on the left can be hidden.

if the default value is displayed, a warning will appear)

2.1.2 Turning off: In the time interface, press the side button for 3 seconds, and

2.2.9 Blood pressure monitoring (press the monitoring screen)

11. Hand washing reminder: (After turning on, you can adjust the start time, the number of cycles

Note: These measurement data are for reference purposes only and should not of hand washing and the number of hand washing cycles)

then press the "√" icon to turn off the device

be used for medical purposes. Safety precautions

Warnings and safety information

SIMPLIFIED EU DECLARATION OF CONFORMITY

All information regarding product usage can be found in the user manual. Before you start using it, familiarize yourself with its

content and follow the instructions contained therein. Shenzhen Colmi Technology Co., Ltd. hereby declares that the type

Before charging, check that the device contacts are clean. Also, familiarize yourself with the following information before use:

Warnings regarding the use of the

Smartwatch radio device, V75 is compliant with Directive 2014/53/EU. Never leave the device unattended during use and charging. Risk of damage to the device:

The full text of the EU declaration of conformity is available at the following address online:

Make sure you can quickly disconnect the device from the power source in an emergency.

● Avoid exposing the smartwatch to extreme temperatures, moisture, and chemicals that may affect its durability and

functioning. ● Do not expose the smartwatch to drops, impacts, and other factors that may contribute to its damage. <https://files.innpro.pl/colmi>

Never expose the device to high temperatures. ● Do not use the smartwatch if you notice any damage, such as a cracked display, damaged buttons, or a flooded

case. Product code

V75

Manufacturer's address:

Charge the device in a dry and well-ventilated place away from flammable materials, keeping a minimum distance of 1m from other objects. ● The smartwatch should be used according to the manufacturer's recommendations to avoid damage resulting from improper use. Room 320, Building 3, Zone A, Xixiang Street Internet Industry Base, Shen-
Never cover the device while charging. ● Do not expose the smartwatch to contact with water unless the manufacturer declares its waterproofness.

● If the smartwatch is waterproof, before submerging it in water, check the integrity of the casing and ensure that its components do not show signs of damage or wear. EAN Code 6972436985807

zhen, Guangdong, China Never use a power supply, charging station, cables, etc., without the manufacturer's recommendations and certification. Radio frequency: 2400~2480MHz
Hazard to children:

● The smartwatch is not intended for children. Take care of your property; the device is equipped with batteries that are difficult to swallow. ● The smartwatch and its accessories may pose a choking hazard. Battery category Portable battery
Maximum radio frequency power: <20dBm If a fire occurs, equip yourself with a fire blanket.

● Store the device in a place inaccessible to children to prevent accidental swallowing of small parts or improper use. Battery type Portable batteries

Environmental protection Lithium-ion battery Risk of skin irritation:

● Ensure that you are not allergic to any of the materials used in the production of the smartwatch. ● If you notice signs of irritation, redness, or rash in the area where the smartwatch is worn, stop using it and consult a doctor. Lithium-polymer (Li-Po)

Used electronic equipment marked according to the European Union directive must not be disposed of together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may vary from that declared in the offer and is not a defect of the device but a feature of the product. To maintain maximum battery life, it is not recommended to discharge it below 3.18V or 15% of total capacity.

Risk of electric shock:

● Use only original chargers and cables supplied with the device or approved by the manufacturer. ● Regularly check the condition of cables, chargers, and connectors – replace damaged components with new ones before further use. Wireless connectivity

Net weight (kg) 0.01072

Lower values, such as ● Only use applications recommended by the manufacturer and downloaded from trusted sources. the risk factors that should be detected and eliminated. 2.5V for the cell permanently damages them and this is not covered by the warranty. In case of ● Secure your data with a password and enable two-factor authentication if available. Capacity (mAh) 650 This document is a translation of the original user manual created by the manufacturer. ● Avoid using the battery or the entire device for longer than one month; the battery should be charged to 50% and its charge level should be checked every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. Detailed information about the distributor/manufacturer warranty conditions is available at <https://serwis.innpro.pl/gwarancja> Proper usage information Wearing and fitting: ● Ensure that the smartwatch is properly fitted to your wrist to ensure comfort and accuracy of sensor readings. The strap should not be too tight or too loose. The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. In the absence of information about necessary maintenance actions or service in the user manual, the physical condition of the product should be assessed regularly, at least once a week, to evaluate any deviation from a physically new product. If any deviation is detected or identified, urgent maintenance (cleaning) or service steps should be taken. Lack of proper maintenance (cleaning) and response upon detection of a deviation may lead to permanent damage to the product. The warranty does not cover damage resulting from neglect. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal operating conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the device but a feature of the product. Cleaning and maintenance: ● Regularly clean the watch with a soft cloth to remove dust, sweat, and other dirt. ● Avoid using strong detergents or sharp tools that may damage the device. ● Store the smartwatch in a dry place to prevent damage from moisture. Charging: ● Always use the original chargers and cables included with the smartwatch or those approved by the manufacturer. ● Avoid charging the smartwatch for too long to prevent battery damage. ● Only connect the device to outlets that meet the technical requirements of the smartwatch.

To maintain maximum battery life, it is not recommended to discharge it below 3.5V or 5% of total capacity. Lower values, such as 3.2V for the cell, permanently damage it and are not covered by warranty. In case of discontinuing the use of the battery or the entire device for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures.

Additional precautions

Importer:

Service and maintenance:

- In case of any issues with the smartwatch, contact an authorized service center for repair or replacement. Do not attempt to repair the device yourself.

Representative in the EU:

INNPRO Robert Błędowski sp. z o.o.

Apex CE Specialists GmbH

ul. Rudzka 65c

Habichtweg 1, 41468 Neuss, Germany

44-200 Rybnik, Poland

info@apex-ce.com

tel. +48 533 234 303

Safe disposal:

- Used smartwatches and components such as batteries should be disposed of in accordance with local regulations regarding electronic waste. If you need additional information regarding the product, contact customer service (email: hurt@innpro.pl, website: <https://innpro.pl/>) or another specialist.

www.innpro.pl