

Γυαλιά ηλίου Colmi V06 AI White Sports (με μπλε φακούς)

COLMi · EAN 6972436986958

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

User Manual

Camera Touch Panel Speaker

Function Button

Port Charging Indicator Status

Light Microphone Photo

On/Off

Turning On: Press and hold the right button for 2 seconds

Turning Off: Press and hold the right button for 5 seconds

(Note: The device will automatically turn off after 5 minutes without a connection. If the connection is not established, a restart of the device is indicated.)

Pairing with Phone

Scan the code to download the app

Playing Music

Play/Pause: Double tap the touch control area

Skip Tracks: Press and hold the touch control area for 2 seconds to go to the next track; press three times to go to the previous track

Volume Control

Increase Volume: Slide the right slider forward

Decrease Volume: Slide the right slider backward

Photos/Videos/Recordings

Take a Photo: Press the right physical button once

Record a Video: Press the right physical button twice (when not on a call or playing)

Stop Recording: Press the right physical button once while recording

Start Recording: Press the left physical button twice (when not on a call or playing)

Stop Recording: Press the left physical button once while recording

(Note: 1. Photos, videos, and audio recordings can be transferred via the app. To ensure stable transmission over Wi-Fi, it is recommended to connect the device to a charger before

starting the transfer. 2. To protect the privacy of bystanders while taking photos, recording videos, or capturing audio, a control light is activated as a reminder.)

Activating Voice Assistant

AI Voice Assistant: Press the left physical button once

Phone Voice Assistant: Press and hold the left physical button for 2 seconds

Phone Calls

Answer/End Call: Press the physical button on the left/right side once

Reject Call: Press and hold the physical button on the left/right side for 2 seconds

Charging

Magnetic Charging: A red LED lights up during charging, and after fully charged, a blue LED lights up continuously

Factory Reset

Factory Reset: Press and hold the right button for 10 seconds. (Note: This will restore factory settings and erase all data from the glasses.)

Deleting Pairing Information

Delete Pairing Information: Press and hold the left physical button for 7 seconds. (Note: This will erase pairing information of connected devices.)

SIMPLIFIED EU DECLARATION OF CONFORMITY

Shenzhen COLMI Technology Co., Ltd hereby declares that the type of radio equipment Sports Glasses Colmi V06 A is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following website: <https://files.innpro.pl/colmi>
Manufacturer's Address: Xixiang Street Bao'an Internet Industrial Base Room 320-321, 3 bldg / Haoye community 0000 Baoan District, Shenzhen City, Guangdong China

Radio Frequency: 2400MHz-2483.5MHz

Maximum Radio Frequency Power: <20dBm

Environmental Protection

Used electronic equipment marked in accordance with European Union directive must not be disposed of together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The system for collecting used equipment complies with locally applicable environmental protection regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, waste management facility, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning safety, health protection, and environmental protection,

identifying hazards that should be detected and eliminated. This document is a translation of the original user manual created by the manufacturer. Detailed information about the distributor/manufacturer warranty conditions is available at the website

<https://serwis.innpro.pl/gwarancja>

The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility.

In the absence of information about necessary periodic maintenance or service actions in the user manual, the physical condition of the product should be assessed regularly, at least once a week, to determine any deviation from a physically new product. If any deviation is detected or identified, urgent maintenance (cleaning) or service steps should be taken.

Failure to perform proper maintenance (cleaning) and to respond upon detecting a deviation may lead to permanent damage to the product. The guarantor is not responsible for

damages resulting from negligence. Importer: INNPRO Robert Błędowski sp. z o.o. ul. Rudzka 65c 44-200 Rybnik, Poland tel. +48 533 234 303 hurt@innpro.pl www.innpro.pl Safety

precautions Before starting to charge, check if the device contacts are clean. Never leave the device unattended while in use and charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high

temperatures. Charge the device in a dry and well-ventilated place away from flammable materials, maintaining a minimum space of 1m from other objects. Never cover the device while charging. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and certification. Take care of your property; the device is equipped with cells that are difficult to extinguish, so have a fire blanket on hand. LI-ION

Battery The device is equipped with a LI ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the

device but a feature of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.18V or 15% of total capacity. Lower values, such as 2.5V for the cell, cause permanent damage and are not covered by warranty. If the

battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level checked periodically every two months. Store the

battery and device in a dry place, away from sunlight and negative temperatures. LI-PO

Battery The device is equipped with a LI PO (lithium-polymer) battery, which, due to its

physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the device but a feature of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.5V or 5% of total capacity. Lower values, such as 3.2V for the cell, cause permanent damage and are not covered by warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. Battery data: Type: Portable lithium-ion batteries (Li-Ion) Net weight: 0.004323 kg Capacity: 260mAh Power: 0.001 kWh Exceeded permissible cadmium content (0.002%) or lead (0.004%): no Battery serial number: ST 501240 Manufacturer Shenzhen COLMI Technology Co., Ltd Xixiang Street Bao'an Internet Industrial Base Room 320-321, 3 bldg / Haoye community 0000 Baoan District, Shenzhen City, Guangdong China sarahwu@colmismart.com Responsible entity Apex CE Specialists GmbH Habichtweg 1 41468 Neuss Germany info@apex-ce.com