


meross

User Manual


■ Safety Information

1. Do NOT operate this product with wet hand.
2. Do NOT touch the atomization piece, or it could be damaged.
3. Do NOT switch on the sprayer when the water tank is empty.
4. Do NOT move the product when it is working.
5. Do NOT tilt the product or put it on unstable surface to prevent water leakage.
6. Do NOT use hot water over 40 °C or 104 °F.
7. Do NOT tear down the product on your own.
8. Do keep the power adapter and the product base dry before power on the product.
9. Do place the product away from child, pet, and electronic home appliances.
10. Do clean the water tank every 3~5 days to keep the product clean.

■ Package Contents



1 x Smart Wi-Fi
Essential Oil Diffuser



1 x Power Adapter




1 x Measuring
Cup



1 x User Manuel

■ LED and Button Rules



① LIGHT Button

Short press to turn on ambient light and cycle the color.

Long press 5s to turn off the ambient light.

② MIST Button

Short press to switch among off mode, light spray mode, and heavy spray mode.

Long press 5s to reset the product.

③ Ambient LED

④ Status LED

Flashing green (once/sec): Ready for pairing.

Flashing green (twice/sec): Pairing or resetting.

Solid green: Wi-Fi connected and working normally.

DC

3.5*1.35mm

Input: 24V/0.65A

■ Installation Guide

- Hardware Installation




Fig1




Fig2




Fig3




Fig4




Fig5




Fig6

1. Detach the upper cover.
2. Plug in the power cable and place the product onto a stable surface.
3. Use the measuring cup to add water and then add 2~3 drops of essential oil for each 100ml water. Do NOT add when the power is on. Do NOT exceed the MAX mark in the water tank.
4. Attach the cover and plug the power adapter in a socket. You will hear the product “Beep” once.
5. Short press the LIGHT button to turn on the ambient LED light. The color will start to cycle automatically. If you prefer a certain color, you can short press the LIGHT button again to keep the current color. Short press the LIGHT button again and then the color will start to cycle automatically again. Long press the LIGHT button will turn off the ambient LED light.
6. Short press the MIST button to turn on the sprayer. Each time you short press the button, the product will cycle among light spray mode, heavy spray mode, and off. Long press the button will reset the product.

Attention:

1. If the product is knocked over by accident or water leaked accidentally, please unplug the power adapter immediately and then dry the product.
2. The amount and density of the spray vary slightly on different devices. It depends on water you use, temperature and humidity of the environment, and air flow in your room. It's not a product defect.
3. The product will power off automatically when water runs out.
4. Please use natural essential oil only. Any chemical ingredients might damage the product.


5. Before you use a new essential oil, please follow the maintenance instruction and clean the product.
6. Please pour out remaining water if the product is not used for a long time.
7. Take care to wipe away any water droplets that accidentally stick to the surface of the device to prevent damage and corrosion.

- Software Installation

1. Download the Meross App.



2. Plug MOD150 into an outlet near home Wi-Fi.



- * Proximity to home Wi-Fi required only during the initial setup process.
- * MOD150 only supports 2.4GHz networks.

3. Set up the device.

1. Connect your smartphone or tablet to a 2.4 GHz Wi-Fi network.
2. Make sure your smart device is covered by strong Wi-Fi signal.
3. The smart device supports iOS 13/ iPadOS 13 and later. It is recommended that you upgrade your iOS or iPadOS to the latest version before pairing with the smart device.
4. Launch the Meross app and log in to your account, or if you are a new user, tap Sign up to create a new account.
5. Tap the “+” icon to select the type of smart device you want to add, then you can just follow the setup wizard to finish configuration.

6. Relocation of the smart device does not require additional operations provided that it remains on the same network with strong Wi-Fi signal.

NOTE:

1. If this is not the first time you've added this smart device, you'll have to reset it before going any further.
2. As long as you finish configuration, you'll be able to manage the device in Apple Home app.
3. If the QR code does not work, please try to add the smart device in Apple Home app.
4. Find more at <https://www.meross.com/support>.

■ Link Meross to Google Assistant or Amazon Alexa

Set up the device in the Meross app and link it to the voice assistants.

Link to Amazon Alexa

Go to **Account-> Amazon Alexa** and allow Meross to link with Alexa.

Link to Google Assistant

Go to **Account-> Google Assistant** and follow the step-by-step instructions to complete the linking process.

■ Voice Control

Amazon Alexa:



Example commands are as follows:

- "Hi Alexa, turn off/on the device."
- "Hi Alexa, turn off/on the light of the device. "

Google Assistant:



Example commands are as follows:

- "Hey Google, turn off/on the device."
- "Hey Google, turn off/on the light of the device."

HomeKit Siri :



Example commands are as follows:

- "Hey Siri, turn off/on the device."
- "Hey Siri, turn off/on the light of the device. "

■ Maintenance

Clean the water tank every 3~5 days or when you want to use a new essential oil. Please follow steps below.

1. Unplug the power adapter and power cable, and then detach the cover.
2. Pour out remaining water from the right side as shown in the picture below.
3. Clean the water tank with a small amount of warm detergent. Wipe and dry the product with a swab. Do NOT use acid or enzymes detergent. Do NOT soak the product in water or let water go into the product.
4. Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
5. Do not permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the humidifier down. If the humidifier output volume cannot be turned down, use the humidifier intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
6. Unplug the appliance during filling and cleaning.
7. Never leave water in the reservoir when the appliance is not in use.
8. Empty and clean the humidifier before storage. Clean the humidifier before next use.

Warning: Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.



■ FAQ

At Meross, we strive to assure your satisfaction. Attached below is a non-exhaustive list of questions that users are mostly concerned about.

1. My diffuser can't be switched on.

- (a) Both the ambient light and the sprayer cannot be switched on.

Please ensure that the power cable was plugged properly.

- (b) The ambient light can be turned on, but the sprayer cannot be turned on. Please ensure that there is enough water in the water tank.

If your power adapter is plugged in properly and the water tank has enough water in it, yet your diffuser refuse to work, please contact us and we will help you figure it out.

2. The spray is too weak and cannot be switched to stronger mode.

It depends on water you use, temperature and humidity of the environment, and air flow in your room. Please try pure water, tap water, or distilled water to find the one best suit your diffuser.

3. How do I manage my Meross device in Apple Home app?

Your Meross smart device will be automatically added to Apple Home app after you finish configuration in the Meross app.

4. Why is my Meross smart device not responding in Apple Home app?

This is an existing issue with Apple Home app. You need to exit and reboot your Home app to fix this problem.