

Γυαλιά ηλίου Colmi V06 AI Black Sports

COLMi · EAN 6972436986934

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

User Manual

Camera Touch Panel Speaker

Function Button

Charging Port Indicator Microphone Status

Light for Photos

Power On/Off

Power On: Press and hold the right button for 2 seconds

Power Off: Press and hold the right button for 5 seconds

(Note: The device will automatically turn off after 5 minutes without a connection. If the connection is not established, a restart of the device is indicated.)

Pairing with Phone

Scan the code to download the app

Music Playback

Play/Pause: Double tap the touch control area

Skip Tracks: Press and hold the touch control area for 2 seconds to go to the next track; press three times to go to the previous track

Volume Control

Increase Volume: Slide the right slider forward

Decrease Volume: Slide the right slider backward

Photos/Videos/Recordings

Take a Photo: Press the right physical button once

Record a Video: Press the right physical button twice (when not on a call or playback)

Stop Recording: Press the right physical button once during recording

Start Recording: Press the left physical button twice (when not on a call or playback)

Stop Recording: Press the left physical button once during recording

(Note: 1. Photos, videos, and audio recordings can be transferred via the app. To ensure stable transmission over Wi-Fi, it is recommended to connect the device to a charger before starting the transfer. 2. To secure the privacy of bystanders while taking photos, recording videos, or capturing audio, a control light is activated as a reminder.)

Activating Voice Assistant

AI Voice Assistant: Press the left physical button once

Phone Voice Assistant: Press and hold the left physical button for 2 seconds

Phone Calls

Answer/End Call: Press the physical button on the left/right side once

Reject Call: Press and hold the physical button on the left/right side for 2 seconds

Charging

Magnetic Charging: A red LED lights up during charging, and after fully charged, a blue LED lights up continuously

Factory Reset

Restore Factory Settings: Press and hold the right button for 10 seconds. (Note: This will restore factory settings and erase all data from the glasses.)

Deleting Pairing Information

Delete Pairing Information: Press and hold the left physical button for 7 seconds. (Note: This will erase pairing information of connected devices.)

SIMPLIFIED EU DECLARATION OF CONFORMITY

Shenzhen COLMI Technology Co., Ltd hereby declares that the type of radio equipment Sports Glasses Colmi V06 A is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following website: <https://files.innpro.pl/colmi>
Manufacturer's Address: Xixiang Street Bao'an Internet Industrial Base Room 320-321, 3 bldg / Haoye community 0000 Baoan District, Shenzhen City, Guangdong China

Radio Frequency: 2400MHz-2483.5MHz

Maximum Radio Frequency Power: <20dBm

Environmental Protection

Waste electrical and electronic equipment marked in accordance with the European Union directive must not be placed together with other municipal waste. It is subject to selective collection and recycling at designated points. By ensuring its proper disposal, you prevent potential negative consequences for the natural environment and human health. The waste collection system complies with locally applicable environmental protection regulations regarding waste disposal. Detailed information on this can be obtained from the municipal office, waste management facility, or the store where the product was purchased. The product meets the requirements of the so-called New Approach directives of the European Union (EU) concerning safety, health protection, and environmental protection, identifying hazards that should be detected and eliminated. This document is a translation of the original user manual created by the manufacturer. Detailed information about the

distributor/manufacturer's warranty conditions is available at the website

<https://serwis.innpro.pl/gwarancja>

The product should be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility.

In the absence of information about necessary periodic maintenance or service actions in the user manual, it is recommended to regularly, at least once a week, assess the difference in the physical condition of the product compared to a physically new product. In case of detecting or identifying any differences, urgent maintenance (cleaning) or service steps should be taken. Failure to perform proper maintenance (cleaning) and to react upon detecting a state of difference may lead to permanent damage to the product. The manufacturer is not responsible for damages resulting from neglect. Importer: INNPRO Robert Błędowski sp. z o.o. ul. Rudzka 65c 44-200 Rybnik, Poland tel. +48 533 234 303 hurt@innpro.pl www.innpro.pl

Safety precautions Before starting to charge, check if the device contacts are clean. Never leave the device unattended while in use and charging. Ensure that you can quickly disconnect the device from the power source in an emergency. Never expose the device to high temperatures. Charge the device in a dry and well-ventilated place away from flammable materials, maintaining a minimum distance of 1m from other objects. Never cover the device while charging. Never use a power supply, charging station, cables, etc., without the manufacturer's recommendation and certification. Take care of your property; the device is equipped with cells that are difficult to extinguish, so equip yourself with a fire blanket.

LI-ION Battery The device is equipped with a LI ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the device but a feature of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.18V or 15% of the total capacity. Lower values, such as 2.5V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures.

LI-PO Battery The device is equipped with a LI PO (lithium-polymer) battery, which, due to its physical and chemical structure, ages over time and with use. The manufacturer specifies the maximum operating time of the device under

laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. Actual operating time may differ from that declared in the offer and this is not a defect of the device but a feature of the product. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.5V or 5% of the total capacity. Lower values, such as 3.2V for the cell, permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and its charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. Battery data: Type: Portable lithium-ion batteries (Li-Ion) Net weight: 0.004323 kg Capacity: 260mAh Power: 0.001 kWh Exceeded permissible cadmium content (0.002%) or lead (0.004%): no Battery serial number: ST 501240 Manufacturer Shenzhen COLMI Technology Co., Ltd Xixiang Street Bao'an Internet Industrial Base Room 320-321, 3 bldg / Haoye community 0000 Baoan District, Shenzhen City, Guangdong China sarahwu@colmismart.com Responsible entity Apex CE Specialists GmbH Habichtweg 1 41468 Neuss Germany info@apex-ce.com