

Pet trimmer 4 in 1 Oneisall

Oneisall · EAN 6934399223242

Machine translation from Polski. In case of doubt the manufacturer's original document prevails.

Clipping Machine for Paws

User Manual

Overview

Blades

Power button,

Speed adjustment

Indicator lights

Charging port

5V/USB

Specifications

Motor Operating voltage: 3 V

Battery type: 600mAh

Clipping machine Battery Charging time: 2h

for paws

Operating time: 2h

USB connection with adapter: 5V 1A

Charging

Power: 5W

Charging Mode

1. Insert the USB cable into the end of the clipping machine. 2. Connect 5V/USB using the adapter. 3. The charging indicator lights up during charging! For first use or if not used for over six months, charge the device for 2 hours.

Indicator lights

Speed indicator 2

Speed indicator 1

Charging indicator

Indication

Indicators Status

Speed 1 Green light Operates at low speed

on

Speed 2 Green light Operates at high speed

on

Speed 1 Green light Battery level

flashes is below 10%

Speed 2 Green light Battery level

flashes is below 10%

Red light Charging

Charging flashes

Charging Green light Fully charged

remains on

Cleaning and Maintenance

Turn clockwise and pull out the blade, which can be directly washed under water. Possibility of trimming in various areas. Product details

Standard cutting head Nail grinding head

For trimming pet hair For grinding pet nails

to avoid scratches

Small cutting head Narrow cutting head

For trimming hair around For trimming hair around claws, hips, and corners of eyes ears and legs of pets

INNPRO Robert Błędowski sp. z

o.o. ul. Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

hurt@innpro.pl

Manufacturer:

NANBANQIU TECHNOLOGY CO.,

LIMITED

Kin Tat Street Hang Wai Ind.Centre

H3 Hongkong

China

support@oneisall.com

Responsible entity in the EU:

Enbaoixin Germany Maternal and Infant

Supplies GmbH

Laubenhof 23

45326 Essen

Germany

jasvigor2020@hmail.com

![];tr❖![]

R\$ ammam

![] Plli.❖:Z

@Oneisall Official

This document is a translation of the original user manual, created by the manufacturer. The product should be regularly maintained (cleaned) by the user or by specialized service points at the user's cost and responsibility. If there is no information about necessary periodic or service maintenance actions in the user manual, the user should regularly, at least once a week, assess the physical condition of the product against that of a physically new product. If any deviation is detected or noted, urgent maintenance (cleaning) or service steps should be taken. Failure to properly maintain (clean) and respond upon detecting a state of deviation may lead to permanent damage to the product. The guarantor is not responsible for damages resulting from neglect. <https://serwis.innpro.pl/gwarancja>

LI-ION Battery

The device is equipped with a LI ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and usage. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. The actual operating time may differ from that declared in the offer and this is not a defect of the device but a characteristic of the product. To maintain maximum battery life, it is not recommended to discharge it below 3.18V or 15% of total capacity. Lower values, such as 2.5V for the cell, can cause permanent damage and are not covered by warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and the charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures.

LIPO Battery

The device is equipped with a LI PO (lithium-polymer) battery, which, due to its physical and chemical structure, ages over time and usage. The manufacturer specifies the maximum operating time of the device under laboratory conditions, where optimal working conditions for the device exist, and the battery itself is new and fully charged. The actual operating time may differ from that declared in the offer and this is not a defect of the device but a

characteristic of the product.

To maintain maximum battery life, it is not recommended to discharge it below 3.5V or 5% of total capacity. Lower values, such as 3.2V for the cell, will permanently damage it and this is not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50% and the charge level should be checked periodically every two months. Store the battery and device in a dry place, away from sunlight and negative temperatures. Product battery specifications

Feature Value

Battery category Portable battery

Battery type Portable lithium-ion (Li-Ion) batteries

Contains Cadmium/Lead (>0.002% Cd, >0.004% Pb)

Net weight (kg) 19.3g

Capacity (mAh) 600

Power (kWh) 2.22WH