


PETKIT

PET GROOMING KIT

PETKIT AIRCLIPPER 5-IN-1

User Instruction



Please read the user instruction carefully prior to product use and keep it in a safe place.

CONTENT


Product list	03
Product installation	05
Product use	06
Maintenance & cleaning	11
Basic specifications	14
A message to our valued customers	15
User safety guide	15

REMINDER

Before use:

- Press the PUSH button on the front side of the dust cup.
- After the dust cup is lifted slightly, it can be removed.
- Open the dust cup buckle and take out the functional parts.


01 PRODUCT LIST



Funktionsteile



Zubehörteile



02 PRODUCT INSTALLATION

1. Dust cup installation

- Align the dust cup buckle with the main device slot.
- Press the end of the dust cup until heard a "click" sound, which means the installation is successful.

2. Soft hose installation


- Align point ① of the hose with the hose connector point ②, after inserting screw it clockwise to the end to ensure that the point ③ is aligned with point ④.

*Note: Please do not use the product for animal body parts with sharp claws or sharp teeth.

3. Functional parts installation and removal (Following picture uses electric clippers as an example, and the installation method of other functional parts is the same)

- Functional part installation: Insert the hose connector into the functional part and fasten tightly.
- Functional part removal: Press the button on the hose lightly to remove the functional part.

4. Assembly completed




03 PRODUCT USE

1. Turn on device and mode selection

- Insert power cable, press On/Off button to start the device.

3 suction level to select



* Note: The product has a voltage error protection setting, when the indicators flash at the same time, and there is a "drip" sound when pressing the button. Please check whether the power input voltage is wrong.

2. Electric clipper

- Can be used for daily fur trimming, the body fur trimmer can shave body fur, and the paw trimmer can shave paw fur and fur around the eyes.

*Note: Please be careful around the soft area of pet's skin, do not use excessive force to avoid skin scratches.

*To avoid damage to the product, please use a power adapter with an output of DC 5V 1A for charging.

*The electric clipper is equipped with overcharging charge protection. When the charging voltage reaches 4.2V or above, the charging power will be cut off, and the power will automatically stop. After the power is cut off, the charging indicator light will not be lit. At this time, the device cannot be charged, charging can resume after replacing with the correct power adapter.

Battery indicator light (working state)


Three blue lights on	Full battery state	Flashing red light	Begin charging
Two blue lights on	Medium battery	Red light is on	Charging
One blue light on	Low battery state	No light	Battery has not out

Battery indicator light (charging state)

Three blue lights on	Battery fully charged
----------------------	-----------------------

Comb attachments use

- When using comb attachments, please move a safe distance to effectively control the overall fur length.



Replacement of trimmer

- Step 1: Turn the attachment counterclockwise to the end and take it out upwards.

- Step 2: Vertically install the replacement attachment at an angle of 45°, and rotate it clockwise to the end.

Electric trimmer use instructions

- *Note: Remember to pay attention to the clipper edge and sharp position during use, and don't use excessive force to avoid skin scratches.

第1页

第2页

第3页

第4页

第5页

第6页


第7页

第8页

2. Grooming brush

- Can clean the remaining loose fur and dandruff on the pet's body, and also pulls the fur, making the fur more fluffy.


- Press the HOLD button and push it forward to the end, then push the HOLD button downward to complete the locking before start use.



- Install the Grooming brush on the hose, turn on the device, and comb along the direction of pet fur.



- When the Grooming brush accumulates a certain amount of fur, push the HOLD button up to unlock the comb, and push it forward repeatedly until the fur is sucked into the dust cup.




When the Grooming brush is not in use, it is recommended to adjust the HOLD button to the unlocked state for easy storage.


3. Deshedding brush

- Can comb away remaining fur and dandruff, and can thin and unknot the fur.


- Press the HOLD button and push it forward to the end, then push the HOLD button downward to complete the locking before use.



- Install the Deshedding brush on the hose, turn on the device, and then press the end of the dust cup. After heard a "click" sound, the installation is successful.



- When the Deshedding brush accumulates a certain amount of fur, push the HOLD button up to unlock the comb, and push it forward repeatedly until the fur is sucked into the dust cup.



*Note: Please be careful around the soft area of pet's skin, and don't use excessive force to avoid skin scratches.

*When the fur deshedding brush is not in use, it is recommended to adjust the HOLD button to the unlocked state for easy storage.

04 MAINTENANCE & CLEANING

1. Dust cup cleaning

- Press the PUSH button and wait for the dust cup to lift up slightly to remove the dust cup.



- After opening the dust cup lid, remove the fur and clean the dust cup.



2. Electric clipper cleaning

- Rinse and wet the blade on the front side of the trimmer in the arrow direction.




- Electric clipper body cannot be washed.


*The filter cotton should be washed regularly with cold water. It is recommended to replace the hepa filter screen if the screen is contaminated. The maintenance period varies according to the frequency and conditions of use. Please clean it regularly. When cleaning, remember to turn off the power and unplug the plug from the socket. Be sure to install the filter cotton after it is dry. Filter cotton that is not dried will cause electric shock and device malfunction.

3. Filter cotton cleaning


- Turn off power supply, remove dust cup and filter cotton.




- Rinse the hepa filter screen in cold water and gently wring it out.



- Install the dried hepa filter screen back. Note: the front is facing outward (the lettering is on the front).




- Place in a ventilated place to dry for more than 24 hours until completely dry.




*Note: The hepa filter screen shall be cleaned with cold water at least once a month. It is recommended to replace the hepa filter screen if the screen is contaminated. The maintenance period varies according to the frequency and conditions of use. Please clean it regularly. When cleaning, remember to turn off the power and unplug the plug from the socket. Be sure to install the hepa filter screen after it is dry. Hepa filter screen that is not dried will cause electric shock and device malfunction.

4. Hepar filter screen cleaning


- Turn off the power, take out the dust cup and the hepa filter screen.



- Rinse the hepa filter screen in cold water and gently wring it out.



- Install the dried hepa filter screen back. Note: the front is facing outward (the lettering is on the front).



- Place in a ventilated place to dry for more than 24 hours until completely dry.




*Note: The hepa filter screen shall be cleaned with cold water at least once a month. It is recommended to replace the hepa filter screen if the screen is contaminated. The maintenance period varies according to the frequency and conditions of use. Please clean it regularly. When cleaning, remember to turn off the power and unplug the plug from the socket. Be sure to install the hepa filter screen after it is dry. Hepa filter screen that is not dried will cause electric shock and device malfunction.

4. Hepar filter screen cleaning

- Turn off the power, take out the dust cup and the hepa filter screen.




- Rinse the hepa filter screen in cold water and gently wring it out.



- Install the dried hepa filter screen back. Note: the front is facing outward (the lettering is on the front).



- Place in a ventilated place to dry for more than 24 hours until completely dry.



*Note: The hepa filter screen shall be cleaned with cold water at least once a month. It is recommended to replace the hepa filter screen if the screen is contaminated. The maintenance period varies according to the frequency and conditions of use. Please clean it regularly. When cleaning, remember to turn off the power and unplug the plug from the socket. Be sure to install the hepa filter screen after it is dry. Hepa filter screen that is not dried will cause electric shock and device malfunction.

05 BASIC SPECIFICATIONS

1. Main device parameters

Product name:	PET GROOMING KIT (PETKIT AIRCLIPPER 5-in-1)
Product model:	LM4
Main device dimensions:	309 *220 *140mm
Recommended pet types:	Cats and dogs aged 6 months and above
Product material:	ABS
Total weight:	approx. 3.15kg
Soft hose length:	1.5m
Dust cup capacity:	1.4L
Power cable length:	2.5m
Maximum noise:	75dBA

2. Electric clipper parameters

Input:	DC 5V 1A
Power rating:	5W
Charge time:	approx. 3 hours
Operational duration:	approx. 2.5 hours
Lithium battery:	3.7V 1400mAh

07 A MESSAGE TO OUR VALUED CUSTOMERS

- Thank you for purchasing PET GROOMING KIT (PETKIT AIRCLIPPER 5-in-1). We at PETKIT have done our best to make life easier for you and your pets with technology.
- Please carefully read the User Manual before using the product. By setting up and using this product, you are acknowledged that you have already read and accepted the safety guidelines listed below.
- We are not liable and will not accept responsibility for any accidents or injuries that result from improper use of this product.
- PETKIT reserves the rights of interpretation and revision.

08 USER SAFETY GUIDE

- * Failure to follow the safety guides outlined below result in product malfunction, or other accidental losses.

- This device is only suitable for indoor use in a dry environment, do not use it on wet ground.

- Please place the device on a hard and flat surface for use, and do not place on a soft and uneven object to prevent the device from falling.

- Do not use or store this product in damp places such as outdoors or bathrooms.

- It is forbidden to suck in wet hair and liquid, so as not to cause device short circuit.

- The device is to be used on cats and dogs over 6 months old.

- Minors are prohibited from using this device.

- Do not operate with wet hands or unplug the power cord to avoid malfunction and electric shock.

- If the device has a persistent burnt smell, stop use immediately.

- Please clean the dust cup and filter cotton regularly to avoid excessive dirt buildup and device malfunction.

- During maintenance and cleaning, please make sure that the power cord is removed.

- If the device temperature rises abnormally during use, please stop use immediately.

- Do not pinch or pull the power cord, and do not place heavy objects on top of the device.

- If the device motor heats up abnormally or the air inlet is blocked, please stop use immediately, take out the dust cup, make sure the air inlet and filter cotton are clean, and turn on the device after 40 minutes.

- Before use, please ensure that the filter cotton and filter screen have been installed to avoid damage to the motor.

- When plugging the electrical wire will cause electric leakage, please ensure pet safety.

- For prolonged storage, please switch off the power first and then unplug the power cord.

- Please do not place in direct sunlight and keep away from ignition sources.

- Please do not use this product if the power cord or power plug is damaged.

- Do not soak this product in water.

- Do not stick items on top of the device.

- Please use the provided power cord, otherwise it will damage the equipment or cause potential safety hazards.

- Do not disassemble the equipment without authorization, and must be repaired under the guidance of professionals to avoid accidental injuries.

- If you encounter any problem while using this product, please contact us immediately.

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

- FCC warning: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- Warning: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can receive radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications; however, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

- The device has been evaluated to meet general RF exposure requirement.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- Caution: This device complies with Industry Canada (Interne-empté RSS) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

- French: L'appareil respecte les normes aux OMI d'Industrie Canada applicables aux appareils radio exempts de licence. L'opération de l'appareil est soumise aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) L'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait causer le fonctionnement indésirable de l'appareil.

- The device has been evaluated to meet general RF exposure requirement.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- Caution: This device complies with Industry Canada (Interne-empté RSS) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

- French: L'appareil respecte les normes aux OMI d'Industrie Canada applicables aux appareils radio exempts de licence. L'opération de l'appareil est soumise aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) L'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait causer le fonctionnement indésirable de l'appareil.

- The device has been evaluated to meet general RF exposure requirement.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- Caution: This device complies with Industry Canada (Interne-empté RSS) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

- French: L'appareil respecte les normes aux OMI d'Industrie Canada applicables aux appareils radio exempts de licence. L'opération de l'appareil est soumise aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) L'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait causer le fonctionnement indésirable de l'appareil.

- The device has been evaluated to meet general RF exposure requirement.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- Caution: This device complies with Industry Canada (Interne-empté RSS) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

- French: L'appareil respecte les normes aux OMI d'Industrie Canada applicables aux appareils radio exempts de licence. L'opération de l'appareil est soumise aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) L'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait causer le fonctionnement indésirable de l'appareil.

- The device has been evaluated to meet general RF exposure requirement.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- Caution: This device complies with Industry Canada (Interne-empté RSS) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

- French: L'appareil respecte les normes aux OMI d'Industrie Canada applicables aux appareils radio exempts de licence. L'opération de l'appareil est soumise aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) L'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait causer le fonctionnement indésirable de l'appareil.

- The device has been evaluated to meet general RF exposure requirement.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- Caution: This device complies with Industry Canada (Interne-empté RSS) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

- French: L'appareil respecte les normes aux OMI d'Industrie Canada applicables aux appareils radio exempts de licence. L'opération de l'appareil est soumise aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) L'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait causer le fonctionnement indésirable de l'appareil.

- The device has been evaluated to meet general RF exposure requirement.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- Caution: This device complies with Industry Canada (Interne-empté RSS) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

- French: L'appareil respecte les normes aux OMI d'Industrie Canada applicables aux appareils radio exempts de licence. L'opération de l'appareil est soumise aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) L'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait causer le fonctionnement indésirable de l'appareil.

- The device has been evaluated to meet general RF exposure requirement.

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- Caution: This device complies with Industry Canada (Interne-empté RSS) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

第9页

第10页

第11页

第12页

第13页

第14页

第15页

第16页