

Contents

WARNING 1

WARRANTY 1

USB CHARGER OF FLASHLIGHT 1-3

USB CHARGER OF HEADLAMP 3-5

HOLDER CHARGER OF FLASHLIGHT 5

WARNING:

Dear valued customer, thank you very much for purchasing this product! Please properly read and understand this manual before using this product.

1. The product will get hot in the strong light mode,which is normal.
2. Do not illuminate the eyes directly with the flashlight to avoid eyes irritation caused by strong light.
3. Please charge when using for the first time or not using for a long time.
4. Please install the battery into torch in correct direction to avoid any damage for flashlight .it every 3 months to keep the battery in good condition.
5. Please keep the battery skin intact during use.Damage battery skin may cause short circuit fire or explosion.

WARRANTY:

1. All the flashlights purchased from our company are under warranty. If you have any flashlight quality problems within one whole year after purchasing, please feel free to contact us anytime.
2. The warranty time of battery and charger etc. is 3 months after purchasing.
3. If your battery isn't used for a very long time,please recharge and discharge it every 3 months to keep the battery in good condition.
4. We won't accept any problems caused by any personal actions and unreasonable usage.
5. If there's any quality products, please sent the product back with the warranty card.

INSTRUCTIONS FOR USB CHARGER OF FLASHLIGHT:

INSTRUCTIONS

1. Using a USB cable plug into the USB interface of flashlight,and connect

the other side into USB charger,phone charger or any other USB devices. (As figure 1.1)




Figure 1.1 Power supply

2.The indicator light shows(blikes)red when charging or battery low,and turns to stable blue/green when fully charged. (As figure 1.2)




Figure 1.2 Charging ways

3. Some of the products could used as a power bank, you can charge you mobile phone.(As figure 1.3)




Figure 1.3 Power bank

INSTRUCTIONS FOR USB CHARGER OF HEADLAMP:

Different headlamps have different configurations and modes, please refer to the actual product.

1. Product switch and modes switch:
 - 1.1 Press the light switch to turn on the light, and continuously press the light to cycle between different modes. Long press 1-2S to turn off the lamp, some lamps do not support long-press to turn off.
 - 1.2 Some light switches are designed with auxilliary lights, and long press the switch to light up.
 - 1.3 Some lamps are designed for stepless dimming. Press and hold the button to continuously change the brightness of the lamp from strong to low or from low to strong, and release it to maintain the current brightness.
 - 1.4 Some lamps are designed with a sensor switch. Press the sensor function switch to turn on the sensor function. Wave your hand in front of the lamp to control the switch of the lamp's bright light mode. Press the induction function switch again to turn off the sensor control function.(As figure 1.4)




Figure 1.4 Sensor function




Figure 1.7 Headlamp adjustment

INSTRUCTIONS FOR HOLDER CHARGER OF FLASHLIGHT:

Remove the battery from the flashlight and place it in the charging slot. Please pay attention to the positive and negative poles of the battery.(As figure 1.8)




Figure 1.8 Battery positive and negative

Press the button at the Tail or Middle to turn On/Off the power,tap to adjust the modes,and then press the light to cycle between different modes,and long press 2'S any mode to shut down.(As figure 1.9)




Figure 1.9 Light modes

Note: The lighting modes of different models of flashlights will be inconsistent, not limited to the above five lighting modes

APPLICATION SCENARIO




Outdoor Lighting



Daily Lighting



Adventure Lighting



Emergency Lighting



Maintenance Lighting



Work Lighting



Home Lighting



Camping Lighting




Figure 1.5 Charging way

3. Focusing function:
Some lamps have a focusing function, which can be achieved by pushing, pulling or rotating the lamp head.(As figure 1.6)




Figure 1.6 Focusing ways

4. The size of the headlight belt can be adjusted according to the situation, so that the lamp does not obviously, the tightness can be adjusted by yourself.(As figure 1.7)