

尺寸：80x120mm

FOCUSING HEADLAMP

HL25 SERIES


GENERAL USER MANUAL

WARNING

Dear valued customer, thank you very much for purchasing this product!
Please properly read and understand this manual before using the product.
Notice:

- 1.In order to bring you a better user experience, after receiving the new product, it is recommended to fully charge before using it.
- 2.This product is not a toy, please keep it away from children, and do not direct light to people's eyes, so as not to affect vision.
- 3.All the product parameters provided in this manual are tested by our company's laboratory standard samples and are for reference only, and may vary slightly due to different samples and environments.

INSTRUCTIONS




Switch Mode :


- 1.HL25 press the right switch to turn on the mode (low light - medium light - strong light - strobe - auxiliary light - main and auxiliary light - off); HL25-A press the right switch to turn on the mode (strong light - medium light -low light - Strobe light - auxiliary light - main and auxiliary light - off) cycle to turn on, in any mode, double-click to turn on the red light, press the red light again to strobe, when the red light mode is turned on, press it again to return to the original mode, any mode Long press to turn off the light source.
- 2.HL25 series adjust the focal length by rotating the head, rotate counterclockwise for spotlight mode, and rotate clockwise for flood mode.




Hand wave sens or demo



Focusing



Charging Display



Function Display

Motion Sensor:

Press the left induction switch to turn on the induction function, the induction indicator lights up, you can wave your hand to switch the light within 10cm, click the right switch to adjust the mode normally, and continue to press the induction switch to shut down.

Indicator Light Mode:

The headlamp is equipped with a Type-C charging port, and the headlamp can be charged with chargers, power banks, computers and other devices. The red light is always on when charging, and the green light is always on when full.

APPLICATION SCENARIO



Model	Power	Charging ways	Distance	Weight	Size	Light Modes
HL25	15W	Type-C	210M	170G	75*45*81mm	Low Light-Medium Light Strong Light-Strobe-Auxiliary Main and Auxiliary Light Red Light-Red Strobe Light
HL25-A	7W	Type-C	233M	123G	75*45*81mm	Strong Light-Medium Light Low Light-Strobe-Auxiliary Main and Auxiliary Light Red Light-Red Strobe Light